



NOTES:

1. USE CLIP ANGLE BETWEEN STIFFENERS. 8'-6" IS MAXIMUM SUPPORT SPACING.
2. HOLE SIZE IN CONN. STIFFENERS MAY BE THE SAME AS OTHER HOLES IN THE STIFFENER (MIN. 13/16").
3. USE SUPPORT BETWEEN STIFFENERS. 8'-6" IS MAXIMUM SUPPORT SPACING.

SHOP INSTALLED
SAFETY HANDRAIL DETAILS

ISSUED: 2009

PLATE
3.9-7