

How to Make a CD Hovercraft

Materials:

- Old CD or DVD disc
- large balloon
- pop-top cap from a liquid soap bottle or a sport water bottle
- hot glue gun

Instructions:

- Decorate your CD with Sharpie markers, stickers, or other items you may have on hand if desired.
- Use hot glue to glue the soap bottle or sport water bottle cap to the center of the CD or DVD disc. The cap will cover the hole in the disc. Create a good seal to keep air from escaping. You can cover the center hole of the CD with a piece of tape and poke about 6 holes in the tape with a push-pin or small nail prior to gluing on the cap. This will slow down the flow of air and allow your hovercraft to hover longer.
- Blow up the balloon all the way and pinch the neck of it to keep air from escaping. (Don't tie it.)
- Make sure the pop-top is closed and fit the neck of the balloon over the pop-up portion of the cap.
- When you're ready to commence hovering, simply put the craft on a smooth surface and pop the top open.

