

**Pennsylvania  
New Jersey  
Delaware  
Maryland**

**Implementation  
Guideline**

For  
**Electronic Data Interchange**

TRANSACTION SET

**867**

**Monthly Usage**

**Ver/Rel 004010**

## Table of Contents

Summary of Changes.....	4
General Notes.....	7
Pennsylvania Notes .....	10
New Jersey Notes .....	12
Maryland Notes .....	15
How to Use the Implementation Guideline .....	20
X12 Structure .....	21
Data Dictionary for 867 Monthly Usage .....	22
Segment: ST Transaction Set Header.....	29
Segment: BPT Beginning Segment for Product Transfer and Resale .....	30
Segment: DTM Date/Time Reference (649=Document Due Date) .....	32
Segment: MEA Measurements (NP=Percent Participation).....	33
Segment: N1 Name (8S=LDC Name) .....	34
Segment: N1 Name (SJ=ESP Name).....	35
Segment: N1 Name (G7=Renewable Energy Provider Name).....	36
Segment: N1 Name (8R=Customer Name) .....	37
Segment: REF Reference Identification (12=LDC Account Number).....	38
Segment: REF Reference Identification (45=LDC Old Account Number).....	39
Segment: REF Reference Identification (11=ESP Account Number).....	40
Segment: REF Reference Identification (BLT=Billing Type).....	41
Segment: REF Reference Identification (PC=Bill Calculator) .....	42
Segment: PTD Product Transfer and Resale Detail (BB=Billed Summary) .....	43
Segment: DTM Date/Time Reference (150=Service Period Start) .....	44
Segment: DTM Date/Time Reference (151=Service Period End) .....	45
Segment: QTY Quantity (Billed kwh) .....	46
Segment: QTY Quantity (Billed Demand).....	47
Segment: QTY Quantity (Measured Demand) .....	48
Segment: PTD Product Transfer and Resale Detail (SU=Metered Services Summary) .....	49
Segment: DTM Date/Time Reference (150=Service Period Start) .....	50
Segment: DTM Date/Time Reference (151=Service Period End) .....	51
Segment: QTY Quantity.....	52
Segment: PTD Product Transfer and Resale Detail (PM=Metered Services Detail) .....	53
Segment: DTM Date/Time Reference (150=Service Period Start) .....	54
Segment: DTM Date/Time Reference (151=Service Period End) .....	55
Segment: DTM Date/Time Reference (514=Meter Exchange Date).....	56
Segment: REF Reference Identification (6W=Channel Number).....	57
Segment: REF Reference Identification (MG=Meter Number) .....	58
Segment: REF Reference Identification (NH=LDC Rate Class).....	59
Segment: REF Reference Identification (PR=LDC Rate Subclass) .....	60
Segment: REF Reference Identification (JH=Meter Role) .....	61
Segment: REF Reference Identification (IX=Number of Dials/Digits).....	62
Segment: QTY Quantity.....	63
Segment: MEA Measurements .....	65
Segment: MEA Measurements (MU=Meter Multiplier) .....	67
Segment: MEA Measurements (ZA=Power Factor).....	68
Segment: MEA Measurements (CO=Transformer Loss Multiplier) .....	69
Segment: PTD Product Transfer and Resale Detail (BP= Bill Presentment) .....	70
Segment: DTM Date/Time Reference (150=Service Period Start) .....	71
Segment: DTM Date/Time Reference (151=Service Period End) .....	72
Segment: DTM Date/Time Reference (514=Meter Exchange Date).....	73
Segment: REF Reference Identification (MG=Meter Number) .....	74
Segment: REF Reference Identification (NH=LDC Rate Class).....	75
Segment: REF Reference Identification (PR=LDC Rate Subclass) .....	76
Segment: REF Reference Identification (K6=LDC Rate Description).....	77
Segment: REF Reference Identification (JH=Meter Role) .....	78

Segment:	REF Reference Identification (IX=Number of Dials/Digits).....	79
Segment:	REF Reference Identification (Unmetered Service Type).....	80
Segment:	QTY Quantity.....	81
Segment:	MEA Measurements .....	83
Segment:	MEA Measurements (MU=Meter Multiplier) .....	85
Segment:	MEA Measurements (ZA=Power Factor).....	86
Segment:	MEA Measurements (CO=Transformer Loss Multiplier) .....	87
Segment:	PTD Product Transfer and Resale Detail (BC=Unmetered Services Summary).....	88
Segment:	DTM Date/Time Reference (150=Service Period Start) .....	89
Segment:	DTM Date/Time Reference (151=Service Period End) .....	90
Segment:	QTY Quantity.....	91
Segment:	PTD Product Transfer and Resale Detail (BJ=Generation Transferred In/Out).....	92
Segment:	DTM Date/Time Reference (150=Service Period Start) .....	93
Segment:	DTM Date/Time Reference (151=Service Period End) .....	94
Segment:	QTY Quantity.....	95
Segment:	MEA Measurements .....	97
Segment:	SE Transaction Set Trailer.....	100
Examples:	.....	101
Example 1 – One Meter – On/off peak:.....		101
Example 2 – One Meter - Totalizer .....		102
Example 3 – One Meter – Totalizer Only – No Demand: .....		103
Selected Billing Test Scenarios:.....		104
Scenario - Single meter totalized (one rate), Month 1 .....		104
Scenario - Single meter with time of day billing, Month 1 .....		104
Scenario - Single meter totalized. Meter switched by LDC during month 1.....		105
Scenario - Single meter. , Demand and KWH meter (non-interval), Month 1 .....		106
Scenario - Multiple meters. Demand and KWH meter (non-interval). .....		106
Scenario - Multiple services, metered and unmetered. ....		107
Scenario - Unmetered Service alone.....		108
Scenario - Single meter totalized (one rate), month 2 .....		109
Scenario - Cancel Months 1 and 2.....		110
Scenario - Restatement of usage for Months 1 and 2. ....		111
Scenario - FINAL during month 2. ....		111
Scenario - Single meter. Demand and KWH meter (non-interval), Month 1: .....		112
Pennsylvania, & New Jersey (not PSE&G or FirstEnergy) Net Metering / Customer Generation Examples ....		112
Pennsylvania Net Metering / Customer Generation Examples (“Bank Rollover”) / not FirstEnergy .....		118
Pennsylvania Net Metering / Customer Generation Examples (FirstEnergy Companies) .....		120
New Jersey ( PSE&G) Net Metering / Customer Generation Examples.....		122
Maryland – 867 Monthly Usage - Multiple meter exchange in same service period.....		124
Maryland (BGE)- Examples of regular Net Metered Accounts with PTD*BJ loop (non-TOU/TOU) .....		125
Maryland (PHI/Potomac Edison)- Examples of regular Net Metered Accounts w/PTD*BJ loop (non-TOU/TOU) .....		139
Maryland (BGE) - Examples of PTD*BJ Loop for Aggregate Net Energy Metering (ANEM), Non-TOU .....		156
Maryland (PHI/PE) - Examples of PTD*BJ Loop for Aggregate Net Energy Metering (ANEM), Non-TOU ....		171
Maryland (BGE) - Examples of PTD*BJ Loop for Aggregate Net Energy Metering (ANEM), TOU .....		188
Maryland (PHI/PE) - Examples of PTD*BJ Loop for Aggregate Net Energy Metering (ANEM), TOU .....		222
Maryland SCB Example – 1: Single Meter Consumption Only .....		253
Maryland SCB Example – 2: Single Meter On/Off Peak.....		255
Maryland SCB Example – 3: Multiple Unmetered Services .....		257
Maryland SCB Example – 4: Telecommunications Network.....		258
Maryland SCB Example – 5: Single TOU meter (kWh, kW, kVar & Power Factor) .....		259
Maryland SCB Example – 6: PEPCO Meter Exchange .....		262

	Summary of Changes
June 29, 1999 Version 1.0	Initial Release. Changes since last draft: <ul style="list-style-type: none"> <li>Changed “EGS” to “ESP” and “EDC” to “LDC” throughout the guideline. Removed “NJ Definitions” and replaced it with “LDC Definitions” and “ESP Definitions” in the Notes section.</li> <li>Added “How to use the implementation guideline” page. In addition, changed all headers to the true X12 definition. Also corrected the Table on Page 4 to reflect X12 definitions and added the words “X12 Structure” to the title on that page.</li> </ul>
July 1, 1999 Version 1.1	<ul style="list-style-type: none"> <li>Removed Code 77 from the BPT07 and modified code F to indicate that it is used when the customer account finals in addition to if the customer switched to a new ESP.</li> <li>Clarified that Document Due Date is not provided for cancel transaction.</li> <li>Added “Must Use” to MEA07 per the data dictionary.</li> <li>Added “... if the LDC reads the meter” to the requirements for the PTD*BB Loop.</li> </ul>
October 1, 1999 Version 1.1a	<ul style="list-style-type: none"> <li>Add Delaware Use for Delmarva</li> <li>Add BPT04 code to indicate this is for Summary Data only for an Interval customer.</li> <li>Added clarification to use of DTM*649 to indicate it should only be used for Bill Ready. It is not valid for Rate Ready or Dual Billing.</li> </ul>
November 4, 1999 Version 1.2	This is a FINAL version for Pennsylvania and New Jersey
November ??, 1999 Draft version 1.2MD1	<ul style="list-style-type: none"> <li>Add Maryland use to document – the changes were added to the version 1.2 of the regional standards</li> <li>Added Table of Contents</li> <li>Added Data Dictionary</li> </ul>
December 23, 1999 Version 1.2MD2	<ul style="list-style-type: none"> <li>Clarified use of X4 code for Maryland</li> <li>Noted that BGE can only provide billed demand</li> </ul>
January 17, 2000 Version 1.2MD3	<ul style="list-style-type: none"> <li>Clarified setting of DTM*649 for ESP consolidated bill</li> <li>Clarified REF*45 is only used when LDC sends transaction.</li> </ul>
April 20, 2000 Version 1.2MD4	<ul style="list-style-type: none"> <li>Clarified APS use of REF*45 in MD</li> <li>Incorporate PA Change Control X015 to add X5 as a valid value for BPT04</li> <li>Removed comment on mandatory use of PTD*BD loop for PA by 3/2000. This is being discussed as part of PA Change Control X018. While it is not determined if there are cases when this loop may be needed, it was agreed that it will not be mandatory by 3/2000.</li> <li>Add PA Notes Section</li> <li>Add MD Notes Section</li> </ul>
May 17, 2000 Version 1.2MD5	<ul style="list-style-type: none"> <li>Incorporate PA Change Control X023 – allow PM loop to be optional on a cancellation</li> </ul>
May 30, 2000 Version 1.2MD6	<ul style="list-style-type: none"> <li>Incorporate PA Change Control X018 – remove BD loop. PA decided this loop would not be used, and PA was the only state that intended to use this loop.</li> </ul>
June 26, 2000 Version 1.2MD7	<ul style="list-style-type: none"> <li>Added clarity to Meter Multiplier and Transformer Loss Multiplier definitions in Data Dictionary</li> <li>Added clarity to example titles</li> </ul>
August 14, 2000 Version 1.2MD8	<ul style="list-style-type: none"> <li>Add NJ Notes Section</li> <li>Add Note for PSE&amp;G on BPT07</li> <li>Added NJ Note for MEA05</li> </ul>
September 10, 2000 Version 1.3	This transaction is a new FINAL version for Pennsylvania, New Jersey, Maryland, and Delaware (Delmarva only).
October 19, 2001 Version 1.3rev01	<ul style="list-style-type: none"> <li>Incorporate Delaware Electric Coop (DEC) information for Delaware</li> </ul>

December 13, 2001 Version 1.3rev02	<ul style="list-style-type: none"> <li>- Incorporate PA Change Control 038 – change all references of PPL to PPL EU.</li> <li>▪ Add clarification to NJ Notes section for PSE&amp;G regarding support of detail interval data (summary level not an option). Also add PSE&amp;G clarification on cancel / rebills for supplier other than supplier of record. Remove note indicating PSE&amp;G does not support cross reference to the 810.</li> </ul>
January 9, 2002 Version 2.0	<p>1. Incorporate SMECO specific data for MD (MD Change Control 003)</p> <p>This transaction is a new FINAL version for Pennsylvania, New Jersey, Maryland, and Delaware.</p>
January 20, 2006 Version 2.0.1D	<ul style="list-style-type: none"> <li>• Incorporate NJ Change Control 005 (NJ CleanPower program changes)</li> <li>• Incorporate PA Change Control 039 to reflect “generated usage”</li> <li>• Incorporate NJ Change Control 006 to reflect current operations</li> </ul>
October 23, 2006 Version 2.0.2D	<ul style="list-style-type: none"> <li>• Incorporate NJ Change Control 008 to reflect NJ CleanPower – unmetered usage for RECO)</li> <li>• Incorporate NJ Change Control 009 to reflect NJ CleanPower change for partial usage.</li> <li>• Add clarifying notes for NJ Net Metering.</li> </ul>
February 12, 2007 Version 2.0.3F	<ul style="list-style-type: none"> <li>• Considered FINAL for PA and NJ</li> </ul>
February 22, 2009 Version 2.0.4D	<ul style="list-style-type: none"> <li>• Incorporate NJ Change Control PSEG-E-Ref45</li> </ul>
January 24, 2010 Version 2.1	<p>This transaction is a new FINAL version for Pennsylvania, New Jersey, Maryland, and Delaware.</p>
September 8, 2010 Version 2.1.1D	<ul style="list-style-type: none"> <li>• Incorporate PA Change Control 060 – (PA Admin/Cleanup)</li> <li>• Incorporate MD Change Control – Admin (Admin/Cleanup for MD)</li> </ul>
February 28, 2011 Version 3.0	<p>This transaction is a new FINAL version for Pennsylvania, New Jersey, Maryland, and Delaware.</p>
February 16, 2012 Version 3.01	<ul style="list-style-type: none"> <li>• Incorporate PA Change Control 093 (Admin Changes)</li> <li>• Incorporate MD Change Control 010 (PEPCO AMI/Smart Meter support)</li> </ul>
March 8, 2013 Version 6.0	<ul style="list-style-type: none"> <li>• Moving to v6.0 to align versions across all transaction sets</li> <li>• Cleaned up references to Allegheny and APS throughout document</li> <li>• Incorporated PA Change Control 103 (uniform net meter consumption reporting)</li> </ul>
March 17, 2014 Version 6.1	<ul style="list-style-type: none"> <li>• Incorporate PA Change Control 105 Update2 (clarify net meter bank rollover)</li> <li>• Incorporate PA Change Control 111 (clarify PECO use of BPT04)</li> <li>• Incorporate PA Change Control 116 (update DLCO net meter looping)</li> <li>• Incorporate MD Change Control 018 (clarify multiple meter exchanges)</li> <li>• Incorporate MD Change Control 025 (867MU changes in PHI new CIS)</li> <li>• Incorporate MD Change Control 028 (BGE support interval usage via EDI)</li> <li>• Incorporate MD Change Control 029 (uniform net meter data reporting)</li> <li>• Incorporate NJ Change Control Electric 016 (uniform net meter data reporting)</li> <li>• Incorporate NJ Change Control Electric 020 (ACE new CIS; 867MU changes)</li> <li>• Incorporate NJ Change Control Electric 031 (RECO removal from IG)</li> </ul>
February 18, 2015 Version 6.2	<ul style="list-style-type: none"> <li>• Incorporate MD Change Control 036 (clarify net meter customer excess generation)</li> </ul>
February 5, 2016 Version 6.3	<ul style="list-style-type: none"> <li>• Incorporate PA Change Control 127 (Clarify PA Notes for net meter bank rollover)</li> <li>• Incorporate MD Change Control 039 (BGE net meter data reporting)</li> <li>• Incorporate MD Change Control 042 (Clarify MD Notes for net meter bank rollover)</li> </ul>
March 14, 2017 Version 6.4	<ul style="list-style-type: none"> <li>• Incorporate MD Change Control 048 (clarify Billed Demand reporting)</li> </ul>
May 18, 2018 Version 6.5	<ul style="list-style-type: none"> <li>• Incorporate PA Change Control 147 (Incorporate Citizens &amp; Wellsboro into IG)</li> <li>• Incorporate NJ Change Control Electric 040 (clarify Notes for PSEG Cancel/Rebill)</li> </ul>
March 22, 2019 Version 6.6	<ul style="list-style-type: none"> <li>• Incorporate MD Change Control 53 (Add new PTD*BJ loop)</li> <li>• Incorporate NJ Change Control Electric 048 (NJ Note – End of Clean Power Choice)</li> </ul>

**March 15, 2025**

Version 7.0

March 31, 2020 Version 6.7	<ul style="list-style-type: none"><li>• Incorporate PA Change Control 150v3 (FirstEnergy PA net meter data reporting)</li></ul>
March 25, 2021 Version 6.8	<ul style="list-style-type: none"><li>• Incorporate NJ Change Control Electric 053 (Add support for PTD*BJ Loop)</li></ul>
April 30, 2024 Version 6.9	<ul style="list-style-type: none"><li>• Incorporate MD Change Control 076v2 (Add Supplier Consolidated Billing)</li><li>• Incorporate MD Change Control 081 (Update Notes Section for Typo)</li></ul>
March 15, 2024	<ul style="list-style-type: none"><li>• Incorporate MD Change Control 089 (Add Community Solar Support for PE)</li><li>• Incorporate NJ Change Control Electric 056v4 (JCPL Net update for Net Metering)</li></ul>

## PTD Loops Definition

## General Notes

The PTD Loops are required. Some are used individually, others are used in pairs. This section describes the purpose of each PTD loop. Depending on the characteristics of the account, there may be a different number of loops.

**Monthly Billed Summary Information (PTD=BB):** This loop is always required for every type of account if the LDC reads the meter.

**Monthly Billed Summary (PTD01=BB):** One PTD per Account – Data obtained from the billing system to reflect the billing data for this account.

**Metered Services Information** (PTD01 = SU, PM and BP) – These loops are used to convey the usage for metered data, at both a detail level by meter by unit of measure (PTD01=PM) and for some units of measure, at a summary level for all meters (PTD01=SU).

**Metered Services Summary (PTD01=SU):** Summing to the account level by kWh and KVARH. Data is obtained from the metering system. For every PTD01=SU, there must be a PTD01=PM. The PTD01=SU loop will NEVER be provided for kW or KVAR.

**Metered Services Detail (PTD01=PM):** One or more PTDs, one for each unit of measure for each meter. Data is obtained from the metering system. In the case of one meter reporting one unit of measure (kWh), the PTD01=PM will be the same as the PTD01=SU and both must be provided. If you have two meters and each meter measures kW and kWh, you will send one PTD SU Loop. The kWh readings from Meter 1 and Meter 2 will be summed and provided in one PTD SU Loop.

**Bill Presentment Loop (PTD01 = BP): Maryland SCB Only**

One or more PTD=BP loops, one for each meter and unit of measure will be created to provide the MD SCB usage related information. Data is obtained from multiple Utility systems and provided to Suppliers to ensure all required information currently printed on Utility Invoices as well as details required to explain the Utility Charges will be available. This BP Loop is based primarily on the PM loop and will be generated in addition to each PM loop for each meter and Unit of measure. If there are multiple PM loops for Consumption and Generation, then there will be a BP loop created for each. There will also be unmetered information passed in the BP loop.

**Unmetered Services Information** (PTD01 = BC) – This loop is used to convey the usage for any unmetered portion of an account. This information must be provided at the summary level (PTD01=BC).

**Unmetered Services Summary (PTD01=BC):** Total Consumption for all unmetered services at the account level. Even though some of the consumption may be estimated, the consumption is reported as actual for unmetered services. The summary is required at this time for Unmetered Services.

**Generation Transferred In/Out** (PTD01 = BJ) – MARYLAND & NEW JERSEY ONLY: This loop is used to convey the generation usage transferred in/out for the period. Required if the account has net metering or is a part of an Aggregated Net Energy Metering (ANEM) Family. Maryland: Required if the account has net metering or is a part of an Aggregated Net Energy Metering (ANEM) Family. New Jersey: Required if the account has net metering.

Cancellations	<ul style="list-style-type: none"> <li>• The MEA is an optional segment on a cancellation.</li> <li>• Cancel 867s will be by metering period, i.e. same as the original 867's. Rebills may be for multiple periods.</li> <li>• The "from" and "to" dates on the cancel must match exactly with the original usage.</li> <li>• On a cancellation, the signs are not reversed (don't change positive usage to negative usage). Quantities will not be negative on Cancels. Cancels should be interpreted as negative consumption.</li> <li>• The consumption sent in the cancel must match the consumption sent in the original transaction.</li> <li>• Cancels must be sent at the same level of detail as the original usage. <ul style="list-style-type: none"> <li>• PA: Cancels must include all account and summary information, however, it is optional to include the PM loops.</li> </ul> </li> </ul>
Restatements	<ul style="list-style-type: none"> <li>• In order to restate usage for a period, the metering party must first completely cancel all usage for that period; then send the full set of restatement transactions.</li> <li>• If you receive a cancellation, you will not necessarily receive a restatement (i.e. if the data was sent to you in error in the first place).</li> <li>• The "from" and "to" dates on the restatement transactions do not have to match the corresponding original or cancel transactions for the same period.</li> <li>• Restatements across multiple cycles may match original from and to dates or may cross bill cycles.</li> <li>• An 867 cancel can be followed by an 867 original the next month. The metering period would include the metering period from the cancelled and the current usage.</li> </ul>
Reporting of usage if supplier is not providing 100% of generation	<p>The usage information provided in the 867 is the total usage not the prorated information. Meter reading party will always send total consumption rounded to nearest kWh.</p>
LDC Definitions:	<p>The term LDC (Local Distribution Company) in this document refers to the utility. Each state may refer to the utility by a different acronym:</p> <ul style="list-style-type: none"> <li>• EDC – Electric Distribution Company (Pennsylvania, Delaware)</li> <li>• LDC – Local Distribution Company (New Jersey)</li> <li>• EC – Electric Company (Maryland)</li> </ul>
ESP Definitions:	<p>The term ESP (Energy Service Provider) in this document refers to the supplier. Each state may refer to the supplier by a different acronym:</p> <ul style="list-style-type: none"> <li>• EGS – Electric Generation Supplier (Pennsylvania)</li> <li>• TPS – Third Party Supplier (New Jersey)</li> <li>• ES – Electric Supplier (Delaware)</li> <li>• ES – Electricity Supplier (Maryland)</li> </ul>
Cross Reference Number between 867, 810, and 820	<p>There is a cross reference between billing related documents.</p> <ul style="list-style-type: none"> <li>• 867 – BPT02 – This document establishes the cross reference number.</li> <li>• 810 – BIG05 – This document must have the cross reference number from the respective 867.</li> <li>• 820 – REF6O (letter O) – When making the other party whole, the 820 to the non-billing party must also include the cross reference number from 867/810 document.</li> </ul>

Total Usage is sent, even  
if supplier is not  
providing 100% of load.

The usage information provided in the 867 is the total usage not the prorated information. Meter reading party will always send total consumption rounded to nearest kWh. It is the obligation of the receiving party to apply their participation percentage to the total provided to determine their actual obligation. If the decimal is .50000 or less, it will go to the lower whole number; if the decimal is .50001 or greater, it will go to the next higher whole number ).

**What document is sent if supplier elects NOT to receive detail interval data?**

## **Pennsylvania Notes**

If a supplier elects to receive only summary level information for an interval account, they will receive an 867MU document.

The 867IU document will be used when interval detail and summary level data is being sent.

### **Pennsylvania:**

- Citizens and Wellsboro – will provide detail interval data using 867IU with BB, BO, PM loops. The default is summary and 867MU and is sent with BB, SU, PM (BPT04 will be “DD”).
- Duquesne – Will provide detail interval data using 867IU with BB, SU, and BQ loops. If summary level is requested, will provide an 867MU with BB, SU, and PM loops (BPT04 will be “X5”).
- FIRST ENERGY – Will provide detail interval data using 867IU with BB, SU, and BQ loops. If summary level is requested, will provide an 867MU with BB, SU, and PM loops (BPT04 will be “X5”).
- PECO – If account-level interval detail is requested, will provide using 867IU with BB, SU, and BQ loops. If meter-level interval detail is requested, will provide using BB, BO, and PM loops. Else, will provide an 867MU with BB, SU, and PM loops (BPT04 in 867MU will be “DD” for AMR monthly metered accounts and “X5” for interval metered accounts).
- PPL EU – Will provide detail interval data using 867IU with BB, SU, and BQ loops. If summary level is requested, will provide an 867MU with BB and SU loops (BPT04 will be “DD”).
- UGI – No interval customers.

**Requirements for uniform support of Net Metered Customers:**

**BB (Billed Summary) Loop** –reports the monthly billed summary usage for net metered customers.

- a. All PA EDCs (Excluding FirstEnergy)
  - i. When customer’s consumption is greater than generation, the billed KH usage in the QTY02 will be reported as net KH (generation subtracted from total consumption).
  - ii. When customer’s generation is greater than consumption, the billed usage in the QTY02 will be reported as 0 (zero) KH.
  - iii. In either scenario, the QTY02 will never be signed negative.
- b. FirstEnergy Companies
  - i. Reports the consumption (delivered) KH as the billed usage

**SU (Metered Services Summary) Loop** –reports the summary usage for net metered customers.

- a. All PA EDCs (Excluding FirstEnergy)
  - i. When the customer’s consumption is greater than generation, the KH will be reported as net consumption (QTY01 w/actual = QD or estimated = KA) with the total generation subtracted from total consumption.
  - ii. When the customer’s generation is greater than consumption, the KH will be reported as net generation (actual = 87 or estimated = 9H) with the total consumption subtracted from total generation).
  - iii. In either scenario, the QTY02 will never be signed negative.
- b. FirstEnergy Companies
  - i. Instead of reporting net KH in SU loop, FirstEnergy will report the consumption and generation separately
    1. Reports consumption (delivered) KH (QTY01 w/actual = QD or estimated = KA)
    2. Reports generation (generation) KH (QTY01 w/actual = 87 or estimated = 9H)

**Requirements for  
uniform support of Net  
Metered Customers  
(continued):**

PM (Meter Services Detail) Loop – The meter loop will report the meter level detail for net metered customers. This may be done via one of the three following configurations:

1. Single meter reporting both in and out flow. The PM loop for KH will be repeated, one reporting consumption and one reporting generation. Used by First Energy and PPL (MV90 only).
  - a. The meter number will be identical for each loop.
  - b. In the consumption loop, the meter role (REF\*JH) will be 'A' (additive) and the KH usage will be reported in quantity delivered (actual = QD or estimated = KA).
    - i. FirstEnergy Only: sends channel number (REF6W) with value of "1"
  - c. In the generation loop, the meter role (REF\*JH) will be 'S' (subtractive) and the KH usage will be reported as net generation delivered (actual = 87 or estimated = 9H).
    - i. FirstEnergy Only:
      1. Sends channel number (REF6W) with value of "2"
      2. Sends generation loop even when there is no generation reported for the period.
  - d. The QTY02 will never be signed negative
  - e. Being this is a single meter, the meter attributes will remain the same for both PM loops.
2. Single meter reporting only the net consumption, one PM loop for KH. Used by PPL (non-MV90), Duquesne Light and Citizens & Wellsboro
  - a. When customer's consumption is greater than generation, the billed KH usage in the QTY02 will be reported as net KH (generation subtracted from total consumption). The meter role (REF\*JH) will be 'A' (additive).
  - b. When customer's generation is greater than consumption, the KH usage will be reported as net generation delivered (actual = 87 or estimated = 9H). The meter role (REF\*JH) will be 'S' (subtractive).
  - c. The QTY02 will never be signed negative.
3. Separate meters, one reporting inflow and another meter reporting outflow. The PM loop will be repeated for KH, one meter reporting consumption and one meter reporting generation. Used by PECO and UGI.
  - a. The meter number should be unique for each KH loop. The meter attributes for each KH loop may have different values.
  - b. In the consumption loop, the meter role (REF\*JH) will be 'A' (additive) and the KH usage will be reported in quantity delivered (actual = QD or estimated = KA).
  - c. In the generation loop, the meter role (REF\*JH) will be 'S' (subtractive) and the KH usage will be reported as net generation delivered (actual = 87 or estimated = 9H).
  - d. The QTY02 will never be signed negative.

**Banked KH adjustment  
for excess customer  
generation:**

Applies to FirstEnergy companies, PPLEU, Duquesne and UGI (PECO does NOT bank excess customer generation)

The LDC will apply excess generation KH from a prior month(s) into the billed quantity (D1) segment of the billed summary (BB) loop of the 867MU/IU transaction sets reducing billed consumption. When this occurs, the sum of the metered services (PM) loops will not equal the KH being reporting in the BB loop. In the event the banked KH is not exhausted it will carry over to the following month. Suppliers should understand this practice and examine current billing processes for net metered customers. In most cases, the customer's actual consumption and generation is made available in the PM (meter) loops of the 867MU/IU.

Settlement process for excess customer generation varies by EDC. EGSs should contact each EDC directly to obtain this information.

## New Jersey Notes

**Rockland Electric Company**

**What document is sent if supplier elects NOT to receive detail interval data?**

Rockland Electric Company (RECO) does not utilize this EDI implementation guideline. RECO uses the New York EDI implementation guidelines.

The standard method for interval accounts is to always pass interval data.

- JCP&L – JCP&L will allow the summary option under the same guidelines they use in PA. JCP&L will provide detail interval data using 867IU with BB, SU, and BQ loops. If summary level is requested, will provide an 867MU with BB, SU, and PM loops (BPT04 will be “X5”).
- Atlantic City Electric will allow a summary option. Atlantic City Electric will provide detail interval data using 867IU with BB, SU, and BQ loops. If summary level is requested, will provide an 867MU with BB, SU, PM, and BC loops. (BPT04 will be “X5”)
- PSE&G will not support supplier having a choice to receive summary only.

**Cancel / Rebill when supplier is no longer active supplier**

PSE&G: Before August 1st, 2016 (867 bill window close date)

PSE&G cannot provide consolidated billing for ESP's who are not supplier of record at the time the cancel / rebill is processed. The process for Cancel/ Rebill for an ESP who is not customer's current supplier of record is:

- PSE&G will cancel charges from 810(s) that correspond to the original 867(s) being canceled.
- Send 867(s) cancel
- Send 867(s) rebill noting that customer billing option is DUAL.
- PSE&G will issue an 820 and reduce a future payment by the amount of the canceled 810(s) (on the scheduled date of the 820).
- TPS must Dual bill customer for the rebilled 867(s).

PSE&G: On or After August 1st, 2016 (867 bill window close date)

PSE&G implemented a system enhancement that will allow the billing option to remain consolidated for a cancel/rebill processed after the customer-supplier relationship has terminated.

- PSE&G will cancel charges from 810(s) that correspond to the original 867(s) being canceled.
- Send 867(s) cancel
- Send 867(s) rebill noting that customer billing option is CONSOLIDATED.
- PSE&G will issue an 820 and reduce a future payment by the amount of the canceled 810(s) (on the scheduled date of the 820).
- TPS must send in 810 charges for the rebilled 867(s).
- PSE&G will issue an 820 for the amount of the 810(s) for the rebilled 867(s).

**Net Metering Information:**

PSE&G- Is currently using a bi-directional meter for the TPS's and providing the in reading as well as the out reading to the EDI process. For Clean Power suppliers a watt-hour meter which goes both ways ultimately provides the net usage to the EDI process.

Atlantic City Electric- Is currently using watt-hour meters that go both ways ultimately providing the net usage to the EDI process. This is for both the TPSs as well as the Clean Power providers.

JCP&L-Is currently using a bi-directional meter for both the TPS's as well as the Clean Power suppliers. The bi-directional meter is providing the in and the out reading to the EDI process. The EDI summary loop will include the net usage.

**Data Requirements for  
uniform support of Net  
Metered Customers:**

- BB (Billed Summary) Loop –reports the monthly billed summary usage for net metered customers.
  1. When customer’s consumption is greater than generation, the billed KH usage in the QTY02 will be reported as net KH (generation subtracted from total consumption).
  2. When customer’s generation is greater than consumption, the billed usage in the QTY02 will be reported as 0 (zero) KH.
  3. In either scenario, the QTY02 will never be signed negative.
- SU (Metered Services Summary) Loop –reports the summary usage for net metered customers. All NJ LDCs (excluding JCP&L)
  1. When the customer’s consumption is greater than generation, the KH will be reported as net consumption (QTY01 w/actual = QD or estimated = KA) with the total generation subtracted from total consumption.
  2. When the customer’s generation is greater than consumption, the KH will be reported as net generation (actual = 87 or estimated = 9H) with the total consumption subtracted from total generation).
  3. In either scenario, the QTY02 will never be signed negative.
- SU (Metered Services Summary) Loop –reports the summary usage for net metered customers.( JCP&L)
  1. Consumption (Usage) KH reported under QTY\*QD segment
  2. Generation KH reported under QTY\*87 (or 9H) segment
  3. In either scenario, the QTY02 will never be signed negative.
- PM (Meter Services Detail) Loop – The meter loop will report the meter level detail for net metered customers. This may be done via one of the three following configurations:
  1. Single meter reporting both in and out flow. The PM loop for KH will be repeated, one reporting consumption and one reporting generation. Used by Atlantic City Electric and PSE&G (Note: PSE&G sends one PM loop with separate QTY segments reporting generation and consumption)
    - a. The meter number will be identical for each loop. (Note: PSE&G sends one PM loop)
    - b. In the consumption loop, the meter role (REF\*JH) will be ‘A’ (additive) and the KH usage will be reported in quantity delivered (actual = QD or estimated = KA). (PSE&G sends meter role of ‘A’)
    - c. In the generation loop, the meter role (REF\*JH) will be ‘S’ (subtractive) and the KH usage will be reported as net generation delivered (actual = 87 or estimated = 9H). (N/A to PSE&G)
    - d. The QTY02 will never be signed negative
    - e. Being this is a single meter, the meter attributes will remain the same for both PM loops. (PSE&G sends one PM loop)
  2. Single meter reporting only the net consumption, one PM loop for KH. (Used by Atlantic City Electric)
    - a. When customer’s consumption is greater than generation, the billed KH usage in the QTY02 will be reported as net KH (generation subtracted from total consumption). The meter role (REF\*JH) will be ‘A’ (additive).
    - b. When customer’s generation is greater than consumption, the KH usage will be reported as net generation delivered (actual = 87 or estimated = 9H). The meter role (REF\*JH) will be ‘S’ (subtractive).
    - c. The QTY02 will never be signed negative.

**Data Requirements for  
uniform support of Net  
Metered Customers  
(Continued):**

**NJ Clean Power Choice**

3. Single meter, separate PM loops. The PM loop will be repeated for KH, one loop reporting consumption and one loop reporting generation. (Used by JCP&L)
  - a. In the consumption loop, the meter role (REF\*JH) will be 'A' (additive) and the KH usage will be reported in quantity delivered (actual = QD or estimated = KA). The REF\*6W Delivery Channel will be "1".
  - b. In the generation loop, the meter role (REF\*JH) will be 'S' (subtractive) and the KH usage will be reported as generation delivered (actual = 87 or estimated = 9H). The REF\*6W Delivery Channel will be "2".
  - c. The QTY02 will never be signed negative.
4. Separate meters, one reporting inflow and another meter reporting outflow. The PM loop will be repeated for KH, one meter reporting consumption and one meter reporting generation.
  - a. The meter number should be unique for each KH loop. The meter attributes for each KH loop may have different values.
  - b. In the consumption loop, the meter role (REF\*JH) will be 'A' (additive) and the KH usage will be reported in quantity delivered (actual = QD or estimated = KA).
  - c. In the generation loop, the meter role (REF\*JH) will be 'S' (subtractive) and the KH usage will be reported as net generation delivered (actual = 87 or estimated = 9H).
  - d. The QTY02 will never be signed negative.

Pursuant to Board Order, Docket No. QO18040393, the Clean Power Choice Program is coming to an end effective February 28, 2019. The EDI segments and data elements used for Clean Power Choice will remain in the EDI Implementation Guidelines to support any cancel/rebill scenarios or for future use in the event another program is established that may need these data elements

## Maryland Notes

### What document is sent if supplier elects NOT to receive detail interval data?

If a supplier elects to receive only summary level information for an interval account, they will receive an 867MU document.

With PHI new CIS, the 'SI' process will be supported by ALL interval metered accounts, not just those with smart meters.

**Note:** BGE – The default is that an ESP will receive interval data at the summary level only (BPT04 = DD)

- If an ESP wants to receive interval data at the detail level for AMI/Smart metered accounts, the ESP must submit "SI" in the LIN05 and "DETAIL" in the REF17.
- The ESP may request detail level interval data post enrollment by submitting a Change Request at a later date.
- For non-AMI/Smart metered interval accounts, the ESP will receive 867MU with the detail interval data posted to BGE's website.

If a supplier elects to receive detail and summary level information for an interval account, this is what they will receive, by utility.

- Delmarva & PEPCO – Supplier will receive 867IU for all accounts (unless supplier has requested summary data. If the supplier elects NOT to receive detail interval data, PHI will send EDI 867MU (BB/SU/PM/BC loops) with BPT04 = 'X5' for accounts the supplier requested summary interval usage. BG&E – For AMI/Smart metered accounts, will provide 867IU if requested as stated above. For non-AMI/Smart metered accounts, no 867IU will be sent. Interval data will be provided on web; however, an 867MU will be provided for the Summary data.
- Potomac Edison – Will provide detail interval data using 867IU with BB, SU, and BQ loops. If summary level is requested, will provide an 867MU with BB, SU, and PM loops (BPT04 will be "X5").

### Looping of DTM segments in the PM (meter) loop when multiple meter exchanges occur during the same service period

If the event the utility experiences multiple meter exchanges during the same service period, the following format applies.

867MU – PTD\*PM Loop – Position 020

DTM\*150\*20130114 – Service Period Start

DTM\*514\*20130117 – First Meter Exchange on 1/17/2013

DTM\*514\*20130117

DTM\*514\*20130119 – Second Meter Exchange on 1/19/2013

DTM\*514\*20130119

DTM\*151\*20130213 – Service Period End

### Requirements for uniform support of Net Metered Customers:

- BB (Billed Summary) Loop –reports the monthly billed summary usage for net metered customers.
  1. When customer's consumption is greater than generation, the billed KH usage in the QTY02 will be reported as net KH (generation subtracted from total consumption).
  2. When customer's generation is greater than consumption, the billed usage in the QTY02 will be reported as 0 (zero) KH.
  3. In either scenario, the QTY02 will never be signed negative.
- SU (Metered Services Summary) Loop –reports the summary usage for net metered customers.
  1. When the customer's consumption is greater than generation, the KH will be reported as net consumption (QTY01 w/actual = QD or estimated = KA) with the total generation subtracted from total consumption.
  2. When the customer's generation is greater than consumption, the KH will be

reported as net generation (actual = 87 or estimated = 9H) with the total consumption subtracted from total generation).

3. In either scenario, the QTY02 will never be signed negative.

■ PM (Meter Services Detail) Loop – The meter loop will report the meter level detail for net metered customers. This may be done via one of the three following configurations:

1. Single meter reporting both in and out flow. The PM loop for KH will be repeated, one reporting consumption and one reporting generation. (Delmarva, PEPCO)
  - a. The meter number will be identical for each loop.
  - b. In the consumption loop, the meter role (REF\*JH) will be 'A' (additive) and the KH usage will be reported in quantity delivered (actual = QD or estimated = KA).
  - c. In the generation loop, the meter role (REF\*JH) will be 'S' (subtractive) and the KH usage will be reported as net generation delivered (actual = 87 or estimated = 9H).
  - d. The QTY02 will never be signed negative
  - e. Being this is a single meter, the meter attributes will remain the same for both PM loops.
2. Single meter reporting only the net consumption, one PM loop for KH. (Potomac Edison& BGE non-Time of Use. See below for BGE Time of Use reporting))
  - a. When customer's consumption is greater than generation, the billed KH usage in the QTY02 will be reported as net KH (generation subtracted from total consumption). The meter role (REF\*JH) will be 'A' (additive).
  - b. When customer's generation is greater than consumption, the KH usage will be reported as net generation delivered (actual = 87 or estimated = 9H). The meter role (REF\*JH) will be 'S' (subtractive).
  - c. The QTY02 will never be signed negative.
3. Separate meters, one reporting inflow and another meter reporting outflow. The PM loop will be repeated for KH, one meter reporting consumption and one meter reporting generation.
  - a. The meter number should be unique for each KH loop. The meter attributes for each KH loop may have different values.
  - b. In the consumption loop, the meter role (REF\*JH) will be 'A' (additive) and the KH usage will be reported in quantity delivered (actual = QD or estimated = KA).
  - c. In the generation loop, the meter role (REF\*JH) will be 'S' (subtractive) and the KH usage will be reported as net generation delivered (actual = 87 or estimated = 9H).
  - d. The QTY02 will never be signed negative.

#### **Demand Reporting – Multiple suppliers during same billing period**

The following describes each utility's process for reporting Demand (K1) when multiple suppliers serve the same customer during the same billing period.

#### **BGE**

The demands passed in each 867MU/IU reflects the highest demand values that occurred during each supplier's sub-period, NOT the entire billing period. Demand values for each sub-period are NOT prorated.

BB Loop / QTY\*D1 - The highest overall demand (regardless of TOU Peak) that occurred in the supplier's sub-period. Although coded "D1", this may not be the highest overall demand billed by BGE for the entire billing period.

BB Loop / QTY\*QD - The highest recorded On Peak demand that occurred in the supplier's

sub-period (This may or may not be the highest overall billed "D1" demand).

**Potomac Edison (FirstEnergy)**

Will send the peak demand for the entire billing period in all 867s created for the period. If the customer's peak demand is 10.4 K1 for the whole billing period, all suppliers would receive 10.4K1 in their 867.

**PHI (Delmarva MD & PEPCO MD)**

Will prorate demand for the entire period based on the number of days served by the supplier.

If max demand for entire period is 90 and one supplier serves 15/30 days, PHI will send that supplier 45, if another supplier serves 10/30 days, will send that supplier 30, and if utility has remaining 5/30 days, they will have 15. PHI will implement this to be consistent with all meter types and to ensure the customer is never charged more than the maximum.

**Requirements for BGE non-residential Time of Use (TOU) Net Metered Customers:**

BGE non-residential Time of Use (TOU) only, refer to above section for non-TOU customer net metering data reporting requirements.

Samples provided in the back of this implementation guideline.

BGE's process 'trues up' customer net metering bank(s) upon supplier switch. BGE is settling on the KH value in the BB (billed) loop at PJM. BGE maintains a 'bank' for each TOU reading. When a customer's TOU reading for the month is generation it is placed into the bank. Once the TOU reading for the month is positive consumption, BGE will apply the bank. This process is not shown in the PM loop, as the PM loop is reporting meter readings not billing adjustments.

BB (Billed Summary) Loop –reports the monthly billed summary usage for net metered customers.

1. BGE will bill all positive consumption for each TOU reading minus any banked excess generation.
2. The QTY02 will never be signed negative.

SU (Metered Services Summary) Loop –reports the summary usage for net metered customers. This reports the customer's net usage for the billing period.

1. When the customer's consumption is greater than generation, the KH will be reported as net consumption (QTY01 w/actual = QD or estimated = KA) with the total generation subtracted from total consumption.
2. When the customer's generation is greater than consumption, the KH will be reported as net generation (actual = 87 or estimated = 9H) with the total consumption subtracted from total generation).
3. In either scenario, the QTY02 will never be signed negative.

PM (Meter Services Detail) Loop – The meter loop reports the meter level detail for TOU net metered customers from the metering system. Single meter reporting On-Peak, Off-Peak and Intermediate-Peak Time TOU in one PM loop.

1. The meter role (REF\*JH) will always report as additive (REF\*JH\*A) regardless if any generation is reported in the PM loop.
2. Each TOU reading may be reported as consumption (QTY01 w/actual = QD or estimated = KA) or generation (QTY01 w/actual = 87 or estimated = 9H) based on the usage. Note the TOU readings in the PM loop will not be based on the meter role, there will be cases where at least one TOU is generation and the meter role is 'Additive'.
3. The QTY02 will never be signed negative

**Net Metering – Excess  
Customer Generation**

Maryland legislation PUA 7-306 states the Electric Company, not the Electricity Supplier, must pay the customer for accrued net excess generation on an annual basis (April meter read). Furthermore the rule states... *“For customers served by an electricity supplier, the dollar value of the net excess generation shall be equal to the generation or commodity rate that the customer would have been charged by the electricity supplier multiplied by the number of kilowatt-hours of net excess generation.”* To support this requirement, each LDC maintains customer generation balance and for any excess generation during the annual true-up, the customer is credited based on their LDC or EGS rate.

**Net Metering – banked  
KH adjustment for  
excess customer  
generation**

Applies to Potomac Edison, BG&E, Delmarva MD and PEPCO MD

The LDC will apply excess generation KH from a prior month(s) into the billed quantity (D1) segment of the billed summary (BB) loop of the 867MU/IU transaction sets reducing billed consumption. When this occurs, the sum of the metered services (PM) loops will not equal the KH being reporting in the BB loop. In the event the banked KH is not exhausted it will carry over to the following month.

With MD EDI Change Control 053, the Generation Transferred In/Out (PTD01 = BJ) loop will identify the generation kWh being transferred In/Out as well as any Starting Bank or Ending Bank generation kWh.

In conjunction with Maryland excess generation rules, the EGS should understand this banked rollover practice and examine current billing processes for net metered customers. Example of banked KH adjustment (non-TOU customers)...

Month 1 – Customer consumes 200KH and generates 500KH, net is excess generation of 300KH. The utility sends 0KH in BB loop. Supplier would bill customer 0 KH

Month 2 – Customer consumes 500KH and generates 150KH, net is consumption of 350KH. The utility rolls banked excess of 300KH from prior month and applies to current month bill. Utility and supplier bill customer for 50KH (350KH – 300KH)

Settlement process for excess customer generation varies by LDC. Suppliers should contact each LDC directly to obtain this information.

**MD Supplier  
Consolidated Billing  
(SCB)**

MD SCB Usage Considerations:

MD SCB Bill Option includes a Purchase of Receivables process in which the Supplier is responsible for creating the consolidated customer bill utilizing information obtained via numerous EDI transactions including an 810 Invoice, 867MU or 867IU usage transactions, and the 814 Enrollment response and change transactions sent to the Supplier by the Utility. The following changes to the 867MU are to ensure the Supplier has access to data currently printed on the Utility bills that is required to be present on the MD SCB bill, as well as additional information that provides support for explaining Utility charges.

Bill Presentment – PTD=BP

Utilities will provide Meter Beginning Reading and Meter Ending Reading values on the MEA05 and MEA06 when available for the Supplier to include on the Customer SCB bill. There are some instances where this information is not currently provided consistently on the PM loops. The LDC Rate Description will be provided in a new REF\*K6 segment for all MD SCB accounts.

Utilities will also provide the following information when available and appropriate:

MU=Meter Multiplier (The meter multiplier will always be passed even when equal to 1.0).  
ZA=Power Factor  
CO=Transformer Loss Multiplier

Unmetered Services Information - PHI and Potomac Edison provide Unmetered usage at the device level on their current Utility Bills. BGE does not currently provide this detail on their bills and will not be required to send this information to MD SCB Suppliers at this time.

PHI and Potomac Edison will provide Unmetered Device Description, number of devices and usage in the BP loop for each unmetered device. PHI, Potomac Edison and BGE will provide an unmetered summary loop (PTD01= BC), containing total unmetered usage for the account.

The PTD\*BJ Loop is required for MD SCB 867 transactions for Potomac Edison that also participate in Community Solar programs. The BJ loop will provide information to be printed on the customer bill including the kwh amount of the usage base CS credit and the name of the community Solar program.

# How to Use the Implementation Guideline

**Segment:** **REF** Reference Identification  
**Position:** 030  
**Loop:** LIN  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** >1  
**Purpose:** To specify identifying information  
**Syntax Notes:** 1 At least one of REF02 or REF03 is required.  
 2 If either C04003 or C04004 is present, then the other is required.  
 3 If either C04005 or C04006 is present, then the other is required.  
**Semantic Notes:** 1 REF04 contains data relating to the value cited in REF02.  
**Comments:**

This section is used to show the X12 Rules for this segment. You must look further into the grayboxes below for State Rules.

<b>Notes:</b>	Recommended by UIG	
<b>PA Use:</b>	Must be identical to account number as it appears on the customer's bill, excluding punctuation (spaces, dashes, etc.). Significant leading and trailing zeros must be included.	
	Request:	Required
	Accept Response:	Required
	Reject Response:	Required
<b>NJ Use:</b>	Same as PA	
<b>Example:</b>	REF*12*2931839200	

The "Notes:" section generally contains notes by the Utility Industry Group (UIG).

This section is used to show the individual State's Rules for implementation of this segment.

One or more examples.

## Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>X12 Attributes</u>
Must Use	REF01	128	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification	M ID 2/3
		12	Billing Account	
			LDC assigned account number for end use customer.	
Must Use	REF02	127	<b>Reference Identification</b> Reference information as determined for a particular Transaction Set or as specified by the Reference Identification Qualifier	X AN 1/30

This column shows the use of each data element. If state rules differ, this will show "Conditional" and the conditions will be explained in the appropriate grayboxes.

These are X12 code descriptions, which often do not relate to the information we are trying to send. Unfortunately, X12 cannot keep up with our code needs so we often change the meanings of existing codes. See graybox for the UIG or state definitions.

This column shows the X12 attributes for each data element. Please refer to Data Dictionary for individual state rules.

M = Mandatory, O= Optional, X = Conditional  
 AN = Alphanumeric, N# = Decimal value,  
 ID = Identification, R = Real  
 1/30 = Minimum 1, Maximum 30

# 867 Product Transfer and Resale Report X12 Structure

Functional Group ID=**PT**

## Heading:

	<u>Pos. No.</u>	<u>Seg. ID</u>	<u>Name</u>	<u>Req. Des.</u>	<u>Max.Use</u>	<u>Loop Repeat</u>	<u>Notes and Comments</u>
Must Use	010	ST	Transaction Set Header	M	1		
Must Use	020	BPT	Beginning Segment for Product Transfer and Resale	M	1		
	050	DTM	Date/Time Reference	O	10		
	075	MEA	Measurements	O	20		
			LOOP ID – N1			5	
	080	N1	Name	O	1		
	120	REF	Reference Identification	O	12		

## Detail:

	<u>Pos. No.</u>	<u>Seg. ID</u>	<u>Name</u>	<u>Req. Des.</u>	<u>Max.Use</u>	<u>Loop Repeat</u>	<u>Notes and Comments</u>
			LOOP ID – PTD			>1	
Must Use	010	PTD	Product Transfer and Resale Detail	M	1		
	020	DTM	Date/Time Reference	O	10		
	030	REF	Reference Identification	O	20		
			LOOP ID – QTY			>1	
	110	QTY	Quantity	O	1		
	160	MEA	Measurements	O	40		

## Summary:

	<u>Pos. No.</u>	<u>Seg. ID</u>	<u>Name</u>	<u>Req. Des.</u>	<u>Max.Use</u>	<u>Loop Repeat</u>	<u>Notes and Comments</u>
Must Use	030	SE	Transaction Set Trailer	M	1		

## Data Dictionary for 867 Monthly Usage

<i>867 Monthly Usage</i>					
<i>Appl Field</i>	<i>Field Name</i>	<i>Description</i>	<i>EDI Segment</i>	<i>Related EDI Qualifier</i>	<i>Data Type</i>
<b>Header Information</b>					
1	Purpose Code	<b>00</b> – Original <b>01</b> – Cancellation – Cancels an entire Usage	BPT01		X(2)
2	Transaction Reference Number	Unique Number identifying this transaction assigned by the sender of the transaction. This number should be unique over all time. This number will also be shown on the related 810 document (both Bill Ready and Rate Ready), and for cases where the billing party makes the other party whole, on the 820 document.	BPT02		X(30)
3	System Date	Date that the data was processed by the sender's application system.	BPT03		9(8)
4	Report Type Code	“DD” Monthly Usage “X4” Summarized data for interval account at account level “X5” Summarized data for interval account at meter level “KJ” Meter Changeout when Meter Agent Changes – Monthly Usage (used to tell the receiver that this is a partial usage statement. The billing agent must sum the KJ usage and the DD usage to calculate the bill.)	BPT04	BPT01	X(2)
5	Final Indicator	Indicates if this is a final reading for that particular ESP (e.g., customer moves, customer switches, etc.).	BPT07 = <b>F</b>		X(1)
6	Transaction Reference Number	Transaction Reference Number echoed from BPT02 of the Original Transaction	BPT09		X(30)
7	Document Due Date/Time	The last date/time that information will be accepted by the billing party for processing the bill.  If 810 is received after this date/time, and the billing party cannot process it, they must notify the non-billing party (via email, phone call, etc.)	DTM02 (CCYYMMDD) and DTM03(HHMM)	DTM01= <b>649</b>	DTM02= 9(8) and DTM03= 9(4)
8	Percent Participation	Used to express the percentage of the total load that is being supplied by the ESP. This is the multiplication of two fields that are on the 814 transaction, AMT*7N (Participating Interest) and AMT*QY (Eligible Load).	MEA03	MEA02 = <b>NP</b>	9(1).9999 9
9	LDC Name	LDC's Name	N102	N1: N101 = <b>8S</b>	X(60)
10	LDC Duns	LDC's DUNS Number or DUNS+4 Number	N104	N1: N101 = <b>8S</b> N103 = <b>1</b> or <b>9</b>	X(13)
11	ESP Name	ESP's Name	N102	N1: N101 = <b>SJ</b>	X(60)
12	ESP Duns	ESP's DUNS Number or DUNS+4 Number	N104	N1: N101 = <b>SJ</b> N103 = <b>1</b> or <b>9</b>	X(13)
12.3	Renewable Energy	Renewable Energy Provider 's Name	N102	N1: N101 =	X(60)

	Provider Name			<b>G7</b>	
12.4	Renewable Energy Provider Duns	Renewable Energy Provider 's DUNS Number or DUNS+4 Number	N104	N1: N101 = <b>G7</b> N103 = <b>1</b> or <b>9</b>	X(13)
13	Customer Name	Customer Name	N102	N1: N101 = <b>8R</b>	X(60)
14	LDC Account Number	LDC Customer Account Number	REF02	N1: N101*8R Loop REF01 = <b>12</b>	X(30)
14.2	LDC Account Number - unmetered	LDC Customer Account Number – Unmetered	REF03	N1: N101 = <b>8R</b> REF01 = <b>12</b> REF03 = <b>U</b>	X(80)
15	Old Account Number	Previous LDC Customer Account Number	REF02	N1: N101*8R Loop REF01 = <b>45</b>	X(30)
16	ESP Account Number	ESP Customer Account Number	REF02	N1: N101*8R Loop REF01 = <b>11</b>	X(30)
17	Billing Type	Indicates type of billing - LDC consolidated Billing (REF02=LDC) - ESP consolidated Billing (REF02=ESP) - Dual bills (REF02=DUAL)	REF02	LIN: REF01= <b>BLT</b>	X(4)
18	Billing Calculation Method	Indicates party to calculate bill. - LDC calculates bill (REF02=LDC) - Each calculate portion (REF02=DUAL)	REF02	LIN: REF01= <b>PC</b>	X(4)
<b>Please refer to General Notes for details about the use of the PTD loop combinations.</b>					
<b>Monthly Billed Summary - Loop Required if the LDC reads the meter</b>					
This information is obtained from the billing system to reflect billing data for this account at the unit of measure level.					
19	Product Transfer Type	Monthly Billed Summary	PTD01= <b>BB</b>		X(2)
20	Service Period Begin Date	Start date of the period for which the readings are provided	DTM02	DTM01 = <b>150</b>	9(8)
21	Service Period End Date	End date of the period for which the readings are provided	DTM02	DTM01 = <b>151</b>	9(8)
22	Quantity Qualifier	Represents that the quantity was billed: <b>D1</b> - Billed	QTY01		X(2)
23	Quantity Delivered - Billed kWh	This data is taken from the LDC billing system and reflects the KWH amount on which the customer was billed.	QTY02	QTY01	- 9(10).9(4) )
24	Quantity Delivered Unit of Measurement	Indicates unit of measurement for quantity of consumption delivered during service period. <b>KH</b> - Kilowatt Hours	QTY03		X(2)
25	Quantity Qualifier	Represents that the quantity was billed: <b>D1</b> - Billed	QTY01		X(2)
26	Quantity Delivered - Derived or Billed Demand	Demand for which the customer was actually billed at account level only. Derived or billed demand is different from measured demand because the result is based on contract demand or rate minimum demand.	QTY02	QTY01	- 9(10).9(4) )
27	Quantity Delivered Unit of Measurement	Indicates unit of measurement for quantity of consumption delivered during service period. <b>K1</b> - Demand (kW)	QTY03		X(2)
28	Quantity Qualifier	Represents whether the quantity is actual or estimated: <b>KA</b> = Estimated Quantity Delivered <b>QD</b> = Actual Quantity Delivered	QTY01		X(2)

29	Quantity Delivered - Measured or Registered Demand	Reflects what the meter actual shows (including all factors except Power Factor) and is provided at the account level only.	QTY02	QTY01	- 9(10).9(4) )
30	Quantity Delivered Unit of Measurement	Indicates unit of measurement for quantity of consumption delivered during service period. <b>K1</b> - Demand (KW)	QTY03		X(2)
<b>Metered Services Summary - Loop required if there are metered services on the account</b>					
31	Product Transfer Type	Metered Services Summary	PTD01= <b>SU</b>		X(2)
32	Service Period Begin Date	Start date of the period for which the readings are provided	DTM02	DTM01 = <b>150</b>	9(8)
33	Service Period End Date	End date of the period for which the readings are provided	DTM02	DTM01 = <b>151</b>	9(8)
34	Quantity Qualifier	Represents whether the quantity is actual or estimated: <b>KA</b> = Estimated Quantity Delivered <b>QD</b> = Actual Quantity Delivered <b>87</b> = Actual Quantity Received (Net Meter) <b>9H</b> = Estimated Quantity Received (Net	QTY01		X(2)
35	Quantity Delivered	Represents quantity of consumption delivered for service period. Contains the difference in the meter readings multiplied by various factors, excluding Power Factor.	QTY02	QTY01	- 9(10).9(4) )
36	Quantity Delivered Unit of Measurement	Indicates unit of measurement for quantity of consumption delivered during service period. Only valid for KWH and KVARH.	QTY03		X(2)
<b>Metered Services Detail - Loop Required if there are metered services on the account</b>					
37	Product Transfer Type	Metered Services Detail	PTD01= <b>PM</b>		X(2)
38	Service Period Begin Date	Start date of the service period or start date of the changed in meter.	DTM02	DTM01 = <b>150</b>	9(8)
39	Service Period End Date	End date of the service period or end date of the changed out meter.	DTM02	DTM01 = <b>151</b>	9(8)
40	Meter Change Out Date	Used in conjunction with either the Service Period Start Date or the Service Period End Date to indicate when a meter has been replaced. Separate PTD loops must be created for each period and meter.	DTM02	DTM01 = <b>514</b>	X(12)
41	Meter Number	Serial number of this specific meter (may have multiple meters)	REF02	REF01 = <b>MG</b>	X(30)
42	LDC Rate Code	Code indicating the rate a customer is being charged by LDC per tariff. Codes posted on LDC's Web site	REF02	REF01 = <b>NH</b>	X(30)
43	LDC Rate Subclass Code	Used to provide further classification of a rate.	REF02	REF01= <b>PR</b>	X(30)
44	Meter Role	Effect of consumption on summarized total. <b>S</b> = Subtractive (consumption subtracted from summarized total). <b>A</b> = Additive (consumption contributed to summarized total - do nothing). <b>I</b> = Ignore (consumption did not contribute to summarized total - do nothing).	REF02	REF01 = <b>JH</b>	X(30)

45	Number of Dials / Digits and related decimal positions	Needed to determine usage if meter reading rolls over during the billing period. Number of dials on the meter displayed as the number of dials to the left of the decimal, a decimal point, and number of dials to the right of the decimal.	REF02	REF01 = <b>IX</b>	9.9
46	Quantity Qualifier	Represents whether the quantity is actual or estimated: <b>KA</b> = Estimated Quantity Delivered <b>QD</b> = Actual Quantity Delivered <b>87</b> = Actual Quantity Received (Net Meter) <b>9H</b> = Estimated Quantity Received (Net	QTY01		X(2)
47	Quantity Delivered	Represents quantity of consumption delivered for service period. Contains the difference in the meter readings (or as measured by the meter) multiplied by various factors, excluding Power Factor.	QTY02	QTY01	9(10).9(4)
48	Quantity Delivered Unit of Measurement	Indicates unit of measurement for quantity of consumption delivered during service period.	QTY03		X(2)
49	Measurement Reference Code	Code identifying category to which measurement applies.	MEA01		X(2)
50	Consumption	Represents quantity of consumption delivered for service period. Contains the difference in the meter readings (or as measured by the meter) multiplied by various factors, excluding Power Factor.	MEA03	MEA02 = <b>PRQ</b>	9(9).9(4)
51	Unit of Measure	Unit of measure for readings.	MEA04		X(2)
52	Beginning Reading	Value specifying beginning reading for the metering period. Factors have not been applied to this value.	MEA05		9(8).9(4)
53	Ending/Single Reading	The ending reading or single reading for metering period. Factors have not been applied to this value.	MEA06		9(8).9(4)
54	Measurement Significance Code	Code used to benchmark, qualify, or further define a measurement value.	MEA07		X(2)
55	Meter Multiplier	Meter Constant - used to represent how many units are reflected by one dial or digit increment.	MEA03	MEA02 = <b>MU</b>	9(9).9(4)
56	Power Factor	Relationship between watts and volt - amperes necessary to supply electric load	MEA03	MEA02 = <b>ZA</b>	9(9).9(4)
57	Transformer Loss Multiplier	Used when a customer owns a transformer and the transformer loss is not measured by the meter. Consumption figures from meter must be adjusted by this factor to reflect true end use consumption.	MEA03	MEA02 = <b>CO</b>	9(9).9(4)
<b>Unmetered Services Summary - Loop required if there are unmetered services on the account</b>					
58	Product Transfer Type	Unmetered Services Summary	PTD01= <b>BC</b>		X(2)
59	Service Period Begin Date	Start date of the period for which the readings are provided	DTM02	DTM01 = <b>150</b>	9(8)
60	Service Period End Date	End date of the period for which the readings are provided	DTM02	DTM01 = <b>151</b>	9(8)

61	Quantity Qualifier	Represents that the quantity is actual: <b>QD</b> = Actual Quantity Delivered	QTY01		X(2)
62	Quantity Delivered	Represents quantity of consumption delivered for service period.	QTY02	QTY01	9(10).9(4)
63	Quantity Delivered Unit of Measurement	Indicates unit of measurement for quantity of consumption delivered during service period.	QTY03		X(2)
<b>Bill Presentation Loop – Maryland SCB only</b>					
63.01	Product Transfer Type	Metered Services Detail	PTD01= <b>BP</b>		X(2)
63.02	Service Period Begin Date	Start date of the service period or start date of the changed in meter.	DTM02	DTM01 = <b>150</b>	9(8)
63.03	Service Period End Date	End date of the service period or end date of the changed-out meter.	DTM02	DTM01 = <b>151</b>	9(8)
63.04	Meter Change Out Date	Used in conjunction with either the Service Period Start Date or the Service Period End Date to indicate when a meter has been replaced. Separate PTD loops must be created for each period and meter.	DTM02	DTM01 = <b>514</b>	X(12)
63.05	Meter Number	Serial number of this specific meter (may have multiple meters). Metered accounts will have the Meter Number. Unmetered accounts will have the value <b>UNMETERED</b> .	REF02  Meter Number or “UNMETE RED”	REF01 = <b>MG</b>	X(30)
63.06	LDC Rate Code	Code indicating the rate a customer is being charged by LDC per tariff. Codes posted on LDC's Web site	REF02	REF01 = <b>NH</b>	X(30)
63.07	LDC Rate Subclass Code	Used to provide further classification of a rate.	REF02	REF01= <b>PR</b>	X(30)
63.075	LDC Print Summary Box Indicator	Used to Identify Additional Utility Bill print requirements.	REF02= (Y or N)	REF01= <b>K6</b>	X(30)
63.076	LDC Rate Description	Rate Description required per current Utility Bill requirements.	REF03	REF01= <b>K6</b>	X(80)
63.08	Meter Role	Effect of consumption on summarized total. S = Subtractive (consumption subtracted from summarized total). A = Additive (consumption contributed to summarized total - do nothing). I = Ignore (consumption did not contribute to summarized total - do nothing).	REF02	REF01 = <b>JH</b>	X(30)
63.09	Number of Dials / Digits and related decimal positions	Needed to determine usage if meter reading rolls over during the billing period. Number of dials on the meter displayed as the number of dials to the left of the decimal, a decimal point, and number of dials to the right of the decimal.	REF02	REF01 = <b>IX</b>	9.9
63.10	Quantity Qualifier	Represents whether the quantity is actual or estimated: <b>KA</b> = Estimated Quantity Delivered <b>QD</b> = Actual Quantity Delivered <b>87</b> = Actual Quantity Received (Net Meter) <b>9H</b> = Estimated Quantity Received (Net	QTY01		X(2)
63.11	Quantity Delivered	Represents quantity of consumption delivered for service period. Contains the difference in the meter readings (or as measured by the meter) multiplied by various factors,	QTY02	QTY01	9(10).9(4)

		excluding Power Factor.			
63.12	Quantity Delivered Unit of Measurement	Indicates unit of measurement for quantity of consumption delivered during service period.	QTY03		X(2)
63.13	Measurement Reference Code	Code identifying category to which measurement applies.	MEA01		X(2)
63.14	Consumption	Represents quantity of consumption delivered for service period. Contains the difference in the meter readings (or as measured by the meter) multiplied by various factors, excluding Power Factor.	MEA03	MEA02 = <b>PRQ</b>	9(9).9(4)
63.145	Usage Deviation	Usage Deviation (applies to Kilowatt Hours, Kilowatt Demand and Reactive Demand) Required when Billed Usage is different than the PRQ Consumption value provided in the PM loop.	MEA03	MEA02 = <b>RUD</b>	9(9).9(4)
63.15	Unit of Measure	Unit of measure for readings.	MEA04		X(2)
63.16	Beginning Reading	Value specifying beginning reading for the metering period. Factors have not been applied to this value.	MEA05		9(8).9(4)
63.17	Ending/Single Reading	The ending reading or single reading for metering period. Factors have not been applied to this value.	MEA06		9(8).9(4)
63.18	Measurement Significance Code	Code used to benchmark, qualify, or further define a measurement value.	MEA07		X(2)
63.19	Meter Multiplier	Meter Constant - used to represent how many units are reflected by one dial or digit increment.	MEA03	MEA02 = <b>MU</b>	9(9).9(4)
63.20	Power Factor	Relationship between watts and volt - amperes necessary to supply electric load	MEA03	MEA02 = <b>ZA</b>	9(9).9(4)
63.21	Transformer Loss Multiplier	Used when a customer owns a transformer and the transformer loss is not measured by the meter. Consumption figures from meter must be adjusted by this factor to reflect true end use consumption.	MEA03	MEA02 = <b>CO</b>	9(9).9(4)
<b>Generation Transferred In/Out (MD Only) - Loop required for net metered accounts or ANEM accounts</b>					
64	Product Transfer Type	Generation Transferred In/Out	PTD01= <b>BJ</b>		X(2)
65	Service Period Begin Date	Start date of the period for which the readings are provided	DTM02	DTM01 = <b>150</b>	9(8)
66	Service Period End Date	End date of the period for which the readings are provided	DTM02	DTM01 = <b>151</b>	9(8)
67	Quantity Qualifier	Represents the type of generation kWh: <b>77</b> = Generation transferred from another account to this account <b>78</b> = Generation transferred from another account to another account <b>79</b> = Self-generation applied from Starting Bank <b>QB</b> = Excess generation from True-Up event <b>QE</b> = Ending Bank <b>QH</b> = Starting Bank	QTY01		X(2)
68	Quantity Delivered	Represents quantity of consumption delivered for service period.	QTY02	QTY01	9(10).9(4)

69	Quantity Delivered Unit of Measurement	Indicates unit of measurement for quantity of consumption delivered during service period.	QTY03		X(2)
70	Measurement Reference Code	Code identifying category to which measurement applies.	MEA01		X(2)
71	Consumption	Represents quantity of consumption delivered for service period. Contains the difference in the meter readings (or as measured by the meter) multiplied by various factors, excluding Power Factor.	MEA03	MEA02 = <b>PRQ</b>	9(9).9(4)
72	Unit of Measure	Unit of measure for readings.	MEA04		X(2)
73	Measurement Significance Code	Code used to benchmark, qualify, or further define a measurement value.	MEA07		X(2)

**Segment:** **ST** Transaction Set Header  
**Position:** 010  
**Loop:**  
**Level:** Heading  
**Usage:** Mandatory  
**Max Use:** 1  
**Purpose:** To indicate the start of a transaction set and to assign a control number  
**Syntax Notes:**  
**Semantic Notes:** 1 The transaction set identifier (ST01) is used by the translation routines of the interchange partners to select the appropriate transaction set definition (e.g., 810 selects the Invoice Transaction Set).

**Comments:**

<b>PA Use:</b>	Required
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Required
<b>MD Use:</b>	Required
<b>Example:</b>	ST*867*000000001

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
Must Use	ST01	143	<b>Transaction Set Identifier Code</b> Code uniquely identifying a Transaction Set	<b>M ID 3/3</b>
			867 Product Transfer and Resale Report	
Must Use	ST02	329	<b>Transaction Set Control Number</b> Identifying control number that must be unique within the transaction set functional group assigned by the originator for a transaction set	<b>M AN 4/9</b>

**Segment:** **BPT** **Beginning Segment for Product Transfer and Resale**  
**Position:** 020  
**Loop:**  
**Level:** Heading  
**Usage:** Mandatory  
**Max Use:** 1  
**Purpose:** To indicate the beginning of the Product Transfer and Resale Report Transaction Set and transmit identifying data  
**Syntax Notes:** 1 If either BPT05 or BPT06 is present, then the other is required.  
**Semantic Notes:** 1 BPT02 identifies the transfer/resale number.  
 2 BPT03 identifies the transfer/resale date.  
 3 BPT08 identifies the transfer/resale time.  
 4 BPT09 is used when it is necessary to reference a Previous Report Number.

**Comments:**

<b>PA Use:</b>	Required
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Required
<b>MD Use:</b>	Required
<b>Examples:</b>	BPT*00*199902010001*19990131*DD BPT*00*199902010001*19990131*DD***F BPT*01*199902020001*19990131*DD*****1999020100001

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>BPT01</b>	<b>353</b>	<b>Transaction Set Purpose Code</b> Code identifying purpose of transaction set	<b>M ID 2/2</b>
			00 Original Conveys original readings for the account being reported.	
			01 Cancellation Indicates that the readings previously reported for the account are to be ignored.	
<b>Must Use</b>	<b>BPT02</b>	<b>127</b>	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier A unique transaction identification number assigned by the originator of this transaction. This number must be unique over time.  <b>PA:</b> This code will be used as a cross reference to the 810 billing document, and for billing parties that make the other party whole, it will also be cross referenced on the 820.	<b>O AN 1/30</b>
<b>Must Use</b>	<b>BPT03</b>	<b>373</b>	<b>Date</b> Date (CCYYMMDD) Transaction Creation Date – the date that the data is processed by the application system.	<b>M DT 8/8</b>
<b>Must Use</b>	<b>BPT04</b>	<b>755</b>	<b>Report Type Code</b> Code indicating the title or contents of a document, report or supporting item	<b>O ID 2/2</b>
			DD Monthly Usage For monthly metered customers only (not interval metered customers).	
			KJ Meter Changeout when Meter Agent Changes – Monthly Usage For monthly metered customers only (not interval metered customers)	

			X4	Summary Report (defined for PA and MD) For interval metered customers, when only summary data is being sent at the ACCOUNT level. <b>PA Note:</b> Some utilities may not be able to comply with this until later since this was added so close to the 4010 implementation date. If the utilities can not comply day 1, the utility will send the code of “DD” <b>MD Note:</b> Use of the “X4” code on the 867MU indicates the interval detail will be provided on the web.
			X5	Restricted Report For interval metered customers, when only summary data is being sent at the METER level. <b>PA Note:</b> Mandatory implementation date is June 2000.
Conditional	BPT07	306	<b>Action Code</b> Code indicating type of action	<b>O AN 1/2</b>
			F	Final – Indicates Final Usage for specific ESP. <b>Condition:</b> Code to indicate this is the final usage data being sent for this customer. Either the customer account is final with the LDC or the customer switched to a new ESP. <b>NJ PSE&amp;G:</b> PSE&G only sends “F” on a customer account final. They do not send an “F” on a customer switch.
Conditional	BPT09	127	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier	<b>O AN 1/30</b>
				<b>Condition:</b> When this is a cancellation of usage, that is BPT01 = 01, this element is required and should contain the transaction identification number from BPT02 of the transaction that is being cancelled.

**Segment:** **DTM** **Date/Time Reference (649=Document Due Date)**  
**Position:** 050  
**Loop:**  
**Level:** Heading  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>Notes:</b>	Required for Bill Ready Consolidated Billing where the meter reading party sends an 867 to the non-billing party, who calculates their own portion of the bill and sends the 810 to the billing party. Must be expressed in Eastern Prevailing Time. Not provided on cancel transaction.
<b>PA Use:</b>	Required for Bill Ready, not used in Rate Ready or Dual Billing  <b>Note:</b> For ESP Consolidated Billing, the document due date will be set according to the specific LDC bill ready implementation.
<b>NJ Use:</b>	Required for Bill Ready, not used in Rate Ready or Dual Billing
<b>DE Use:</b>	Required for Bill Ready, not used in Rate Ready or Dual Billing
<b>MD Use:</b>	Required for Bill Ready, not used in Rate Ready or Dual Billing
<b>Examples:</b>	DTM*649*19990131*2359

**Data Element Summary**

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>Attributes</b>
<b>Must Use</b>	<b>DTM01</b>	<b>374</b>	<b>Date/Time Qualifier</b> Code specifying type of date or time, or both date and time  649 Document Due  The date that the non-billing party must provide the 810 transaction back to the billing party.  If a file is received by the billing party after the date, and the billing party cannot process it, they must notify the non-billing party (via email, phone call, or any other means).	<b>M ID 3/3</b>
<b>Must Use</b>	<b>DTM02</b>	<b>373</b>	<b>Date</b> Date expressed as CCYYMMDD	<b>X DT 8/8</b>
<b>Must Use</b>	<b>DTM03</b>	<b>337</b>	<b>Time</b> Time expressed in 24-hour clock time as follows: HHMM, or HHMMSS, or HHMMSSD, or HHMMSSDD, where H = hours (00-23), M = minutes (00-59), S = integer seconds (00-59) and DD = decimal seconds; decimal seconds are expressed as follows: D = tenths (0-9) and DD = hundredths (00-99) HHMM format	<b>X TM 4/8</b>

**Segment:** **MEA** Measurements (NP=Percent Participation)  
**Position:** 075  
**Loop:**  
**Level:** Heading  
**Usage:** Optional  
**Max Use:** 20  
**Purpose:** To specify physical measurements or counts, including dimensions, tolerances, variances, and weights (See Figures Appendix for example of use of C001)  
**Syntax Notes:**  
 1 At least one of MEA03 MEA05 MEA06 or MEA08 is required.  
 2 If MEA05 is present, then MEA04 is required.  
 3 If MEA06 is present, then MEA04 is required.  
 4 If MEA07 is present, then at least one of MEA03 MEA05 or MEA06 is required.  
 5 Only one of MEA08 or MEA03 may be present.  
**Semantic Notes:**  
 1 MEA04 defines the unit of measure for MEA03, MEA05, and MEA06.  
**Comments:**  
 1 When citing dimensional tolerances, any measurement requiring a sign (+ or -), or any measurement where a positive (+) value cannot be assumed, use MEA05 as the negative (-) value and MEA06 as the positive (+) value.

<b>PA Use:</b>	Required if less than 100%
<b>NJ Use:</b>	Not used
<b>DE Use:</b>	Not used
<b>MD Use:</b>	Not Used
<b>Example:</b>	MEA**NP*.66667

### Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	MEA02	738	<b>Measurement Qualifier</b> Code identifying a specific product or process characteristic to which a measurement applies NP Percent Participation This code is used to indicate the percentage of the total load that is supplied by the ESP. This is the multiplication of two fields that are on the 814 transaction, AMT*7N (Participating Interest) and AMT*QY (Eligible Load).	<b>O ID 1/3</b>
Must Use	MEA03	739	<b>Measurement Value</b> The value of the measurement The whole number "1" represents 100 percent. Decimal numbers less than "1" represent percentages from 1 percent to 99 percent.	<b>X R 1/20</b>

**Segment:** **N1** Name (8S=LDC Name)  
**Position:** 080  
**Loop:** N1  
**Level:** Heading  
**Usage:** Optional  
**Max Use:** 1  
**Purpose:** To identify a party by type of organization, name, and code  
**Syntax Notes:** 1 At least one of N102 or N103 is required.  
 2 If either N103 or N104 is present, then the other is required.  
**Semantic Notes:**  
**Comments:** 1 This segment, used alone, provides the most efficient method of providing organizational identification. To obtain this efficiency the "ID Code" (N104) must provide a key to the table maintained by the transaction processing party.  
 2 N105 and N106 further define the type of entity in N101.

<b>PA Use:</b>	Required
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Required
<b>MD Use:</b>	Required
<b>Example:</b>	N1*8S*LDC COMPANY*1*007909411

## Data Element Summary

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>Attributes</b>
<b>Must Use</b>	<b>N101</b>	<b>98</b>	<b>Entity Identifier Code</b> Code identifying an organizational entity, a physical location, property or an individual 8S Consumer Service Provider (CSP) LDC	<b>M ID 2/3</b>
<b>Must Use</b>	<b>N102</b>	<b>93</b>	<b>Name</b> Free-form name LDC Company Name	<b>X AN 1/60</b>
<b>Must Use</b>	<b>N103</b>	<b>66</b>	<b>Identification Code Qualifier</b> Code designating the system/method of code structure used for Identification Code (67) 1 D-U-N-S Number, Dun & Bradstreet 9 D-U-N-S+4, D-U-N-S Number with Four Character Suffix	<b>X ID 1/2</b>
<b>Must Use</b>	<b>N104</b>	<b>67</b>	<b>Identification Code</b> Code identifying a party or other code LDC D-U-N-S Number or D-U-N-S + 4 Number	<b>X AN 2/20</b>

**Segment:** **N1** Name (SJ=ESP Name)  
**Position:** 080  
**Loop:** N1  
**Level:** Heading  
**Usage:** Optional  
**Max Use:** 1  
**Purpose:** To identify a party by type of organization, name, and code  
**Syntax Notes:** 1 At least one of N102 or N103 is required.  
 2 If either N103 or N104 is present, then the other is required.  
**Semantic Notes:**  
**Comments:** 1 This segment, used alone, provides the most efficient method of providing organizational identification. To obtain this efficiency the "ID Code" (N104) must provide a key to the table maintained by the transaction processing party.  
 2 N105 and N106 further define the type of entity in N101.

<b>PA Use:</b>	Required
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Required
<b>MD Use:</b>	Required
<b>Example:</b>	N1*SJ*ESP COMPANY*9*007909422ESP

## Data Element Summary

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
<b>Must Use</b>	<b>Des.</b>	<b>Element</b>		
	<b>N101</b>	<b>98</b>	<b>Entity Identifier Code</b>	<b>M ID 2/3</b>
			Code identifying an organizational entity, a physical location, property or an individual	
			SJ Service Provider	
			ESP	
<b>Must Use</b>	<b>N102</b>	<b>93</b>	<b>Name</b>	<b>X AN 1/60</b>
			Free-form name	
			ESP Company Name	
<b>Must Use</b>	<b>N103</b>	<b>66</b>	<b>Identification Code Qualifier</b>	<b>X ID 1/2</b>
			Code designating the system/method of code structure used for Identification Code (67)	
			1 D-U-N-S Number, Dun & Bradstreet	
			9 D-U-N-S+4, D-U-N-S Number with Four Character Suffix	
<b>Must Use</b>	<b>N104</b>	<b>67</b>	<b>Identification Code</b>	<b>X AN 2/20</b>
			Code identifying a party or other code	
			ESP D-U-N-S Number or D-U-N-S + 4 Number	

**Segment:** **N1** Name (G7=Renewable Energy Provider Name)  
**Position:** 080  
**Loop:** N1  
**Level:** Heading  
**Usage:** Optional  
**Max Use:** 1  
**Purpose:** To identify a party by type of organization, name, and code  
**Syntax Notes:** 1 At least one of N102 or N103 is required.  
 2 If either N103 or N104 is present, then the other is required.  
**Semantic Notes:**  
**Comments:** 1 This segment, used alone, provides the most efficient method of providing organizational identification. To obtain this efficiency the "ID Code" (N104) must provide a key to the table maintained by the transaction processing party.  
 2 N105 and N106 further define the type of entity in N101.

<b>PA Use:</b>	Not used
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Not used
<b>MD Use:</b>	Not used
<b>Example:</b>	N1*G7*RENEWABLE COMPANY*9*007909422GPM

## Data Element Summary

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>N101</b>	<b>98</b>	<b>Entity Identifier Code</b> Code identifying an organizational entity, a physical location, property or an individual G7 Entity Providing the Service Renewable Energy Provider	<b>M ID 2/3</b>
<b>Must Use</b>	<b>N102</b>	<b>93</b>	<b>Name</b> Free-form name Renewable Energy Provider Company Name	<b>X AN 1/60</b>
<b>Must Use</b>	<b>N103</b>	<b>66</b>	<b>Identification Code Qualifier</b> Code designating the system/method of code structure used for Identification Code (67) 1 D-U-N-S Number, Dun & Bradstreet 9 D-U-N-S+4, D-U-N-S Number with Four Character Suffix	<b>X ID 1/2</b>
<b>Must Use</b>	<b>N104</b>	<b>67</b>	<b>Identification Code</b> Code identifying a party or other code Renewable Energy Provider D-U-N-S Number or D-U-N-S + 4 Number	<b>X AN 2/20</b>

**Segment:** **N1** Name (8R=Customer Name)  
**Position:** 080  
**Loop:** N1  
**Level:** Heading  
**Usage:** Optional  
**Max Use:** 1  
**Purpose:** To identify a party by type of organization, name, and code  
**Syntax Notes:** 1 At least one of N102 or N103 is required.  
 2 If either N103 or N104 is present, then the other is required.  
**Semantic Notes:**  
**Comments:** 1 This segment, used alone, provides the most efficient method of providing organizational identification. To obtain this efficiency the "ID Code" (N104) must provide a key to the table maintained by the transaction processing party.  
 2 N105 and N106 further define the type of entity in N101.

<b>Notes:</b>	Please note that while you may place your N1 segments in any order, the REF segments that follow must be contained within the N1*8R loop.
<b>PA Use:</b>	Required
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Required
<b>MD Use:</b>	Required
<b>Example:</b>	N1*8R*CUSTOMER NAME

## Data Element Summary

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>Attributes</b>
<b>Must Use</b>	<b>N101</b>	<b>98</b>	<b>Entity Identifier Code</b> Code identifying an organizational entity, a physical location, property or an individual 8R Consumer Service Provider (CSP) Customer End Use Customer	<b>M ID 2/3</b>
<b>Must Use</b>	<b>N102</b>	<b>93</b>	<b>Name</b> Free-form name Customer Name	<b>X AN 1/60</b>

**Segment:** **REF** **Reference Identification (12=LDC Account Number)**  
**Position:** 120  
**Loop:** N1  
**Level:** Heading  
**Usage:** Optional  
**Max Use:** 12  
**Purpose:** To specify identifying information  
**Syntax Notes:**

- 1 At least one of REF02 or REF03 is required.
- 2 If either C04003 or C04004 is present, then the other is required.
- 3 If either C04005 or C04006 is present, then the other is required.

**Semantic Notes:**

- 1 REF04 contains data relating to the value cited in REF02.

**Comments:**

<b>PA Use:</b>	Required
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Required
<b>MD Use:</b>	Required
<b>Example:</b>	REF*12*1239485790

### Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	REF01	128	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification 12 Billing Account LDC-assigned account number for the end use customer. Must appear as it does on the customer's bill excluding punctuation (spaces, dashes, etc.) Significant leading and trailing zeros must be included.	<b>M ID 2/3</b>
Must Use	REF02	127	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier	<b>X AN 1/30</b>

**Segment:** **REF** Reference Identification (45=LDC Old Account Number)  
**Position:** 120  
**Loop:** N1  
**Level:** Heading  
**Usage:** Optional  
**Max Use:** 12  
**Purpose:** To specify identifying information  
**Syntax Notes:**

- 1 At least one of REF02 or REF03 is required.
- 2 If either C04003 or C04004 is present, then the other is required.
- 3 If either C04005 or C04006 is present, then the other is required.

**Semantic Notes:**

- 1 REF04 contains data relating to the value cited in REF02.

**Comments:**

<b>PA Use:</b>	Required if account number has changed within the last 60 days.
<b>NJ Use:</b>	Required if account number has changed within the last 60 days.
<b>DE Use:</b>	Not used
<b>MD Use:</b>	Not Used by BGE, PEPCO and Delmarva. PE: Required if the account number has changed in the last 60 days.
<b>Example:</b>	REF*45*939581900

### Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	REF01	128	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification 45 Old Account Number Previous LDC-assigned account number for the end use customer.	<b>M ID 2/3</b>
Must Use	REF02	127	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier	<b>X AN 1/30</b>

**Segment:** **REF** **Reference Identification (11=ESP Account Number)**  
**Position:** 120  
**Loop:** N1  
**Level:** Heading  
**Usage:** Optional  
**Max Use:** 12  
**Purpose:** To specify identifying information  
**Syntax Notes:**

- 1 At least one of REF02 or REF03 is required.
- 2 If either C04003 or C04004 is present, then the other is required.
- 3 If either C04005 or C04006 is present, then the other is required.

**Semantic Notes:**

- 1 REF04 contains data relating to the value cited in REF02.

**Comments:**

<b>PA Use:</b>	Required if it was previously provided to the LDC.
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	REF*11*1394959

#### Data Element Summary

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>Attributes</b>
Must Use	<b>REF01</b>	<b>128</b>	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification 11 Account Number ESP-assigned account number for the end use customer.	<b>M ID 2/3</b>
Must Use	<b>REF02</b>	<b>127</b>	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier	<b>X AN 1/30</b>

**Segment:** **REF** Reference Identification (BLT=Billing Type)  
**Position:** 120  
**Loop:** N1  
**Level:** Heading  
**Usage:** Optional  
**Max Use:** 12  
**Purpose:** To specify identifying information  
**Syntax Notes:**

- 1 At least one of REF02 or REF03 is required.
- 2 If either C04003 or C04004 is present, then the other is required.
- 3 If either C04005 or C04006 is present, then the other is required.

**Semantic Notes:**

- 1 REF04 contains data relating to the value cited in REF02.

**Comments:**

<b>PA Use:</b>	Required
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Required
<b>MD Use:</b>	Required
<b>Example:</b>	REF*BLT*LDC

#### Data Element Summary

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>X12 Attributes</b>
Must Use	<b>REF01</b>	<b>128</b>	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification BLT Billing Type Identifies whether the bill is consolidated by the LDC or ESP, or whether each party will render their own bill. See REF02 for valid values.	<b>M ID 2/3</b>
Must Use	<b>REF02</b>	<b>127</b>	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier  When REF01 is BLT, valid values for REF02 are: LDC - The LDC bills the customer ESP - The ESP bills the customer DUAL - Each party bills the customer for their portion  <b>Note:</b> In New Jersey, only LDC and DUAL are valid.	<b>X AN 1/30</b>

**Segment:** **REF** Reference Identification (PC=Bill Calculator)  
**Position:** 120  
**Loop:** N1  
**Level:** Heading  
**Usage:** Optional  
**Max Use:** 12  
**Purpose:** To specify identifying information  
**Syntax Notes:**

- 1 At least one of REF02 or REF03 is required.
- 2 If either C04003 or C04004 is present, then the other is required.
- 3 If either C04005 or C04006 is present, then the other is required.

**Semantic Notes:**

- 1 REF04 contains data relating to the value cited in REF02.

**Comments:**

<b>PA Use:</b>	Required
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Required
<b>MD Use:</b>	Required
<b>Example:</b>	REF*PC*LDC

## Data Element Summary

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>X12 Attributes</b>
Must Use	<b>REF01</b>	<b>128</b>	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification PC Production Code Identifies the party that is to calculate the charges on the bill.	<b>M ID 2/3</b>
Must Use	<b>REF02</b>	<b>127</b>	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier When REF01 is PC, valid values for REF02 are: LDC - The LDC calculates the charges on the bill (Rate Ready) DUAL - Each party calculates its portion of the bill (Dual or Bill Ready)	<b>X AN 1/30</b>

IF ...			THEN...	
Bills the Customer	Calculates		Billing Party	Calc. Party
	LDC Portion	ESP Portion	REF*BLT	REF*PC
LDC	LDC	LDC	LDC	LDC
LDC	LDC	ESP	LDC	DUAL
ESP	LDC	ESP	ESP	DUAL
DUAL	LDC	ESP	DUAL	DUAL

Be careful to use the UIG Standard Code Values LDC and ESP rather than the Pennsylvania versions of those codes.

**Segment:** **PTD** Product Transfer and Resale Detail (BB=Billed Summary)  
**Position:** 010  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Mandatory  
**Max Use:** 1  
**Purpose:** To indicate the start of detail information relating to the transfer/resale of a product and provide identifying data

**Syntax Notes:** 1 If either PTD02 or PTD03 is present, then the other is required.  
 2 If either PTD04 or PTD05 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>Notes:</b>	PTD Loops may be sent in any order.
<b>PA Use:</b>	One Monthly Billed Summary PTD loop is required for every account.
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Required
<b>MD Use:</b>	Required
<b>Example:</b>	PTD*BB

**Data Element Summary**

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	PTD01	521	<b>Product Transfer Type Code</b> Code identifying the type of product transfer	M ID 2/2
			BB Monthly Billed Summary	
			This information is obtained from the billing system to reflect the billing data for this account at the unit of measure level.	

**Note:**

Refer to the “PTD Loops Definition” section earlier in this document for an explanation of this specific PTD Loop.

**Segment:** **DTM** **Date/Time Reference (150=Service Period Start)**  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>PA Use:</b>	Required
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Required
<b>MD Use:</b>	Required
<b>Example:</b>	DTM*150*19990101

**Data Element Summary**

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>Attributes</b>
<b>Must Use</b>	<b>DTM01</b>	<b>374</b>	<b>Date/Time Qualifier</b> Code specifying type of date or time, or both date and time 150 Service Period Start	<b>M ID 3/3</b>
<b>Must Use</b>	<b>DTM02</b>	<b>373</b>	<b>Date</b> Date expressed as CCYYMMDD	<b>X DT 8/8</b>

**Segment:** **DTM** **Date/Time Reference (151=Service Period End)**  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>PA Use:</b>	Required
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Required
<b>MD Use:</b>	Required
<b>Example:</b>	DTM*151*19990131

**Data Element Summary**

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>Attributes</b>
<b>Must Use</b>	<b>DTM01</b>	<b>374</b>	<b>Date/Time Qualifier</b> Code specifying type of date or time, or both date and time 151 Service Period End	<b>M ID 3/3</b>
<b>Must Use</b>	<b>DTM02</b>	<b>373</b>	<b>Date</b> Date expressed as CCYYMMDD	<b>X DT 8/8</b>

**Segment:** **QTY** Quantity (Billed kwh)  
**Position:** 110  
**Loop:** QTY  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 1  
**Purpose:** To specify quantity information  
**Syntax Notes:** 1 At least one of QTY02 or QTY04 is required.  
 2 Only one of QTY02 or QTY04 may be present.  
**Semantic Notes:** 1 QTY04 is used when the quantity is non-numeric.  
**Comments:**

<b>Notes:</b>	Billed KWH
<b>PA Use:</b>	Required
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Required
<b>MD Use:</b>	Required
<b>Example:</b>	QTY*D1*22348*KH

## Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	QTY01	673	<b>Quantity Qualifier</b> Code specifying the type of quantity D1 Billed Used when Quantity in QTY02 is a “Billed” quantity.	M ID 2/2
Must Use	QTY02	380	<b>Quantity</b> Numeric value of quantity	X R 1/15
Must Use	QTY03	355	<b>Unit or Basis for Measurement Code</b> Code specifying the units in which a value is being expressed, or manner in which a measurement has been taken KH Kilowatt Hour Billed Kilowatt Hours as shown on the customer’s bill. May or may not be the same as measured kilowatt hours.	M ID 2/2

**Segment:** QTY Quantity (Billed Demand)  
**Position:** 110  
**Loop:** QTY  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 1  
**Purpose:** To specify quantity information  
**Syntax Notes:** 1 At least one of QTY02 or QTY04 is required.  
 2 Only one of QTY02 or QTY04 may be present.  
**Semantic Notes:** 1 QTY04 is used when the quantity is non-numeric.  
**Comments:**

<b>Notes:</b>	Billed Demand
<b>PA Use:</b>	Required if account measures Demand (KW). This must be sent even if Billed (derived) demand is equal to measured demand.
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	QTY*D1*14*K1

## Data Element Summary

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
Must Use	QTY01	673	<b>Quantity Qualifier</b> Code specifying the type of quantity	<b>M ID 2/2</b>
			D1 Billed	
			Used when Quantity in QTY02 is a "Billed" quantity.	
Must Use	QTY02	380	<b>Quantity</b> Numeric value of quantity	<b>X R 1/15</b>
Must Use	QTY03	355	<b>Unit or Basis for Measurement Code</b> Code specifying the units in which a value is being expressed, or manner in which a measurement has been taken	<b>M ID 2/2</b>
			K1 Kilowatt Demand	

**Segment:** QTY Quantity (Measured Demand)  
**Position:** 110  
**Loop:** QTY  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 1  
**Purpose:** To specify quantity information  
**Syntax Notes:** 1 At least one of QTY02 or QTY04 is required.  
 2 Only one of QTY02 or QTY04 may be present.  
**Semantic Notes:** 1 QTY04 is used when the quantity is non-numeric.  
**Comments:**

<b>Notes:</b>	Measured Demand
<b>PA Use:</b>	Required if account measures Demand (KW)
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA <b>Note:</b> BGE does not store Measured Demand. They will send Billed Demand in this field.
<b>Example:</b>	QTY*QD*14*K1

## Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	QTY01	673	<b>Quantity Qualifier</b> Code specifying the type of quantity	<b>M ID 2/2</b>
			KA Estimated Quantity Delivered Used when the quantity delivered is an estimated quantity.	
			QD Actual Quantity Delivered Used when the quantity delivered is an actual quantity.	
Must Use	QTY02	380	<b>Quantity</b> Numeric value of quantity	<b>X R 1/15</b>
Must Use	QTY03	355	<b>Unit or Basis for Measurement Code</b> Code specifying the units in which a value is being expressed, or manner in which a measurement has been taken	<b>M ID 2/2</b>
			K1 Kilowatt Demand	

**Segment:** **PTD** Product Transfer and Resale Detail (SU=Metered Services Summary)  
**Position:** 010  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Mandatory  
**Max Use:** 1  
**Purpose:** To indicate the start of detail information relating to the transfer/resale of a product and provide identifying data

**Syntax Notes:** 1 If either PTD02 or PTD03 is present, then the other is required.  
 2 If either PTD04 or PTD05 is present, then the other is required.

**Semantic Notes:**

**Comments:**

<b>Notes:</b>	PTD Loops may be sent in any order.
<b>PA Use:</b>	Required if this is a metered account that measures kWh or KVARH and the LDC reads the meter.
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	PTD*SU

#### Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	PTD01	521	<b>Product Transfer Type Code</b> Code identifying the type of product transfer SU Summary	<b>M ID 2/2</b> A summary loop will be provided for each type of consumption for every unit of measure for all meters in the account.

#### Note:

Refer to the “PTD Loops Definition” section earlier in this document for an explanation of this specific PTD Loop.

**Segment:** **DTM** **Date/Time Reference (150=Service Period Start)**  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>PA Use:</b>	Required if account has metered services.
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	DTM*150*19990101

**Data Element Summary**

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>Attributes</b>
<b>Must Use</b>	<b>DTM01</b>	<b>374</b>	<b>Date/Time Qualifier</b> Code specifying type of date or time, or both date and time 150 Service Period Start	<b>M ID 3/3</b>
<b>Must Use</b>	<b>DTM02</b>	<b>373</b>	<b>Date</b> Date expressed as CCYYMMDD	<b>X DT 8/8</b>

**Segment:** **DTM** **Date/Time Reference (151=Service Period End)**  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>PA Use:</b>	Required if account has metered services.
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	DTM*151*19990131

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
Must Use	DTM01	374	<b>Date/Time Qualifier</b> Code specifying type of date or time, or both date and time 151 Service Period End	<b>M ID 3/3</b>
Must Use	DTM02	373	<b>Date</b> Date expressed as CCYYMMDD	<b>X DT 8/8</b>

**Segment:** QTY Quantity  
**Position:** 110  
**Loop:** QTY  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 1  
**Purpose:** To specify quantity information  
**Syntax Notes:** 1 At least one of QTY02 or QTY04 is required.  
 2 Only one of QTY02 or QTY04 may be present.  
**Semantic Notes:** 1 QTY04 is used when the quantity is non-numeric.  
**Comments:**

<b>Notes:</b>	There will be one QTY loop for each of the QTY03 Units of Measurement listed below that are measured on this account.
<b>PA Use:</b>	Required if account has metered services
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	QTY*QD*22348*KH

## Data Element Summary

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
Must Use	QTY01	673	<b>Quantity Qualifier</b> Code specifying the type of quantity	M ID 2/2
			KA Estimated Quantity Delivered Used when the quantity delivered is an estimated quantity.	
			QD Actual Quantity Delivered Used when the quantity delivered is an actual quantity.	
			87 Actual Quantity Received (Net Metering) Used when the net generation quantity received is actual.	
			9H Estimated Quantity Received (Net Metering) Used when the net generation quantity received is estimated.	
Must Use	QTY02	380	<b>Quantity</b> Numeric value of quantity	X R 1/15
Must Use	QTY03	355	<b>Unit or Basis for Measurement Code</b> Code specifying the units in which a value is being expressed, or manner in which a measurement has been taken	M ID 2/2
			K3 Kilovolt Amperes Reactive Hour (kVARH) Represents actual electricity equivalent to kilowatt hours; billable when usage meets or exceeds defined parameters	
			KH Kilowatt Hour	

**Segment:** **PTD** Product Transfer and Resale Detail (PM=Metered Services Detail)  
**Position:** 010  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Mandatory  
**Max Use:** 1  
**Purpose:** To indicate the start of detail information relating to the transfer/resale of a product and provide identifying data  
**Syntax Notes:** 1 If either PTD02 or PTD03 is present, then the other is required.  
 2 If either PTD04 or PTD05 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>Notes:</b>	PTD Loops may be sent in any order.  There will be a separate PTD loop for each unit of measurement for each meter on the account.  <b>Note:</b> If the BPT04="X4" indicating this document is being sent for an interval account at the account level, this loop may be sent for each unit of measure, but not each meter. When the BPT04="X4", the data may be summarized for the account.
<b>PA Use:</b>	Required if this is a metered account.  <b>Note:</b> The sending of the PM loop s is optional when this is a cancel transaction (BPT01=01).
<b>NJ Use:</b>	Required if this is a metered account.
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	PTD*PM

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
Must Use	PTD01	521	Product Transfer Type Code	M ID 2/2
			Code identifying the type of product transfer	
			PM	Physical Meter Information

**Note:**

Refer to the "PTD Loops Definition" section earlier in this document for an explanation of this specific PTD Loop.

**Segment:** **DTM** **Date/Time Reference (150=Service Period Start)**  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>Notes:</b>	This date reflects the beginning of the date range for this meter for this billing period.
	This specific PTD loop is required if there are metered services on the account.
<b>PA Use:</b>	Required, unless a “DTM*514” is substituted for this code.
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	DTM*150*19990101

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>DTM01</b>	<b>374</b>	<b>Date/Time Qualifier</b>	<b>M ID 3/3</b>
			Code specifying type of date or time, or both date and time	
			150 Service Period Start	
<b>Must Use</b>	<b>DTM02</b>	<b>373</b>	<b>Date</b>	<b>X DT 8/8</b>
			Date expressed as CCYYMMDD	

**Segment:** **DTM** **Date/Time Reference (151=Service Period End)**  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>Notes:</b>	This date reflects the end of the date range for this meter for this billing period.
	This specific PTD loop is required if there are metered services on the account.
<b>PA Use:</b>	Required, unless a “DTM*514” is substituted for this code.
<b>NJ Use:</b>	Same as PA.
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	DTM*151*19990131

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>DTM01</b>	<b>374</b>	<b>Date/Time Qualifier</b>	<b>M ID 3/3</b>
			Code specifying type of date or time, or both date and time	
			151 Service Period End	
<b>Must Use</b>	<b>DTM02</b>	<b>373</b>	<b>Date</b>	<b>X DT 8/8</b>
			Date expressed as CCYYMMDD	

**Segment:** **DTM** Date/Time Reference (514=Meter Exchange Date)  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>Notes:</b>	Used in conjunction with either the Service Period Start Date or the Service Period End Date to indicate when a meter has been replaced. Separate PTD loops must be created for each period and meter.
<b>PA Use:</b>	Required when a meter is changed and the meter agent does not change.
<b>NJ Use:</b>	Same as PA.
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	<p>Date Range in the first PTD is shown as:  DTM*150*19990201  DTM*514*19990214</p> <p>Date Range in the second PTD is shown as:  DTM*514*19990214  DTM*151*19990228</p>

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>DTM01</b>	<b>374</b>	<b>Date/Time Qualifier</b>	<b>M ID 3/3</b>
			Code specifying type of date or time, or both date and time	
			514 Transferred	
			Exchanged meter read date	
<b>Must Use</b>	<b>DTM02</b>	<b>373</b>	<b>Date</b>	<b>X DT 8/8</b>
			Date expressed as CCYYMMDD	

**Segment:** **REF** Reference Identification (6W=Channel Number)  
**Position:** 030  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 20  
**Purpose:** To specify identifying information  
**Syntax Notes:**

- 1 At least one of REF02 or REF03 is required.
- 2 If either C04003 or C04004 is present, then the other is required.
- 3 If either C04005 or C04006 is present, then the other is required.

**Semantic Notes:**

- 1 REF04 contains data relating to the value cited in REF02.

**Comments:**

<b>PA Use:</b>	Used by FirstEnergy: Channel 1 = Delivered kWh and Channel 2 = Received kWh
<b>NJ Use:</b>	Used by JCP&L: Channel 1 = Delivered kWh and Channel 2 = Received kWh
<b>DE Use:</b>	N/A
<b>MD Use:</b>	N/A
<b>Example:</b>	REF*6W*1

## Data Element Summary

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>Attributes</b>
<b>Must Use</b>	<b>REF01</b>	<b>128</b>	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification 6W Sequence Number Channel Number	<b>M ID 2/3</b>
<b>Must Use</b>	<b>REF02</b>	<b>127</b>	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier Channel Number	<b>X AN 1/30</b>

**Segment:** **REF** **Reference Identification (MG=Meter Number)**  
**Position:** 030  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 20  
**Purpose:** To specify identifying information  
**Syntax Notes:** 1 At least one of REF02 or REF03 is required.  
 2 If either C04003 or C04004 is present, then the other is required.  
 3 If either C04005 or C04006 is present, then the other is required.  
**Semantic Notes:** 1 REF04 contains data relating to the value cited in REF02.  
**Comments:**

<b>PA Use:</b>	Required if this is a metered account and the meter is on the account at the end of the period. For some utilities, they may not be able to provide the actual meter number for a meter that has been changed out during the month. In that case, the REF*MG will not be sent. Everyone is working toward being able to provide the old meter number. <b>Note:</b> If the BPT04="X4" indicating this document is being sent for an interval account at the account level, this segment will be not be used.
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	REF*MG*2222277S

#### Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	REF01	128	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification MG Meter Number	M ID 2/3
Must Use	REF02	127	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier	X AN 1/30

**Segment:** **REF** **Reference Identification (NH=LDC Rate Class)**  
**Position:** 030  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 20  
**Purpose:** To specify identifying information  
**Syntax Notes:**

- 1 At least one of REF02 or REF03 is required.
- 2 If either C04003 or C04004 is present, then the other is required.
- 3 If either C04005 or C04006 is present, then the other is required.

**Semantic Notes:**

- 1 REF04 contains data relating to the value cited in REF02.

**Comments:**

<b>PA Use:</b>	Optional
<b>NJ Use:</b>	Optional
<b>DE Use:</b>	Optional
<b>MD Use:</b>	Optional
<b>Example:</b>	REF*NH*GS1

#### Data Element Summary

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>Attributes</b>
<b>Must Use</b>	<b>REF01</b>	<b>128</b>	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification NH LDC Rate Code	<b>M ID 2/3</b>
<b>Must Use</b>	<b>REF02</b>	<b>127</b>	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier	<b>X AN 1/30</b>

**Segment:** **REF** Reference Identification (PR=LDC Rate Subclass)  
**Position:** 030  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 20  
**Purpose:** To specify identifying information  
**Syntax Notes:**

- 1 At least one of REF02 or REF03 is required.
- 2 If either C04003 or C04004 is present, then the other is required.
- 3 If either C04005 or C04006 is present, then the other is required.

**Semantic Notes:**

- 1 REF04 contains data relating to the value cited in REF02.

**Comments:**

<b>Notes:</b>	This iteration of the REF segment is used for meter level information.
<b>PA Use:</b>	Conditional: If maintained by utility, must be sent for each meter loop that is used for billing purposes. <b>Note:</b> If the BPT04="X4" indicating this document is being sent for an interval account at the account level, this segment will be not be used.
<b>NJ Use:</b>	Optional
<b>DE Use:</b>	Optional
<b>MD Use:</b>	Optional
<b>Example:</b>	REF*PR*123

## Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>X12 Attributes</u>
Must Use	REF01	128	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification PR Price Quote Number LDC Rate Subclass – Used to provide further classification of a rate.	M ID 2/3
Must Use	REF02	127	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier	X AN 1/30

**Segment:** **REF** **Reference Identification (JH=Meter Role)**  
**Position:** 030  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 20  
**Purpose:** To specify identifying information  
**Syntax Notes:**

- 1 At least one of REF02 or REF03 is required.
- 2 If either C04003 or C04004 is present, then the other is required.
- 3 If either C04005 or C04006 is present, then the other is required.

**Semantic Notes:**

- 1 REF04 contains data relating to the value cited in REF02.

**Comments:**

<b>PA Use:</b>	Required if consumption is provided at a meter level <b>Note:</b> If the BPT04="X4" indicating this document is being sent for an interval account at the account level, this segment will be not be used.
<b>NJ Use:</b>	Required if consumption is provided at a meter level
<b>DE Use:</b>	Required if consumption is provided at a meter level
<b>MD Use:</b>	Required if consumption is provided at a meter level
<b>Example:</b>	REF*JH*A

#### Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	REF01	128	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification JH Meter Role	<b>M ID 2/3</b>
Must Use	REF02	127	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier When REF01 is JH, valid values for REF02 are: S = Subtractive - this consumption needs to be subtracted from the summarized total. A = Additive - this consumption contributed to the summarized total (do nothing). I = Ignore - this consumption did not contribute to the summarized total (do nothing).	<b>X AN 1/30</b>

**Segment:** **REF** **Reference Identification (IX=Number of Dials/Digits)**  
**Position:** 030  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 20  
**Purpose:** To specify identifying information  
**Syntax Notes:** 1 At least one of REF02 or REF03 is required.  
 2 If either C04003 or C04004 is present, then the other is required.  
 3 If either C04005 or C04006 is present, then the other is required.  
**Semantic Notes:** 1 REF04 contains data relating to the value cited in REF02.  
**Comments:**

<b>PA Use:</b>	Required for meters with dials <b>Note:</b> If the BPT04="X4" indicating this document is being sent for an interval account at the account level, this segment will be not be used.
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Examples:</b>	REF*IX*6.0 REF*IX*5.1 REF*IX*4.2

#### Data Element Summary

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>X12 Attributes</b>
<b>Must Use</b>	<b>REF01</b>	<b>128</b>	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification IX Rate Card Number Number of Dials on the Meter displayed as the number of dials to the left of the decimal, a decimal point, and the number of dials to the right of the decimal.	<b>M ID 2/3</b>
<b>Must Use</b>	<b>REF02</b>	<b>127</b>	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier	<b>X AN 1/30</b>
<b>Optional</b>	<b>REF03</b>	<b>352</b>	<b>Description</b> A free-form description to clarify the related data elements and their content Optional use: See Meter Type (REF*MT) on 814 Enrollment for valid codes.	<b>X AN 1/80</b>

# Dials	Positions to left of decimal	Positions to right of decimal	X12 Example
6	6	0	REF*IX*6.0
6	5	1	REF*IX*5.1
6	4	2	REF*IX*4.2

**Segment:** QTY Quantity  
**Position:** 110  
**Loop:** QTY  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 1  
**Purpose:** To specify quantity information  
**Syntax Notes:** 1 At least one of QTY02 or QTY04 is required.  
 2 Only one of QTY02 or QTY04 may be present.  
**Semantic Notes:** 1 QTY04 is used when the quantity is non-numeric.  
**Comments:**

<b>Notes:</b>	<p>There will be one QTY loop for <b>each</b> of the QTY03 Units of Measurement listed below for each meter that is measured on this account.</p> <p>If there are 2 meters on the account, and one measures KWH and KW, and the other measures just KWH, there will be 3 PTD01=PM loops.</p> <p>If a meter measures total usage, as well as on-peak and off-peak, there will be three QTY loops sent within one PTD01=PM loop. The MEA segment that follows each QTY will specify which time of use the QTY applies to.</p>
<b>PA Use:</b>	Required if there are metered services on the account.
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	QTY*QD*22348*KH QTY*QD*14*K1 (If meter measures both, you will have two QTY loops)

## Data Element Summary

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
Must Use	QTY01	673	<b>Quantity Qualifier</b> Code specifying the type of quantity	M ID 2/2
			KA Estimated Quantity Delivered Used when the quantity delivered is an estimated quantity.	
			QD Actual Quantity Delivered Used when the quantity delivered is an actual quantity.	
			87 Actual Quantity Received (Net Metering) Used when the net generation quantity received is actual.	
			9H Estimated Quantity Received (Net Metering) Used when the net generation quantity received is estimated.	
Must Use	QTY02	380	<b>Quantity</b> Numeric value of quantity	X R 1/15
Must Use	QTY03	355	<b>Unit or Basis for Measurement Code</b> Code specifying the units in which a value is being expressed, or manner in which a measurement has been taken	M ID 2/2
			K1 Kilowatt Demand (kW) Represents potential power load measured at predetermined intervals	
			K2 Kilovolt Amperes Reactive Demand (kVAR) Reactive power that must be supplied for specific types of customer's equipment; billable when kilowatt demand usage meets or exceeds a defined parameter	

K3	Kilovolt Amperes Reactive Hour (kVARH) Represents actual electricity equivalent to kilowatt hours; billable when usage meets or exceeds defined parameters
K4	Kilovolt Amperes (KVA)
KH	Kilowatt Hour (kWh)

**Segment: MEA Measurements****Position:** 160**Loop:** QTY**Level:** Detail**Usage:** Optional**Max Use:** 40**Purpose:** To specify physical measurements or counts, including dimensions, tolerances, variances, and weights (See Figures Appendix for example of use of C001)**Syntax Notes:** 1 At least one of MEA03 MEA05 MEA06 or MEA08 is required.

2 If MEA05 is present, then MEA04 is required.

3 If MEA06 is present, then MEA04 is required.

4 If MEA07 is present, then at least one of MEA03 MEA05 or MEA06 is required.

5 Only one of MEA08 or MEA03 may be present.

**Semantic Notes:** 1 MEA04 defines the unit of measure for MEA03, MEA05, and MEA06.**Comments:** 1 When citing dimensional tolerances, any measurement requiring a sign (+ or -), or any measurement where a positive (+) value cannot be assumed, use MEA05 as the negative (-) value and MEA06 as the positive (+) value.

<b>Notes:</b>	The MEA segment is sent for each QTY loop. The MEA will indicate the “time of use” that applies to the QTY. If meter readings are included in the MEA, they will indicate the “time of use” that the meter readings apply to.
<b>PA Use:</b>	Required (optional on a cancellation)
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Examples:</b>	MEA*AA*PRQ*22348*KH***51 MEA*AA*PRQ*14*K1***51 (If meter measures multiple things, you need to send multiple QTY loops, one for each unit of measurement).

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>MEA01</b>	<b>737</b>	<b>Measurement Reference ID Code</b>	<b>O ID 2/2</b>
			Code identifying the broad category to which a measurement applies	
			AA Meter reading-beginning actual/ending actual	
			AE Meter reading-beginning actual/ending estimated	
			AF Actual Total	
			BO Meter Reading as Billed	
			Used when billing charges are based on contractual agreements or pre-established usage and not on actual usage	
			EA Meter reading-beginning estimated/ending actual	
			EE Meter reading-beginning estimated/ending estimated	
<b>Must Use</b>	<b>MEA02</b>	<b>738</b>	<b>Measurement Qualifier</b>	<b>O ID 1/3</b>
			Code identifying a specific product or process characteristic to which a measurement applies	
			PRQ Consumption	
<b>Must Use</b>	<b>MEA03</b>	<b>739</b>	<b>Measurement Value</b>	<b>X R 1/20</b>
			The value of the measurement	
			Represents quantity of consumption delivered for service period. Contains the difference in the meter readings (or as measured by the meter) multiplied by various factors, excluding Power Factor.	

<b>Must Use</b>	<b>MEA04</b>	<b>355</b>	<b>Unit or Basis for Measurement Code</b> <b>M ID 2/2</b> Code specifying the units in which a value is being expressed, or manner in which a measurement has been taken
			K1 Kilowatt Demand Represents potential power load measured at predetermined intervals
			K2 Kilovolt Amperes Reactive Demand Reactive power that must be supplied for specific types of customer's equipment; billable when kilowatt demand usage meets or exceeds a defined parameter
			K3 Kilovolt Amperes Reactive Hour Represents actual electricity equivalent to kilowatt hours; billable when usage meets or exceeds defined parameters
			K4 Kilovolt Amperes (KVA)
			K5 Kilovolt Amperes Reactive
			KH Kilowatt Hour
<b>Conditional</b>	<b>MEA05</b>	<b>740</b>	<b>Range Minimum</b> <b>X R 1/20</b> The value specifying the minimum of the measurement range Beginning reading <b>Condition for PA:</b> Required for Residential. If the meter provides beginning and ending reads for on and off peak usage, then you must provide beginning and ending reads and consumption. If the meter does not provide beg/ending reads, you only provide consumption. <b>Condition for MD:</b> Required for residential if printed on the LDC bill. <b>Condition for NJ:</b> Required for all rate classes if printed on the LDC bill, and this is an actual read. If the meter does not provide begin/ending reads, only consumption will be provided.
<b>Must Use</b>	<b>MEA06</b>	<b>741</b>	<b>Range Maximum</b> <b>X R 1/20</b> The value specifying the maximum of the measurement range Ending reading or single reading (e.g., demand). <b>PA:</b> Required for Residential. If the meter provides beginning and ending reads for on and off peak usage, then you must provide beginning and ending reads and consumption. If the meter does not provide beg/ending reads, you only provide consumption. <b>MD:</b> Required for residential if printed on the LDC bill.
<b>Must Use</b>	<b>MEA07</b>	<b>935</b>	<b>Measurement Significance Code</b> <b>O ID 2/2</b> Code used to benchmark, qualify or further define a measurement value
			41 Off Peak
			42 On Peak
			43 Intermediate
			51 Total
			Totalizer
			66 Shoulder

**Segment:** **MEA** Measurements (MU=Meter Multiplier)

**Position:** 160

**Loop:** QTY

**Level:** Detail

**Usage:** Optional

**Max Use:** 40

**Purpose:** To specify physical measurements or counts, including dimensions, tolerances, variances, and weights (See Figures Appendix for example of use of C001)

**Syntax Notes:** 1 At least one of MEA03 MEA05 MEA06 or MEA08 is required.

2 If MEA05 is present, then MEA04 is required.

3 If MEA06 is present, then MEA04 is required.

4 If MEA07 is present, then at least one of MEA03 MEA05 or MEA06 is required.

5 Only one of MEA08 or MEA03 may be present.

**Semantic Notes:** 1 MEA04 defines the unit of measure for MEA03, MEA05, and MEA06.

**Comments:** 1 When citing dimensional tolerances, any measurement requiring a sign (+ or -), or any measurement where a positive (+) value cannot be assumed, use MEA05 as the negative (-) value and MEA06 as the positive (+) value.

<b>PA Use:</b>	Required for a meter that has a meter multiplier other than 1. <b>Note:</b> If the BPT04="X4" indicating this document is being sent for an interval account at the account level, this segment will be not be used.
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	MEA**MU*2

### Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	MEA02	738	<b>Measurement Qualifier</b> Code identifying a specific product or process characteristic to which a measurement applies	<b>O</b> ID 1/3
			MU Multiplier	
Must Use	MEA03	739	<b>Measurement Value</b> The value of the measurement	<b>X</b> R 1/20
			Represents the meter constant when MEA02 equals "MU. When the multiplier equals 1, do not send this MEA segment.	

**Segment:** **MEA** Measurements (ZA=Power Factor)

**Position:** 160

**Loop:** QTY

**Level:** Detail

**Usage:** Optional

**Max Use:** 40

**Purpose:** To specify physical measurements or counts, including dimensions, tolerances, variances, and weights (See Figures Appendix for example of use of C001)

**Syntax Notes:**

- 1 At least one of MEA03 MEA05 MEA06 or MEA08 is required.
- 2 If MEA05 is present, then MEA04 is required.
- 3 If MEA06 is present, then MEA04 is required.
- 4 If MEA07 is present, then at least one of MEA03 MEA05 or MEA06 is required.
- 5 Only one of MEA08 or MEA03 may be present.

**Semantic Notes:**

- 1 MEA04 defines the unit of measure for MEA03, MEA05, and MEA06.

**Comments:**

- 1 When citing dimensional tolerances, any measurement requiring a sign (+ or -), or any measurement where a positive (+) value cannot be assumed, use MEA05 as the negative (-) value and MEA06 as the positive (+) value.

<b>PA Use:</b>	Required if it is available to the meter agent and it is used in the calculation of the customer's bill. This is only relevant and should only ever be sent with Demand (K1). If not present with a demand quantity, it should be assumed to be 1. <b>Note:</b> If the BPT04="X4" indicating this document is being sent for an interval account at the account level, this segment will be not be used.
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	MEA**ZA*.95

### Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	MEA02	738	<b>Measurement Qualifier</b> Code identifying a specific product or process characteristic to which a measurement applies ZA Power Factor Relationship between watts and volt - amperes necessary to supply electric load	<b>O ID 1/3</b>
Must Use	MEA03	739	<b>Measurement Value</b> The value of the measurement Represents the Power Factor when MEA02 equals "ZA". When no Power Factor is present or the value is 1, do not send this MEA segment.	<b>X R 1/20</b>

**Segment:** **MEA** Measurements (CO=Transformer Loss Multiplier)

**Position:** 160

**Loop:** QTY

**Level:** Detail

**Usage:** Optional

**Max Use:** 40

**Purpose:** To specify physical measurements or counts, including dimensions, tolerances, variances, and weights (See Figures Appendix for example of use of C001)

**Syntax Notes:**

- 1 At least one of MEA03 MEA05 MEA06 or MEA08 is required.
- 2 If MEA05 is present, then MEA04 is required.
- 3 If MEA06 is present, then MEA04 is required.
- 4 If MEA07 is present, then at least one of MEA03 MEA05 or MEA06 is required.
- 5 Only one of MEA08 or MEA03 may be present.

**Semantic Notes:** 1 MEA04 defines the unit of measure for MEA03, MEA05, and MEA06.

**Comments:** 1 When citing dimensional tolerances, any measurement requiring a sign (+ or -), or any measurement where a positive (+) value cannot be assumed, use MEA05 as the negative (-) value and MEA06 as the positive (+) value.

<b>PA Use:</b>	Required when Transformer Loss is not calculated by the meter. <b>Note:</b> If the BPT04="X4" indicating this document is being sent for an interval account at the account level, this segment will not be used.
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	MEA**CO*1.02

### Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	MEA02	738	<b>Measurement Qualifier</b> Code identifying a specific product or process characteristic to which a measurement applies CO Transformer Loss Multiplier When a customer owns a transformer and the transformer loss is not measured by the meter.	<b>O ID 1/3</b>
Must Use	MEA03	739	<b>Measurement Value</b> The value of the measurement Represents the Transformer Loss Multiplier when MEA02 equals "CO".	<b>X R 1/20</b>

**Segment:** **PTD** Product Transfer and Resale Detail (BP= Bill Presentment)

**Position:** 010

**Loop:** PTD

**Level:** Detail

**Usage:** Mandatory

**Max Use:** 1

**Purpose:** To indicate the start of detail information relating to the transfer/resale of a product and provide identifying data

**Syntax Notes:** 1 If either PTD02 or PTD03 is present, then the other is required.

2 If either PTD04 or PTD05 is present, then the other is required.

**Semantic Notes:**

**Comments:**

<b>Notes:</b>	PTD Loops may be sent in any order.  There will be a separate PTD BP loop for each meter and unit of measurement on the account. There will also be BP loops for unmetered data as needed.
<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB
<b>Example:</b>	PTD*BP

#### Data Element Summary

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>PTD01</b>	<b>521</b>	<b>Product Transfer Type Code</b>	<b>M ID 2/2</b>
			Code identifying the type of product transfer	
			BP Bill Presentment Information	

**Segment:** **DTM** **Date/Time Reference (150=Service Period Start)**  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>Notes:</b>	This date reflects the beginning of the date range for this meter for this billing period.
<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB
<b>Example:</b>	DTM*150*20240101

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>DTM01</b>	<b>374</b>	<b>Date/Time Qualifier</b>	<b>M ID 3/3</b>
			Code specifying type of date or time, or both date and time	
			150 Service Period Start	
<b>Must Use</b>	<b>DTM02</b>	<b>373</b>	<b>Date</b>	<b>X DT 8/8</b>
			Date expressed as CCYYMMDD	

**Segment:** **DTM** **Date/Time Reference (151=Service Period End)**  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>Notes:</b>	This date reflects the end of the date range for this meter for this billing period.
<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB
<b>Example:</b>	DTM*151*20240131

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>DTM01</b>	<b>374</b>	<b>Date/Time Qualifier</b>	<b>M ID 3/3</b>
			Code specifying type of date or time, or both date and time	
			151 Service Period End	
<b>Must Use</b>	<b>DTM02</b>	<b>373</b>	<b>Date</b>	<b>X DT 8/8</b>
			Date expressed as CCYYMMDD	

**Segment:** **DTM** Date/Time Reference (514=Meter Exchange Date)  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>Notes:</b>	Used in conjunction with either the Service Period Start Date or the Service Period End Date to indicate when a meter has been replaced. Separate PTD loops must be created for each period and meter.
<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB and if included on the corresponding PTD*PM Loop
<b>Example:</b>	<p>Date Range in the first PTD is shown as:  DTM*150*19990201  DTM*514*19990214</p> <p>Date Range in the second PTD is shown as:  DTM*514*19990215  DTM*151*19990228</p>

**Data Element Summary**

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>Attributes</b>
<b>Must Use</b>	<b>DTM01</b>	<b>374</b>	<b>Date/Time Qualifier</b>	<b>M ID 3/3</b>
			Code specifying type of date or time, or both date and time	
			514 Transferred	
			Exchanged meter read date	
<b>Must Use</b>	<b>DTM02</b>	<b>373</b>	<b>Date</b>	<b>X DT 8/8</b>
			Date expressed as CCYYMMDD	

**Segment:** **REF** Reference Identification (MG=Meter Number)  
**Position:** 030  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 20  
**Purpose:** To specify identifying information  
**Syntax Notes:**

- 1 At least one of REF02 or REF03 is required.
- 2 If either C04003 or C04004 is present, then the other is required.
- 3 If either C04005 or C04006 is present, then the other is required.

**Semantic Notes:**

- 1 REF04 contains data relating to the value cited in REF02.

**Comments:**

<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB. Metered accounts will have the Meter Number. Unmetered accounts will have the value UNMETERED.
<b>Example:</b>	REF*MG*2222277S REF*MG*UNMETERED

#### Data Element Summary

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>Attributes</b>
<b>Must Use</b>	<b>REF01</b>	<b>128</b>	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification MG Meter Number	<b>M ID 2/3</b>
<b>Must Use</b>	<b>REF02</b>	<b>127</b>	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier	<b>X AN 1/30</b>

**Segment:** **REF** **Reference Identification (NH=LDC Rate Class)**  
**Position:** 030  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 20  
**Purpose:** To specify identifying information  
**Syntax Notes:**

- 1 At least one of REF02 or REF03 is required.
- 2 If either C04003 or C04004 is present, then the other is required.
- 3 If either C04005 or C04006 is present, then the other is required.

**Semantic Notes:**

- 1 REF04 contains data relating to the value cited in REF02.

**Comments:**

<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB if present on corresponding 867MU PTD-PM Loop
<b>Example:</b>	REF*NH*GS1

#### Data Element Summary

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>Attributes</b>
<b>Must Use</b>	<b>REF01</b>	<b>128</b>	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification NH LDC Rate Code	<b>M ID 2/3</b>
<b>Must Use</b>	<b>REF02</b>	<b>127</b>	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier	<b>X AN 1/30</b>

**Segment:** **REF** Reference Identification (PR=LDC Rate Subclass)  
**Position:** 030  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 20  
**Purpose:** To specify identifying information  
**Syntax Notes:** 1 At least one of REF02 or REF03 is required.  
 2 If either C04003 or C04004 is present, then the other is required.  
 3 If either C04005 or C04006 is present, then the other is required.  
**Semantic Notes:** 1 REF04 contains data relating to the value cited in REF02.  
**Comments:**

<b>Notes:</b>	This iteration of the REF segment is used for meter level information.
<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB if present on corresponding 867MU PTD-PM Loop
<b>Example:</b>	REF*PR*123

#### Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>X12 Attributes</u>
<b>Must Use</b>	<b>REF01</b>	<b>128</b>	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification  PR Price Quote Number LDC Rate Subclass – Used to provide further classification of a rate.	<b>M ID 2/3</b>
<b>Must Use</b>	<b>REF02</b>	<b>127</b>	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier	<b>X AN 1/30</b>

**Segment:** **REF** **Reference Identification (K6=LDC Rate Description)**  
**Position:** 030  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 20  
**Purpose:** To specify identifying information  
**Syntax Notes:** 1 At least one of REF02 or REF03 is required.  
 2 If either C04003 or C04004 is present, then the other is required.  
 3 If either C04005 or C04006 is present, then the other is required.  
**Semantic Notes:** 1 REF04 contains data relating to the value cited in REF02.  
**Comments:**

<b>Notes:</b>	This iteration of the REF segment is used for passing the Rate description on some PHI accounts for inclusion on the MD SCB Bill.
<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB if Rate Description is required to be printed on MD SCB Customer Bill.
<b>Example:</b>	REF*K6*Y*Unmetered Street Lighting REF*K6*N*Telecommunications Network

#### Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>X12 Attributes</u>
Must Use	REF01	128	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification  K6 Purchase Description LDC Rate Description – Used to provide required detail for inclusion on MD SCB Bill.	M ID 2/3
Must Use	REF02	127	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier.  Print Summary Box indicator (Y/N)	X AN 1/30
Must Use	REF03	352	<b>Description</b> A free-form description to clarify the related data elements and their content	X AN 1/80

**Segment:** **REF** **Reference Identification (JH=Meter Role)**  
**Position:** 030  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 20  
**Purpose:** To specify identifying information  
**Syntax Notes:**

- 1 At least one of REF02 or REF03 is required.
- 2 If either C04003 or C04004 is present, then the other is required.
- 3 If either C04005 or C04006 is present, then the other is required.

**Semantic Notes:**

- 1 REF04 contains data relating to the value cited in REF02.

**Comments:**

<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB
<b>Example:</b>	REF*JH*A

### Data Element Summary

	<b>Ref. Des.</b>	<b>Data Element</b>	<b>Name</b>	<b>Attributes</b>
<b>Must Use</b>	<b>REF01</b>	<b>128</b>	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification JH Meter Role	<b>M ID 2/3</b>
<b>Must Use</b>	<b>REF02</b>	<b>127</b>	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier When REF01 is JH, valid values for REF02 are: S = Subtractive - this consumption needs to be subtracted from the summarized total. A = Additive - this consumption contributed to the summarized total (do nothing). I = Ignore - this consumption did not contribute to the summarized total (do nothing).	<b>X AN 1/30</b>

**Segment:** **REF** Reference Identification (IX=Number of Dials/Digits)  
**Position:** 030  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 20  
**Purpose:** To specify identifying information  
**Syntax Notes:** 1 At least one of REF02 or REF03 is required.  
 2 If either C04003 or C04004 is present, then the other is required.  
 3 If either C04005 or C04006 is present, then the other is required.  
**Semantic Notes:** 1 REF04 contains data relating to the value cited in REF02.  
**Comments:**

<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB if present on corresponding 867MU PTD-PM Loop
<b>Examples:</b>	REF*IX*6.0 REF*IX*5.1 REF*IX*4.2

#### Data Element Summary

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>X12 Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>REF01</b>	<b>128</b>	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification  IX Rate Card Number Number of Dials on the Meter displayed as the number of dials to the left of the decimal, a decimal point, and the number of dials to the right of the decimal.	<b>M ID 2/3</b>
<b>Must Use</b>	<b>REF02</b>	<b>127</b>	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier	<b>X AN 1/30</b>
<b>Optional</b>	<b>REF03</b>	<b>352</b>	<b>Description</b> A free-form description to clarify the related data elements and their content Optional use: See Meter Type (REF*MT) on 814 Enrollment for valid codes.	<b>X AN 1/80</b>

# Dials	Positions to left of decimal	Positions to right of decimal	X12 Example
6	6	0	REF*IX*6.0
6	5	1	REF*IX*5.1
6	4	2	REF*IX*4.2

<b>Segment:</b>	<b>REF</b> <b>Reference Identification (Unmetered Service Type)</b>
<b>Position:</b>	030
<b>Loop:</b>	PTD
<b>Level:</b>	Detail
<b>Usage:</b>	Optional
<b>Max Use:</b>	20
<b>Purpose:</b>	To specify identifying information
<b>Syntax Notes:</b>	<ol style="list-style-type: none"> <li>1 At least one of REF02 or REF03 is required.</li> <li>2 If either C04003 or C04004 is present, then the other is required.</li> <li>3 If either C04005 or C04006 is present, then the other is required.</li> </ol>
<b>Semantic Notes:</b>	1 REF04 contains data relating to the value cited in REF02.
<b>Comments:</b>	

<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	<p>Conditional: Required for MD SCB when the REF*MG Meter number = UNMETERED and the REF*K6 Print Summary Box = Y.  REF*MG*UNMETERED  REF*K6*Y*Unmetered Street Lighting</p> <p>PHI and Potomac Edison will provide additional information to the Supplier for the specified Unmetered Service for inclusion on the MD SCB Bill. Includes the type of device as well as additional text information which may be useful (i.e., a specific wattage of a light, additional text information for further clarification, etc.)</p> <p>BGE does not currently provide this detail on their bill and will not provide it in the 867.</p>
<b>Examples:</b>	REF*PRT*UNMETERED*100 WATT HPS REF*PRT*UNMETERED*150 WATT HPS REF*PRT*UNMETERED*400 WATT HPS REF*PRT*UNMETERED*70 WATT HPS REF*PRT*UNMETERED*ATTACHED TO C&P TEL CO POLE

## Data Element Summary

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>REF01</b>	<b>128</b>	<b>Reference Identification Qualifier</b> Code qualifying the Reference Identification PRT Product Type Defined Unmetered Service Type	<b>M ID 2/3</b>
<b>Must Use</b>	<b>REF02</b>	<b>127</b>	<b>Reference Identification</b> Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier UNMETERED This code will be used for all PHI and PE unmetered devices. BGE does not currently provide this detail on their bills.	<b>X AN 1/30</b>
<b>Must Use</b>	<b>REF03</b>	<b>352</b>	<b>Description</b> A free-form description to clarify the related data elements and their content Used to provide the description of the specific Unmetered Device. i.e., 100 WATT HPS  This free-form text cannot contain any characters that may be used as element delimiters, sub-element delimiters, segment terminators, or field separators (This includes asterisk *, pipes  , tabs, linefeeds, carets ^, angle brackets < >, and tildes ~).	<b>X AN 1/80</b>

**Segment:** QTY Quantity  
**Position:** 110  
**Loop:** QTY  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 1  
**Purpose:** To specify quantity information  
**Syntax Notes:** 1 At least one of QTY02 or QTY04 is required.  
 2 Only one of QTY02 or QTY04 may be present.  
**Semantic Notes:** 1 QTY04 is used when the quantity is non-numeric.  
**Comments:**

<b>Notes:</b>	<p>There will be one QTY loop for <b>each</b> of the QTY03 Units of Measurement listed below for each meter that is measured on this account.</p> <p>If there are 2 meters on the account, and one measures KWH and KW, and the other measures just KWH, there will be 3 PTD01=PM loops.</p> <p>If a meter measures total usage, as well as on-peak and off-peak, there will be three QTY loops sent within one PTD01=PM loop. The MEA segment that follows each QTY will specify which time of use the QTY applies to.</p>
<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	<p>Conditional: Required for MD SCB if present on corresponding 867MU PTD-PM Loop and when the REF*MG Meter number = UNMETERED with the REF*K6 Print Summary Box = Y. (REF*MG*UNMETERED and REF*K6*Y*Unmetered Street Lighting)</p> <p>One QTY Loop is required for each consumption quantity per unmetered device. The billable quantity is the total unmetered consumption per device type for the billable period.</p>
<b>Example:</b>	<p>QTY*QD*22348*KH</p> <p>QTY*QD*14*K1 (If meter measures both, you will have two QTY loops)</p> <p>QTY~QD~2000~EA^^20^KH</p>

## Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	QTY01	673	Quantity Qualifier	M ID 2/2
			Code specifying the type of quantity	
			KA Estimated Quantity Delivered	
			Used when the quantity delivered is an estimated quantity.	
			QD Actual Quantity Delivered	
			Used when the quantity delivered is an actual quantity.	
			87 Actual Quantity Received (Net Metering)	
			Used when the net generation quantity received is actual.	
			9H Estimated Quantity Received (Net Metering)	
			Used when the net generation quantity received is estimated.	
Must Use	QTY02	380	Quantity	X R 1/15
			Numeric value of quantity	
Must Use	QTY03	355	Unit or Basis for Measurement Code	M ID 2/2
			Code specifying the units in which a value is being expressed, or manner in which a measurement has been taken	
			K1 Kilowatt Demand (kW)	

				Represents potential power load measured at predetermined intervals
			K2	Kilovolt Amperes Reactive Demand (kVAR)
				Reactive power that must be supplied for specific types of customer's equipment; billable when kilowatt demand usage meets or exceeds a defined parameter
			K3	Kilovolt Amperes Reactive Hour (kVARH)
				Represents actual electricity equivalent to kilowatt hours; billable when usage meets or exceeds defined parameters
			K4	Kilovolt Amperes (KVA)
			KH	Kilowatt Hour (kWh)
			EA	Each
<b>Cond</b>	<b>C00103</b>	<b>649</b>	<b>Multiplier</b>	<b>O R 1/10</b>
				Value to be used as a multiplier to obtain a new value
				Number of unmetered devices for this specific Unmetered Service Type (as defined in the REF~PRT segment).
<b>Cond</b>	<b>C00104</b>	<b>355</b>	<b>Unit or Basis for Measurement Code</b>	<b>O ID 2/2</b>
				Code specifying the units in which a value is being expressed, or manner in which a measurement has been taken.
			KH	Kilowatt Hour

**Segment: MEA Measurements****Position:** 160**Loop:** QTY**Level:** Detail**Usage:** Optional**Max Use:** 40**Purpose:** To specify physical measurements or counts, including dimensions, tolerances, variances, and weights (See Figures Appendix for example of use of C001)**Syntax Notes:** 1 At least one of MEA03 MEA05 MEA06 or MEA08 is required.

2 If MEA05 is present, then MEA04 is required.

3 If MEA06 is present, then MEA04 is required.

4 If MEA07 is present, then at least one of MEA03 MEA05 or MEA06 is required.

5 Only one of MEA08 or MEA03 may be present.

**Semantic Notes:** 1 MEA04 defines the unit of measure for MEA03, MEA05, and MEA06.**Comments:** 1 When citing dimensional tolerances, any measurement requiring a sign (+ or -), or any measurement where a positive (+) value cannot be assumed, use MEA05 as the negative (-) value and MEA06 as the positive (+) value.

<b>Notes:</b>	The MEA segment is sent for each QTY loop. The MEA will indicate the “time of use” that applies to the QTY. If meter readings are included in the MEA, they will indicate the “time of use” that the meter readings apply to.
<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB if present on corresponding PTD-PM Loop and to provide additional information for bill presentment purposes. MEA segment must contain MEA05 and MEA06 Meter Beginning Reading and Meter Ending Reading values on KH reads. BGE does not provide on TOU reads, only total usage segments.
<b>Examples:</b>	MEA*AE*PRQ*589.00000*KH*89466.00000*90055.00000*51 MEA*BO*RUD*243342*KH***51

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>MEA01</b>	<b>737</b>	<b>Measurement Reference ID Code</b>	<b>O ID 2/2</b>
			Code identifying the broad category to which a measurement applies	
			AA	Meter reading-beginning actual/ending actual
			AE	Meter reading-beginning actual/ending estimated
			AF	Actual Total
			BO	Meter Reading as Billed
				Used when billing charges are based on contractual agreements or pre-established usage and not on actual usage
			EA	Meter reading-beginning estimated/ending actual
			EE	Meter reading-beginning estimated/ending estimated
<b>Must Use</b>	<b>MEA02</b>	<b>738</b>	<b>Measurement Qualifier</b>	<b>O ID 1/3</b>
			Code identifying a specific product or process characteristic to which a measurement applies	
			PRQ	Consumption
			RUD	Usage Deviation (applies to Kilowatt Hours, Kilowatt Demand and Reactive Demand)
				MD SCB: A RUD MEA segment is required when Billed Usage is different than the PRQ Consumption value provided in the PM loop. This is used for Supplier to be able to present the current level of detail that is on the Utility Bill.

<b>Must Use</b>	<b>MEA03</b>	<b>739</b>	<b>Measurement Value</b>	<b>X</b>	<b>R 1/20</b>
The value of the measurement					
Represents quantity of consumption delivered for service period. Contains the difference in the meter readings (or as measured by the meter) multiplied by various factors, excluding Power Factor.					
<b>Must Use</b>	<b>MEA04</b>	<b>355</b>	<b>Unit or Basis for Measurement Code</b>	<b>M</b>	<b>ID 2/2</b>
Code specifying the units in which a value is being expressed, or manner in which a measurement has been taken					
<div>K1</div> <div>Kilowatt Demand</div> <div>Represents potential power load measured at predetermined intervals</div>					
<div>K2</div> <div>Kilovolt Amperes Reactive Demand</div> <div>Reactive power that must be supplied for specific types of customer's equipment; billable when kilowatt demand usage meets or exceeds a defined parameter</div>					
<div>K3</div> <div>Kilovolt Amperes Reactive Hour</div> <div>Represents actual electricity equivalent to kilowatt hours; billable when usage meets or exceeds defined parameters</div>					
<div>K4</div> <div>Kilovolt Amperes (KVA)</div>					
<div>K5</div> <div>Kilovolt Amperes Reactive</div>					
<div>KH</div> <div>Kilowatt Hour</div>					
<b>Must Use</b>	<b>MEA05</b>	<b>740</b>	<b>Range Minimum</b>	<b>X</b>	<b>R 1/20</b>
The value specifying the minimum of the measurement range					
Beginning reading Required for MD SCB for Printing in the SCB Customer Bill.					
<b>Must Use</b>	<b>MEA06</b>	<b>741</b>	<b>Range Maximum</b>	<b>X</b>	<b>R 1/20</b>
The value specifying the maximum of the measurement range					
Ending reading or single reading (e.g., demand). Required for MD SCB for Printing in the SCB Customer Bill.					
<b>Must Use</b>	<b>MEA07</b>	<b>935</b>	<b>Measurement Significance Code</b>	<b>O</b>	<b>ID 2/2</b>
Code used to benchmark, qualify, or further define a measurement value					
<div>41</div> <div>Off Peak</div>					
<div>42</div> <div>On Peak</div>					
<div>43</div> <div>Intermediate</div>					
<div>51</div> <div>Total</div>					
<div></div> <div>Totalizer</div>					
<div>66</div> <div>Shoulder</div>					

<b>Segment:</b>	<b>MEA</b> Measurements (MU=Meter Multiplier)
<b>Position:</b>	160
<b>Loop:</b>	QTY
<b>Level:</b>	Detail
<b>Usage:</b>	Optional
<b>Max Use:</b>	40
<b>Purpose:</b>	To specify physical measurements or counts, including dimensions, tolerances, variances, and weights (See Figures Appendix for example of use of C001)
<b>Syntax Notes:</b>	<ol style="list-style-type: none"> <li>1 At least one of MEA03 MEA05 MEA06 or MEA08 is required.</li> <li>2 If MEA05 is present, then MEA04 is required.</li> <li>3 If MEA06 is present, then MEA04 is required.</li> <li>4 If MEA07 is present, then at least one of MEA03 MEA05 or MEA06 is required.</li> <li>5 Only one of MEA08 or MEA03 may be present.</li> </ol>
<b>Semantic Notes:</b>	1 MEA04 defines the unit of measure for MEA03, MEA05, and MEA06.
<b>Comments:</b>	1 When citing dimensional tolerances, any measurement requiring a sign (+ or -), or any measurement where a positive (+) value cannot be assumed, use MEA05 as the negative (-) value and MEA06 as the positive (+) value.

<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB if present on corresponding PTD-PM Loop and to provide additional information for bill presentment purposes. Will be added in the BP Loop when Meter Multiplier = 1 or missing in the corresponding PM Loop.
<b>Example:</b>	MEA**MU*2

#### Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	MEA02	738	Measurement Qualifier	O ID 1/3
			Code identifying a specific product or process characteristic to which a measurement applies	
			MU Multiplier	
Must Use	MEA03	739	Measurement Value	X R 1/20
			The value of the measurement	
			Represents the meter constant when MEA02 equals "MU".	
			MD SCB Use - the Meter Multiplier should be provided when available including when it is equal to 1.	

**Segment:** **MEA** Measurements (ZA=Power Factor)

**Position:** 160

**Loop:** QTY

**Level:** Detail

**Usage:** Optional

**Max Use:** 40

**Purpose:** To specify physical measurements or counts, including dimensions, tolerances, variances, and weights (See Figures Appendix for example of use of C001)

**Syntax Notes:**

- 1 At least one of MEA03 MEA05 MEA06 or MEA08 is required.
- 2 If MEA05 is present, then MEA04 is required.
- 3 If MEA06 is present, then MEA04 is required.
- 4 If MEA07 is present, then at least one of MEA03 MEA05 or MEA06 is required.
- 5 Only one of MEA08 or MEA03 may be present.

**Semantic Notes:**

- 1 MEA04 defines the unit of measure for MEA03, MEA05, and MEA06.

**Comments:**

- 1 When citing dimensional tolerances, any measurement requiring a sign (+ or -), or any measurement where a positive (+) value cannot be assumed, use MEA05 as the negative (-) value and MEA06 as the positive (+) value.

<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB if present on corresponding PTD-PM Loop and to provide additional information for bill presentment purposes. Will be added in the BP Loop when Meter Multiplier = 1 or missing in the corresponding PM Loop.
<b>Example:</b>	MEA**ZA*.95

#### Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	MEA02	738	Measurement Qualifier	O ID 1/3
			Code identifying a specific product or process characteristic to which a measurement applies	
			ZA Power Factor	
			Relationship between watts and volt - amperes necessary to supply electric load	
Must Use	MEA03	739	Measurement Value	X R 1/20
			The value of the measurement	
			Represents the Power Factor when MEA02 equals "ZA".	
			MD SCB Use - the Power Factor should be provided when available including when it is equal to 1.	

<b>Segment:</b>	<b>MEA</b> Measurements (CO=Transformer Loss Multiplier)
<b>Position:</b>	160
<b>Loop:</b>	QTY
<b>Level:</b>	Detail
<b>Usage:</b>	Optional
<b>Max Use:</b>	40
<b>Purpose:</b>	To specify physical measurements or counts, including dimensions, tolerances, variances, and weights (See Figures Appendix for example of use of C001)
<b>Syntax Notes:</b>	<ol style="list-style-type: none"> <li>1 At least one of MEA03 MEA05 MEA06 or MEA08 is required.</li> <li>2 If MEA05 is present, then MEA04 is required.</li> <li>3 If MEA06 is present, then MEA04 is required.</li> <li>4 If MEA07 is present, then at least one of MEA03 MEA05 or MEA06 is required.</li> <li>5 Only one of MEA08 or MEA03 may be present.</li> </ol>
<b>Semantic Notes:</b>	1 MEA04 defines the unit of measure for MEA03, MEA05, and MEA06.
<b>Comments:</b>	1 When citing dimensional tolerances, any measurement requiring a sign (+ or -), or any measurement where a positive (+) value cannot be assumed, use MEA05 as the negative (-) value and MEA06 as the positive (+) value.

<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional: Required for MD SCB if present on corresponding PTD-PM Loop and to provide additional information for bill presentment purposes. Will be added in the BP Loop when Meter Multiplier = 1 or missing in the corresponding PM Loop.
<b>Example:</b>	MEA**CO*1.02

## Data Element Summary

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>MEA02</b>	<b>738</b>	<b>Measurement Qualifier</b>	<b>O ID 1/3</b>
			Code identifying a specific product or process characteristic to which a measurement applies	
			CO Transformer Loss Multiplier	
			When a customer owns a transformer, and the transformer loss is not measured by the meter.	
<b>Must Use</b>	<b>MEA03</b>	<b>739</b>	<b>Measurement Value</b>	<b>X R 1/20</b>
			The value of the measurement	
			Represents the Transformer Loss Multiplier when MEA02 equals "CO".	

**Segment:** **PTD** Product Transfer and Resale Detail (BC=Unmetered Services Summary)  
**Position:** 010  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Mandatory  
**Max Use:** 1  
**Purpose:** To indicate the start of detail information relating to the transfer/resale of a product and provide identifying data

**Syntax Notes:** 1 If either PTD02 or PTD03 is present, then the other is required.  
 2 If either PTD04 or PTD05 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>Notes:</b>	PTD Loops may be sent in any order.
<b>PA Use:</b>	Required if there are unmetered services on this account.
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	PTD*BC

**Data Element Summary**

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	PTD01	521	Product Transfer Type Code Code identifying the type of product transfer BC Unmetered Services Summary	M ID 2/2

**Note:**

Refer to the “PTD Loops Definition” section earlier in this document for an explanation of this specific PTD Loop.

**Segment:** **DTM** Date/Time Reference (150=Service Period Start)  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>PA Use:</b>	Required if there are unmetered services on this account
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	DTM*150*19990101

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
Must Use	DTM01	374	<b>Date/Time Qualifier</b> Code specifying type of date or time, or both date and time 150 Service Period Start	<b>M ID 3/3</b>
Must Use	DTM02	373	<b>Date</b> Date expressed as CCYYMMDD	<b>X DT 8/8</b>

**Segment:** **DTM** Date/Time Reference (151=Service Period End)  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>PA Use:</b>	Required if there are unmetered services on this account
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Same as PA
<b>Example:</b>	DTM*151*19990131

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
Must Use	DTM01	374	<b>Date/Time Qualifier</b> Code specifying type of date or time, or both date and time 151 Service Period End	<b>M ID 3/3</b>
Must Use	DTM02	373	<b>Date</b> Date expressed as CCYYMMDD	<b>X DT 8/8</b>

**Segment:** QTY Quantity  
**Position:** 110  
**Loop:** QTY  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 1  
**Purpose:** To specify quantity information  
**Syntax Notes:** 1 At least one of QTY02 or QTY04 is required.  
 2 Only one of QTY02 or QTY04 may be present.  
**Semantic Notes:** 1 QTY04 is used when the quantity is non-numeric.  
**Comments:**

<b>Notes:</b>	This loop is required when there are unmetered services on the account. This will contain the total quantity for the unmetered services.
<b>PA Use:</b>	Required is there are unmetered services on the account
<b>NJ Use:</b>	Same as PA
<b>DE Use:</b>	Same as PA
<b>MD Use:</b>	Required if there are unmetered services on the account.  MD SCB Use: The billable quantity is the TOTAL unmetered consumption per account. Detailed QTY values by device will be provided in the PTD*BP Loop for Bill Presentment purposes.
<b>Example:</b>	QTY*QD*500*KH

## Data Element Summary

	<u>Ref.</u> <u>Des.</u>	<u>Data</u> <u>Element</u>	<u>Name</u>	<u>Attributes</u>
Must Use	QTY01	673	<b>Quantity Qualifier</b> Code specifying the type of quantity	M ID 2/2
			QD Actual Quantity Delivered Used when the quantity delivered is an actual quantity.	
			<b>All States:</b> Whether unmetered services are estimated, calculated, or actual, they will be coded as actual.	
Must Use	QTY02	380	<b>Quantity</b> Numeric value of quantity	X R 1/15
Must Use	QTY03	355	<b>Unit or Basis for Measurement Code</b> Code specifying the units in which a value is being expressed, or manner in which a measurement has been taken	M ID 2/2
			99 Watts	
			K1 Kilowatt Demand (kW)	
			KH Kilowatt Hour	

**Segment:** **PTD** **Product Transfer and Resale Detail (BJ=Generation Transferred In/Out)**

**Position:** 010

**Loop:** PTD

**Level:** Detail

**Usage:** Mandatory

**Max Use:** 1

**Purpose:** To indicate the start of detail information relating to the transfer/resale of a product and provide identifying data

**Syntax Notes:**

- 1 If either PTD02 or PTD03 is present, then the other is required.
- 2 If either PTD04 or PTD05 is present, then the other is required.

**Semantic Notes:**

**Comments:**

<b>Notes:</b>	PTD Loops may be sent in any order.
	There will be one PTD loop to identify the generation transferred in/out for the period.
<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	ACE and JCPL Only: Required if the account has net metering
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Required if the account has net metering or is a part of an Aggregated Net Energy Metering (ANEM) Family.
<b>Example:</b>	PTD*BJ

### Data Element Summary

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
Must Use	PTD01	521	<b>Product Transfer Type Code</b>	<b>M ID 2/2</b>
			Code identifying the type of product transfer	
			BJ	Relocation
				Generation transferred:
				<ul style="list-style-type: none"> <li>From this account to another account</li> <li>From another account to this account</li> <li>From this account to this account</li> </ul>
				Generation banked:
				<ul style="list-style-type: none"> <li>Starting Bank</li> <li>Ending Bank</li> </ul>

**Segment:** **DTM** **Date/Time Reference (150=Service Period Start)**  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>Notes:</b>	This specific PTD loop is required if the account has net metering or is a part of an Aggregated Net Energy Metering (ANEM) Family.
	This date reflects the beginning of the date range for this meter for this billing period.
<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	ACE and JCPL Only: Required if the account has net metering
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Required
<b>Example:</b>	DTM*150*20160615

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>DTM01</b>	<b>374</b>	<b>Date/Time Qualifier</b>	<b>M ID 3/3</b>
			Code specifying type of date or time, or both date and time	
			150 Service Period Start	
<b>Must Use</b>	<b>DTM02</b>	<b>373</b>	<b>Date</b>	<b>X DT 8/8</b>
			Date expressed as CCYYMMDD	

**Segment:** **DTM** **Date/Time Reference (151=Service Period End)**  
**Position:** 020  
**Loop:** PTD  
**Level:** Detail  
**Usage:** Optional  
**Max Use:** 10  
**Purpose:** To specify pertinent dates and times  
**Syntax Notes:**

- 1 At least one of DTM02 DTM03 or DTM05 is required.
- 2 If DTM04 is present, then DTM03 is required.
- 3 If either DTM05 or DTM06 is present, then the other is required.

**Semantic Notes:****Comments:**

<b>Notes:</b>	<p>This specific PTD loop is required if the account has net metering or is a part of an Aggregated Net Energy Metering (ANEM) Family.</p> <p>This date reflects the end of the date range for this meter for this billing period.</p>
<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	ACE and JCPL Only: Required if the account has net metering
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Required
<b>Example:</b>	DTM*151*20160715

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>DTM01</b>	<b>374</b>	<b>Date/Time Qualifier</b>	<b>M ID 3/3</b>
			Code specifying type of date or time, or both date and time	
			151 Service Period End	
<b>Must Use</b>	<b>DTM02</b>	<b>373</b>	<b>Date</b>	<b>X DT 8/8</b>
			Date expressed as CCYYMMDD	

<b>Segment:</b>	<b>QTY</b> Quantity
<b>Position:</b>	110
<b>Loop:</b>	QTY
<b>Level:</b>	Detail
<b>Usage:</b>	Optional
<b>Max Use:</b>	1
<b>Purpose:</b>	To specify quantity information
<b>Syntax Notes:</b>	<b>1</b> At least one of QTY02 or QTY04 is required. <b>2</b> Only one of QTY02 or QTY04 may be present.
<b>Semantic Notes:</b>	<b>1</b> QTY04 is used when the quantity is non-numeric.
<b>Comments:</b>	

<b>Notes:</b>	<p>This specific PTD loop is required if the account has net metering or is a part of an Aggregated Net Energy Metering (ANEM) Family.</p> <p>If the meter measures total usage, as well as on-peak, intermediate peak and off-peak, there will be three MEA loops sent within each QTY loop to specify which time of use each MEA applies to. If any TOU measurement is zero, it must be sent.</p>
<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	ACE and JCPL Only: Required if the account has net metering
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	<p>Required Notes for use...</p> <p><u>QTY01 = 77:</u> required in ANEM family accounts when generation is transferred into the account. Not used for net metered accounts not part of ANEM family. MD SCB – FE (Potomac Edison) only. Will use “77” to show transfer of Community Solar kwh credit from the Host account to the Child account.</p> <p><u>QTY01 = 78:</u> required in ANEM family accounts when generation is transferred out of the account. Not used for net metered accounts not part of ANEM family.</p> <p><u>QTY01 = 79:</u> required in ANEM family accounts and regular net metered accounts not part of ANEM family when there is excess generation self-applied from the Starting Bank.</p> <p><u>QTY01 = QB:</u> required in ANEM family accounts and regular net metered accounts not part of ANEM family when there is excess generation for a True-Up event.</p> <p><u>QTY01 = OH (Starting Bank) &amp; OE (Ending Bank):</u> required for the PARENTHOST account and CHILD accounts with net metering under the ANEM family. Also required for any net metered account that is not part of the ANEM family. These segments will be sent even where the value is 0 kWh. Not sent under the PARENT account for PHI.</p>
<b>Example:</b>	<p>QTY*77*1000*KH                      Example generation transferred in to this child account            MEA*AF*PRQ*1000*KH***51</p> <p>QTY*78*750*KH                      Example generation transferred out from TOU parent account            MEA*AF*PRQ*400*KH***41            MEA*AF*PRQ*300*KH***42            MEA*AF*PRQ*50*KH***43</p> <p>Additional examples provided in the back of this Implementation Guideline.</p>

## Data Element Summary

Ref.	Data	Name	Attributes
Des.	Element	Quantity Qualifier	M ID 2/2
Must Use	QTY01	673	
		Code specifying the type of quantity	
		77	Stock Transfers In Generation transferred from another account to this account
		78	Stock Transfers Out Generation transferred from this account to another account
		79	Billing Unit(s) Per Pricing Unit Self-generation applied from Starting Bank
	867 Monthly Usage (4010)	95	IG867MUv7-0.docx

			QB	Quantity Dispensed			
				Excess generation for True-Up event.			
			QE	Quantity Carried Forward			
				Ending Bank			
			QH	Quantity on Hold			
				Starting Bank			
Must Use	QTY02	380	Quantity		X	R	1/15
			Numeric value of quantity				
Must Use	QTY03	355	Unit or Basis for Measurement Code		M	ID	2/2
			Code specifying the units in which a value is being expressed, or manner in which a measurement has been taken				
			KH	Kilowatt Hour (kWh)			

**Segment: MEA Measurements****Position:** 160**Loop:** QTY**Level:** Detail**Usage:** Optional**Max Use:** 40**Purpose:** To specify physical measurements or counts, including dimensions, tolerances, variances, and weights (See Figures Appendix for example of use of C001)**Syntax Notes:** 1 At least one of MEA03 MEA05 MEA06 or MEA08 is required.

2 If MEA05 is present, then MEA04 is required.

3 If MEA06 is present, then MEA04 is required.

4 If MEA07 is present, then at least one of MEA03 MEA05 or MEA06 is required.

5 Only one of MEA08 or MEA03 may be present.

**Semantic Notes:** 1 MEA04 defines the unit of measure for MEA03, MEA05, and MEA06.**Comments:** 1 When citing dimensional tolerances, any measurement requiring a sign (+ or -), or any measurement where a positive (+) value cannot be assumed, use MEA05 as the negative (-) value and MEA06 as the positive (+) value.

<b>Notes:</b>	This specific PTD loop is required if the account has net metering or is a part of an Aggregated Net Energy Metering (ANEM) Family.	
	The MEA segment is sent for each QTY loop. The MEA will indicate the “time of use” that applies to the QTY.	
<b>PA Use:</b>	Not Used	
<b>NJ Use:</b>	ACE and JCPL Only: Required if the account has net metering	
<b>DE Use:</b>	Not Used	
<b>MD Use:</b>	Required for each QTY	
<b>Examples:</b>	<p>QTY*77*1000*KH                      Example kWh transferred to child account          MEA*AF*PRQ*1000*KH***51</p> <p>QTY*78*750*KH                      Example kWh transferred away from TOU host account          MEA*AF*PRQ*400*KH***41          MEA*AF*PRQ*300*KH***42          MEA*AF*PRQ*50*KH***43</p>	

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b>Des.</b>	<b>Element</b>		
<b>Must Use</b>	<b>MEA01</b>	<b>737</b>	<b>Measurement Reference ID Code</b>	<b>O ID 2/2</b>
			Code identifying the broad category to which a measurement applies	
			AF                      Actual Total	
			Total consumption being transferred from a host account or to a child account; or starting/ending bank value.	
<b>Must Use</b>	<b>MEA02</b>	<b>738</b>	<b>Measurement Qualifier</b>	<b>O ID 1/3</b>
			Code identifying a specific product or process characteristic to which a measurement applies	
			PRQ                      Consumption	
<b>Must Use</b>	<b>MEA03</b>	<b>739</b>	<b>Measurement Value</b>	<b>X R 1/20</b>
			The value of the measurement	
			Represents quantity of consumption being transferred between host and child accounts for a service period. The addition of the QTYs in this loop, as well as the PTD*PM and PTD*BC loop should add to the PTD*BB loop.	
<b>Must Use</b>	<b>MEA04</b>	<b>355</b>	<b>Unit or Basis for Measurement Code</b>	<b>M ID 2/2</b>
			Code specifying the units in which a value is being expressed, or manner in which a measurement has been taken	
			KH                      Kilowatt Hour	
<b>Must Use</b>	<b>MEA07</b>	<b>935</b>	<b>Measurement Significance Code</b>	<b>O ID 2/2</b>
			Code used to benchmark, qualify or further define a measurement value	

41	Off Peak
42	On Peak
43	Intermediate
51	Total
	Totalizer
66	Shoulder

<b>Segment:</b>	<b>REF</b> Reference Identification (AN=Aggregate Net Energy Meter Role)
<b>Position:</b>	190
<b>Loop:</b>	QTY
<b>Level:</b>	Detail
<b>Usage:</b>	Optional
<b>Max Use:</b>	>1
<b>Purpose:</b>	To specify identifying information
<b>Syntax Notes:</b>	<ol style="list-style-type: none"> <li>1 At least one of REF02 or REF03 is required.</li> <li>2 If either C04003 or C04004 is present, then the other is required.</li> <li>3 If either C04005 or C04006 is present, then the other is required.</li> </ol>
<b>Semantic Notes:</b>	1 REF04 contains data relating to the value cited in REF02.
<b>Comments:</b>	

<b>PA Use:</b>	Not Used
<b>NJ Use:</b>	Not Used
<b>DE Use:</b>	Not Used
<b>MD Use:</b>	Conditional –FE (Potomac Edison) ONLY: Required when customer participates in BOTH Supplier Consolidated Billing (SCB) and Community Solar (CS) programs. Used when usage is transferred into a Child account from the Community Solar Host account.in order to provide the Community Solar Program Description for printing on the customer bill. NOTE: Not Used by BGE and PHI. Neither provide usage-based Community Solar Credits.
<b>Example:</b>	REF*AN* CHILD* Maryland Community Solar Program.”

## Data Element Summary

	Ref. Des.	Data Element	Name	X12 Attributes
Must Use	REF01	128	Reference Identification Qualifier	M ID 2/3
			Code qualifying the Reference Identification	
			AN Associated Accounts	
			FE (Potomac Edison) Community Solar Child Account	
Must Use	REF02	127	Reference Identification	X AN 1/30
			Reference information as defined for a particular Transaction Set or as specified by the Reference Identification Qualifier	
			CHILD FE (Potomac Edison): Community Solar Child Account to identify the Community Solar Program description for SCB customer bill requirements.	
			BGE & PHI: Not Used	
Must Use	REF03	352	Description	X AN 1/80
			A free-form description to clarify the related data elements and their content	
			Maryland Community Solar Program.	
			Required for Potomac Edison Community Solar Program description for bill print requirements. This should be printed on the SCB bill.	

**Segment:** **SE** Transaction Set Trailer  
**Position:** 030  
**Loop:**  
**Level:** Summary  
**Usage:** Mandatory  
**Max Use:** 1  
**Purpose:** To indicate the end of the transaction set and provide the count of the transmitted segments (including the beginning (ST) and ending (SE) segments)

**Syntax Notes:****Semantic Notes:**

**Comments:** **1** SE is the last segment of each transaction set.

<b>PA Use:</b>	Required
<b>NJ Use:</b>	Required
<b>DE Use:</b>	Required
<b>MD Use:</b>	Required
<b>Example:</b>	SE*28*000000001

**Data Element Summary**

	<b>Ref.</b>	<b>Data</b>	<b>Name</b>	<b>Attributes</b>
	<b><u>Des.</u></b>	<b><u>Element</u></b>		
<b>Must Use</b>	<b>SE01</b>	<b>96</b>	<b>Number of Included Segments</b>	<b>M N0 1/10</b>
			Total number of segments included in a transaction set including ST and SE segments	
<b>Must Use</b>	<b>SE02</b>	<b>329</b>	<b>Transaction Set Control Number</b>	<b>M AN 4/9</b>
			Identifying control number that must be unique within the transaction set functional group assigned by the originator for a transaction set	

## Examples:

### General Note:

For the detail portion, you may send your PTD loops in any order; this is a function of ANSI. The indicator in the PTD loop tells what information is contained in the loop. A translator's mapper will map the loop according to your instructions.

### Example 1 – One Meter – On/off peak:

Following example is for an account with one meter. Meter multiplier is 2, Power factor is 1.9999, and no transformer loss. The meter measures on and off peak consumption, and the meter readings are at the on / off peak consumption level. The meter also measures on and off peak demand.

- Total consumption is 100 KWH (60 on peak / 40 off-peak). Demand: On peak 4.7, Off peak 4.1 (billed 4.7).
- This example includes the Summary loop which summarizes kWh (and KVARH, if it existed), and the Monthly Billed Summary for billed kWh, kW (and kvarh if relevant).

BPT*00*REF1-990125*19990125*DD	Meter detail loop
DTM*649*19990202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
MEA**NP*0.66667	Percent participation. If 100%, no need to send. This example is ESP has 66.667%, LDC 33.333%.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME	Customer name
REF*12*1234567891	LDC Account number
REF*45*9395819001	Old LDC Account number (to be sent for 60 days after a account number change)
REF*11*1394951	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*D1*100*KH	Monthly billed kWh
QTY*D1*4.7*K1	Monthly derived (billed) demand
QTY*QD*4.7*K1	Monthly measured demand
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990101	
DTM*151*19990131	
QTY*QD*100*KH	Calculated summary of all meters for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop for kWh
DTM*150*19990101	
DTM*151*19990131	
REF*MG*111111111	Meter number
REF*NH*RES	LDC Rate
REF*PR*RESRT	LDC Rate Subclass
REF*JH*A	Additive meter
REF*IX*6.0	Number of dials or digits
QTY*QD*100*KH	Consumption
MEA**MU*2	Meter multiplier = 2
MEA*AA*PRQ*100*KH*1201*1250*51	Total consumption with begin/end reads
QTY*QD*60*KH	Consumption
MEA**MU*2	Meter multiplier = 2
MEA*AA*PRQ*60*KH*11001*11030*42	(On peak with consumption and begin/end reads)
QTY*QD*40*KH	Consumption
MEA**MU*2	Meter multiplier = 2
MEA*AA*PRQ*40*KH*23031*23050*41	(Off peak with consumption and begin/end reads)
<b>PTD*PM</b>	Meter detail loop for kW
DTM*150*19990101	
DTM*151*19990131	

REF*MG*11111111	Meter number
REF*NH*RES	LDC Rate
REF*PR*RESRT	LDC Rate Subclass
REF*JH*A	Additive meter
REF*IX*6.0	Number of dials or digits
QTY*QD*4.7*K1	Demand
MEA**MU*2	Meter multiplier = 2
MEA**ZA*1.9999	Power factor = 1.9999
MEA*AA*PRQ*4.7*K1***42	On peak demand – readings not required since reset each month
QTY*QD*4.2*K1	Demand
MEA**MU*2	Meter multiplier = 2
MEA**ZA*1.9999	Power factor = 1.9999
MEA*AA*PRQ*4.2*K1***41	Off peak demand

### Example 2 – One Meter - Totalizer

Following example is for an account with one meter. Meter multiplier is 2, Power factor is 1.9999, and no transformer loss. The meter measures on and off peak consumption, and the meter readings are only at the “totalizer” level. The meter also measures on and off peak demand.

- Total consumption is 100 KWH (60 on peak / 40 off-peak). Demand: On peak 4.7, Off peak 4.1 (billed 4.7).
- This example includes the Summary loop which summarizes kWh (and Kvarh, if it existed), and the Monthly Billed Summary for billed kWh, kW (and kvarh if relevant).

BPT*00*REF1-990155*19990131*DD	Meter detail loop
DTM*649*19990202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME	Customer name
REF*12*1234567890	LDC Account number
REF*45*9395819000	Old LDC Account number (to be sent for 60 days after a account number change)
REF*11*1394959	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*D1*100*KH	Monthly billed kWh
QTY*D1*4.7*K1	Monthly derived demand
QTY*QD*4.7*K1	Monthly measured demand
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*QD*100*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
REF*MG*11111111	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*100*KH	Consumption
MEA**MU*2	Meter multiplier = 2
MEA*AA*PRQ*100*KH*2500*2550*51	Total consumption, and begin and end readings
QTY*QD*60*KH	Consumption
MEA**MU*2	Meter multiplier = 2
MEA*AA*PRQ*60*KH***42	(On peak consumption)
QTY*QD*40*KH	Consumption
MEA**MU*2	Meter multiplier = 2
MEA*AA*PRQ*40*KH***41	(off peak consumption)
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990101	Start period

DTM*151*19990131	End period
REF*MG*11111111	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*4.7*K1	Demand
MEA**MU*2	Meter multiplier = 2
MEA**ZA*1.9999	Power factor = 1.9999
MEA*AA*PRQ*4.7*K1***42	On peak demand – readings not required since reset each month
QTY*QD*4.2*K1	Demand
MEA**MU*2	Meter multiplier = 2
MEA**ZA*1.9999	Power factor = 1.9999
MEA*AA*PRQ*4.2*K1***41	Off peak demand)

**Example 3 – One Meter – Totalizer Only – No Demand:**

Following example is for an account with one meter. Meter multiplier is 1. There is no Power factor and no transformer loss. There is no time of use on the meter. Demand is not measured.

- Total consumption is 600 kWh.
- This example includes the Summary loop which summarizes kWh, and the Monthly Billed Summary for billed kWh.

BPT*00*REF1-990124*19990124*DD	Meter detail loop
DTM*649*19990202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME	Customer name
REF*12*12345678920	LDC Account number
REF*45*93958190020	Old LDC Account number (to be sent for 60 days after a account number change)
REF*11*13949529	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*D1*600*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*QD*600*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
REF*MG*22222222	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*600*KH	Consumption
MEA*AA*PRQ*600*KH*32000*32600*51	Total consumption, and begin and end readings

**Selected Billing Test Scenarios:****Scenario - Single meter totaled (one rate), Month 1**

Consumption is 1234.

BPT*00*REF01-990201*19990201*DD	Meter detail loop
DTM*649*19990202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT1	Customer name
REF*12*1111111111111111	LDC Account number
REF*11*1394959	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*D1*1234*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*QD*1234*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
REF*MG*222222S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*1234*KH	Consumption
MEA*AA*PRQ*1234*KH*32000*33234*51	Total consumption, and begin and end readings

**Scenario - Single meter with time of day billing, Month 1**

On peak – 724, Off peak 539.

BPT*00*REF04-990201*19990201*DD	Meter detail loop
DTM*649*19990202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT4	Customer name
REF*12*4444444444	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*D1*1263*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*QD*1263*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
REF*MG*222223S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*1263*KH	Consumption
MEA*AA*PRQ*1263*KH*10000*11263*51	Total consumption
QTY*QD*724*KH	Consumption

MEA*AA*PRQ*724*KH*32000*32724*42	On peak, and begin and end readings
QTY*QD*539*KH	Consumption
MEA*AA*PRQ*539*KH*15000*15539*41	Off peak, and begin and end readings

**Scenario - Single meter totaled. Meter switched by LDC during month 1.**

Meter 1 usage 652, meter 2 usage 235.

BPT*00*REF06-990201*19990201*DD	Meter detail loop
DTM*649*19990202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*12*6323423480	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*D1*887*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*QD*887*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop – Meter 1
DTM*150*19990101	Start period
DTM*514*19990121	End period
REF*MG*2222266S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*652*KH	Consumption – Meter 1
MEA*AA*PRQ*652*KH*20000*20652*51	Total consumption, with begin/end readings– Meter 1
<b>PTD*PM</b>	Meter detail loop – Meter 2
DTM*514*19990122	Start period
DTM*151*19990131	End period
REF*MG*3333366S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*235*KH	Consumption – Meter 2
MEA*AA*PRQ*235*KH*0*235*51	Total consumption, with begin/end readings– meter 2

**Scenario - Single meter, Demand and KWH meter (non-interval), Month 1**

Month 1 information: KW 14, KWH 22,348 (no readings available). Billed demand is 50 per contract.

BPT*00*REF07-990201*19990201*DD	Meter detail loop
DTM*649*19990202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT7	Customer name
REF*12*7777777777	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*D1*22348*KH	Monthly billed kWh
QTY*D1*50*K1	Monthly derived demand
QTY*QD*14*K1	Monthly measured demand
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*QD*22348*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
REF*MG*2222277S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*22348*KH	Consumption
MEA*AA*PRQ*22348*KH*130000*152348*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
REF*MG*2222277S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*14*K1	Demand
MEA*AA*PRQ*14*K1***51	Total demand, with begin/end readings

**Scenario - Multiple meters, Demand and KWH meter (non-interval).**

Month 1 Meter 1 information: KW 14, KWH 22,348 (no readings available). Billed demand is 50 per contract.

Meter 2 information: KW 15, KWH 20,000.

BPT*00*REF07-990201*19990201*DD	Meter detail loop
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT8	Customer name
REF*12*888888888888	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*D1*42348*KH	Monthly billed kWh
QTY*D1*50*K1	Monthly derived demand
QTY*QD*29*K1	Monthly measured demand
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*QD*42348*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*PM</b>	Meter 1 detail loop
DTM*150*19990101	Start period

DTM*151*19990131	End period
REF*MG*222277S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*22348*KH	Consumption
MEA*AA*PRQ*22348*KH*130000*152348*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter 1 detail loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
REF*MG*222277S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*14*K1	Demand
MEA*AA*PRQ*14*K1***51	Total demand, with begin/end readings
<b>PTD*PM</b>	Meter 2 detail loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
REF*MG*1234577S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*20000*KH	Consumption
MEA*AA*PRQ*20000*KH*185000*205000*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter 1 detail loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
REF*MG*1234577S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*15*K1	Demand
MEA*AA*PRQ*15*K1***51	Total demand, with begin/end readings

**Scenario - Multiple services, metered and unmetered.**

Metered consumption is 763, unmetered is 48.

BPT*00*REF09-990201*19990201*DD	Meter detail loop
DTM*649*19990202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT9	Customer name
REF*12*999999999999	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*D1*811*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*QD*763*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
REF*MG*222299S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*763*KH	Consumption
MEA*AA*PRQ*763*KH*12000*12763*51	Total consumption, with begin/end readings
<b>PTD*BC</b>	Unmetered Services Summary
DTM*150*19990101	Start period
DTM*151*19990131	End period

QTY*QD*48*KH	Unmetered consumption
--------------	-----------------------

**Scenario - Unmetered Service alone.**

Unmetered consumption is 97.

BPT*00*REF10-990201*19990201*DD	Meter detail loop
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT10	Customer name
REF*12*100000000	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*D1*97*KH	Monthly billed kWh
<b>PTD*BC</b>	Unmetered Services Summary
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*QD*97*KH	Unmetered consumption

**Scenario - Single meter totaled (one rate), month 2**

Consumption is 867.

BPT*00*REF01-990301*19990301*DD	Meter detail loop
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT1	Customer name
REF*12*1111111111111111	LDC Account number
REF*11*1394959	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990201	Start period
DTM*151*19990228	End period
QTY*D1*867*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990201	Start period
DTM*151*19990228	End period
QTY*QD*867*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990201	Start period
DTM*151*19990228	End period
REF*MG*2222222S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*867*KH	Consumption
MEA*AA*PRQ*867*KH*33244*34111*51	Total consumption, and begin and end readings

**Scenario - Cancel Months 1 and 2.**

Separate documents must be sent for each month.

BPT*01*REF01-990310A*19990310*DD*****REF01-090201	Meter detail loop
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT1	Customer name
REF*12*111111111111111	LDC Account number
REF*11*1394959	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*D1*1234*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*QD*1234*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
REF*MG*222222S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*1234*KH	Consumption
MEA*AA*PRQ*1234*KH*32000*33234*51	Total consumption, and begin and end readings (not all LDCs can provide MEA on a cancel)

BPT*01*REF01-990310B*19990301*DD*****REF01-990301	Meter detail loop
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT1	Customer name
REF*12*1	LDC Account number
REF*11*1394959	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990201	Start period
DTM*151*19990228	End period
QTY*D1*867*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990201	Start period
DTM*151*19990228	End period
QTY*QD*867*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990201	Start period
DTM*151*19990228	End period
REF*MG*222222S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*867*KH	Consumption
MEA*AA*PRQ*867*KH*33234*34101*51	Total consumption, and begin and end readings (not all LDCs can provide MEA on a cancel)

**Scenario - Restatement of usage for Months 1 and 2.**

Total usage for 2 months is 2043.

BPT*00*REF01-990310C*19990310*DD	Meter detail loop
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT1	Customer name
REF*12*111111111111111	LDC Account number
REF*11*1394959	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990101	Start period
DTM*151*19990228	End period
QTY*D1*2043*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990101	Start period
DTM*151*19990228	End period
QTY*QD*2043*KH	Calculated summary of all metered for kWh only
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990101	Start period
DTM*151*19990228	End period
REF*MG*222222S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*2043*KH	Consumption
MEA*AA*PRQ*2043*KH***51	Total consumption, and readings not known

**Scenario - FINAL during month 2.**

Single meter with time of day billing. Month 2 – On peak – 189, Off peak 67.

BPT*00*REF04-990301*19990301*DD***F	Meter detail loop
DTM*649*19990202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT4	Customer name
REF*12*444444444444	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990201	Start period
DTM*151*19990224	End period
QTY*D1*256*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990201	Start period
DTM*151*19990224	End period
QTY*QD*256*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990201	Start period
DTM*151*19990224	End period
REF*MG*222223S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*256*KH	Consumption
MEA*AA*PRQ*256*KH*20100*20356*51	Total consumption
QTY*QD*189*KH	Consumption
MEA*AA*PRQ*189*KH*32724*32913*42	On peak, and begin and end readings
QTY*QD*67*KH	Consumption
MEA*AA*PRQ*67*KH*15539*15606*41	Off peak, and begin and end readings

**Scenario - Single meter, Demand and KWH meter (non-interval), Month 1:**

KW 14, KWH 22,348 (no readings available – non-residential account). Percent participation: ESP has .6667, LDC has .3333

BPT*00*REF07-990201*19990201*DD	Meter detail loop
DTM*649*19990202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
MEA**NP*0.66667	Percent participation. This example is ESP has 66.667%, LDC 33.333%.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT17	Customer name
REF*12*17	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*D1*22348*KH	Monthly billed kWh
QTY*D1*14*K1	Monthly derived demand
QTY*QD*14*K1	Monthly measured demand
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
QTY*QD*22348*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
REF*MG*2222277S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*22348*KH	Consumption
MEA*AA*PRQ*22348*KH***51	Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*19990101	Start period
DTM*151*19990131	End period
REF*MG*2222277S	
REF*JH*A	
REF*IX*6.0	Number of dials or digits
QTY*QD*14*K1	Consumption
MEA*AA*PRQ*14*K1***51	Total consumption, with begin/end readings

**Pennsylvania, & New Jersey (not PSE&G or FirstEnergy) Net Metering / Customer Generation Examples****Net Meter / Customer Generation Scenario 1A: Consumption greater than generation**

Single meter reporting both in and out flow KH.

Customer consumed 1000KH and generated 200KH. The billed KH in the BB loop is 800KH.

The net consumption in the SU loop is 800KH. The PM is looped, one for the consumption KH (1000KH) and another for the generation KH (200) both with same meter number.

BPT*00*REF06-120201*20120201*DD	Meter detail loop
DTM*649*20120202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*12*6323423480	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*D1*800*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*QD*800*KH	Calculated summary of all metered for KH / kvarh only
<b>PTD*PM</b>	Meter detail loop – <b>Consumption Meter</b>
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*1000*KH	<b>Consumption</b>
MEA*AA*PRQ*1000*KH*20000*21000*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – <b>Generation Meter</b>
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*200*KH	<b>Actual Generation</b>
MEA*AA*PRQ*200*KH*300*500*51	Total generation, with begin/end readings

**Net Meter / Customer Generation Scenario 1B: Generation greater than consumption**

Single meter reporting both in and out flow KH.

Customer generated 1300KH and consumed 1000KH.

The billed KH in the BB loop is zero. The net generation reported in the SU loop is 300KH. The PM is looped, one for the consumption KH (1000KH) and another for the generation KH (1300) both with same meter number.

BPT*00*REF06-120201*20120201*DD	Meter detail loop
DTM*649*20120202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*12*6323423480	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type

REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*87*300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop – <b>Consumption Meter</b>
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*1000*KH	<b>Consumption</b>
MEA*AA*PRQ*1000*KH*20000*21000*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – <b>Generation Meter</b>
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*1300*KH	<b>Actual Generation</b>
MEA*AA*PRQ*1300*KH*300*1600*51	Total generation, with begin/end readings

**Net Meter / Customer Generation Scenario 2A: Consumption greater than generation**

Single meter reporting net KH. Customer consumed 1000KH and generated 200KH. The billed KH in the BB loop is 800KH. The net generation is reported in both the SU and PM loops is 800KH. This method his does NOT report the customer's actual consumption; only the net generation is being reported.

BPT*00*REF06-120201*20120201*DD	Meter detail loop
DTM*649*20120202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*12*6323423480	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*D1*800*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*QD*800*KH	Calculated summary of all metered for KH / kvarh only
<b>PTD*PM</b>	Meter detail loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*800*KH	<b>Consumption</b>
MEA*AA*PRQ*800*KH*20000*20800*51	Total consumption, with begin/end readings

**Net Meter / Customer Generation Scenario 2B: Generation greater than consumption**

Single meter reporting net KH. Customer generated 650KH and consumed 500KH.

The billed KH in the BB loop is zero. The net generation is reported in both the SU and PM loops is 150KH. This method his does NOT report the customer's actual consumption; only the net generation is being reported.

BPT*00*REF06-120201*20120201*DD	Meter detail loop
DTM*649*20120202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*12*6323423480	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*87*150*KH	Net generation, the meter is only reporting the net
<b>PTD*PM</b>	Meter detail loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*150*KH	<b>Actual Generation</b>
MEA*AA*PRQ*150*KH*20000*20150*51	Net generation, with begin/end readings

**Net Meter / Customer Generation Scenario 3A: Consumption greater than generation**

Separate meters, one reporting inflow and another meter reporting outflow KH.

Customer consumed 1000KH and generated 600KH. The net consumption in the SU loop is 400KH.

The billed KH in the BB loop is 400KH.

BPT*00*REF06-120201*20120201*DD	Meter detail loop
DTM*649*20120202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*12*6323423480	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*D1*400*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*QD*400*KH	Calculated summary of all metered for KH / kvarh only
<b>PTD*PM</b>	Meter detail loop – <b>Consumption Meter</b>
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*2222266S	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*1000*KH	<b>Consumption</b>
MEA*AA*PRQ*1000*KH*20000*21000*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – <b>Generation Meter</b>
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*3333366S	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*600*KH	<b>Actual Generation</b>
MEA*AA*PRQ*600*KH*300*900*51	Total generation, with begin/end readings

**Net Meter / Customer Generation Scenario 3B: Generation greater than consumption**

Separate meters, one reporting inflow and another meter reporting outflow KH.

Customer generated 600KH and consumed 400KH. The net generation reported in the SU loop is 200KH.

The billed KH in the BB loop is zero.

BPT*00*REF06-120201*20120201*DD	Meter detail loop
DTM*649*20120202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*12*6323423480	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*87*200*KH	Calculated summary of all metered for KH / kvarh only
<b>PTD*PM</b>	Meter detail loop – <b>Consumption Meter</b>
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*2222266S	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*400*KH	<b>Consumption</b>
MEA*AA*PRQ*400*KH*20000*20400*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – <b>Generation Meter</b>
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*3333366S	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*600*KH	<b>Actual Generation</b>
MEA*AA*PRQ*600*KH*300*900*51	Total generation, with begin/end readings

**Pennsylvania Net Metering / Customer Generation Examples (“Bank Rollover”) / not FirstEnergy**

Scenario is for single meter reading both consumption and generation. Month 1 is net generation applied into ‘bank’. Month 2 is net consumption with bank applied to bill but not fully exhausted. Month 3 is net consumption with bank applied to bill and exhausted with remaining consumption billed to customer.

*Month 1- Customer net generates 800KH into ‘bank’, billed KH is zero.*

BPT*00*REF06-120201*20120201*DD	Meter detail loop
DTM*649*20120202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*12*6323423480	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*87*800*KH	Net KH – 800KH excess generation
<b>PTD*PM</b>	Meter detail loop – <b>Consumption Loop</b>
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*100*KH	<b>Actual Consumption</b>
MEA*AA*PRQ*100*KH*21000*21100*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – <b>Generation Loop</b>
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*900*KH	<b>Actual Generation</b>
MEA*AA*PRQ*900*KH*100*1000*51	Total generation, with begin/end readings

*Month 2- Customer net consumes 500KH reducing the 800KH ‘bank’ by 500KH, billed KH remains zero.*

BPT*00*REF06-120201*20120201*DD	Meter detail loop
DTM*649*20120202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*12*6323423480	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20120201	Start period
DTM*151*20120228	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20120201	Start period
DTM*151*20120228	End period
QTY*QD*500*KH	Net KH – 500KH consumption
<b>PTD*PM</b>	Meter detail loop – <b>Consumption Loop</b>
DTM*150*20120201	Start period
DTM*151*20120228	End period
REF*MG*11111111	Meter Number

REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*700*KH	<b>Actual Consumption</b>
MEA*AA*PRQ*700*KH*21100*21800*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – <b>Generation Loop</b>
DTM*150*20120201	Start period
DTM*151*20120228	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*200*KH	<b>Actual Generation</b>
MEA*AA*PRQ*200*KH*1000*1200*51	Total generation, with begin/end readings

*Month 3- Customer net consumes 500KH, empties the remaining 'bank' of 300KH, billed net of consumption and the bank which is 200KH.*

BPT*00*REF06-120201*20120201*DD	Meter detail loop
DTM*649*20120202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*I2*6323423480	LDC Account number
REF*I1*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20120301	Start period
DTM*151*20120331	End period
QTY*D1*200*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20120301	Start period
DTM*151*20120331	End period
QTY*QD*500*KH	Net KH – 500KH consumption
<b>PTD*PM</b>	Meter detail loop – <b>Consumption Loop</b>
DTM*150*20120201	Start period
DTM*151*20120228	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*800*KH	<b>Actual Consumption</b>
MEA*AA*PRQ*800*KH*21800*22600*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – <b>Generation Loop</b>
DTM*150*20120201	Start period
DTM*151*20120228	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*300*KH	<b>Actual Generation</b>
MEA*AA*PRQ*300*KH*1200*1500*51	Total generation, with begin/end readings

**Pennsylvania Net Metering / Customer Generation Examples (FirstEnergy Companies)**

Scenario 1 – Customer Generation (2000 KH) more than Consumption (1500 KH)

BPT*00*700418133078E*20181213*DD	Meter detail loop
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*12*6323423480	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20181115	Start period
DTM*151*20181213	End period
QTY*D1*1500.00000*KH	Monthly <b>DELIVERED</b> KH (Consumption)
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20181115	Start period
DTM*151*20181213	End period
QTY*QD*1500.00000*KH	Monthly <b>DELIVERED</b> KH
QTY*87*2000.00000*KH	Monthly <b>RECEIVED</b> KH
<b>PTD*PM</b>	Meter detail loop – <b>Consumption Loop (DELIVERED KH)</b>
DTM*150*20181115	Start period
DTM*151*20181213	End period
REF*MG*111111111	Meter Number
REF*6W*1	DELIVERED Channel ID (FirstEnergy ONLY)
REF*NH*ME-RSD	LDC Rate Class
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1500.00000*KH	<b>Actual Consumption (Delivered KH)</b>
MEA*AA*PRQ*1500.00*KH*32134.00000*33634.00000*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – <b>Generation Loop (RECEIVED KH)</b>
DTM*150*20181115	Start period
DTM*151*20181213	End period
REF*MG*111111111	Meter Number
REF*6W*2	RECEIVED Channel ID (FirstEnergy ONLY)
REF*NH*ME-RSD	LDC Rate Class
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*2000.00000*KH	<b>Actual Generation (Received KH)</b>
MEA*AA*PRQ*2000.00000*KH*2393.00000*4393.00000*51	Total generation, with begin/end readings

Scenario 2 – Customer Generation (500 KH) less than Consumption (1500 KH)

BPT*00*700418133078E*20181213*DD	Meter detail loop
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*12*6323423480	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20181115	Start period
DTM*151*20181213	End period
QTY*D1*1500.00000*KH	Monthly <b>DELIVERED</b> KH (Consumption)
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20181115	Start period
DTM*151*20181213	End period
QTY*QD*1500.00000*KH	Monthly <b>DELIVERED</b> KH
QTY*87*500.00000*KH	Monthly <b>RECEIVED</b> KH
<b>PTD*PM</b>	Meter detail loop – <b>Consumption Loop (DELIVERED KH)</b>
DTM*150*20181115	Start period
DTM*151*20181213	End period
REF*MG*11111111	Meter Number
REF*6W*1	DELIVERED Channel ID (FirstEnergy ONLY)
REF*NH*ME-RSD	LDC Rate Class
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1500.00000*KH	<b>Actual Consumption (Delivered KH)</b>
MEA*AA*PRQ*1500.00*KH*32134.00000*33634.00000*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – <b>Generation Loop (RECEIVED KH)</b>
DTM*150*20181115	Start period
DTM*151*20181213	End period
REF*MG*11111111	Meter Number
REF*6W*2	RECEIVED Channel ID (FirstEnergy ONLY)
REF*NH*ME-RSD	LDC Rate Class
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*500.00000*KH	<b>Actual Generation (Received KH)</b>
MEA*AA*PRQ*500.00000*KH*2393.00000*4393.00000*51	Total generation, with begin/end readings

**New Jersey ( PSE&G) Net Metering / Customer Generation Examples****Net Meter / Customer Generation PSE&G Scenario 1A: Consumption greater than generation**

Single meter reporting both in and out flow KH.

Customer consumed 1000KH and generated 200KH.

The billed KH in the BB loop is 800KH.

The net consumption in the SU loop is 800KH.

There is one PM with the QTY looped, one for the consumption KH (1000KH) and another for the generation KH (200) both with same meter number.

BPT*00*REF06-120201*20120201*DD	Meter detail loop
DTM*649*20120202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*12*6323423480	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*D1*800*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*QD*800*KH	Calculated summary of all metered for KH / kvarh only
<b>PTD*PM</b>	Meter detail loop – <b>Consumption Meter</b>
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*111111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*1000*KH	<b>Consumption</b>
MEA*AA*PRQ*1000*KH*20000*21000*51	Total consumption, with begin/end readings
QTY*87*200*KH	<b>Actual Generation</b>
MEA*AA*PRQ*200*KH*300*500*51	Total generation, with begin/end readings

**Net Meter / Customer Generation PSE&G Scenario 1B: Generation greater than consumption**

Single meter reporting both in and out flow KH.

Customer generated 1300KH and consumed 1000KH.

The billed KH in the BB loop is zero.

The net generation reported in the SU loop is 300KH.

There is one PM with the QTYlooped, one for the consumption KH (1000KH) and another for the generation KH (1300).

BPT*00*REF06-120201*20120201*DD	Meter detail loop
DTM*649*20120202*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT6	Customer name
REF*12*6323423480	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*DUAL	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20120101	Start period
DTM*151*20120131	End period
QTY*87*300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop – <b>Consumption Meter</b>
DTM*150*20120101	Start period
DTM*151*20120131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*1000*KH	<b>Consumption</b>
MEA*AA*PRQ*1000*KH*20000*21000*51	Total consumption, with begin/end readings
QTY*87*1300*KH	<b>Actual Generation</b>
MEA*AA*PRQ*1300*KH*300*1600*51	Total generation, with begin/end readings

**Maryland – 867 Monthly Usage - Multiple meter exchange in same service period.**

Service period 1/14/2013 to 2/13/2013

1<sup>st</sup> Meter Exchange on 1/17/20132<sup>nd</sup> Meter Exchange on 1/19/2013

BPT*00*1234567890*20130214*DD	Meter detail loop
DTM*649*20130217*1700	This is only required on Bill Ready Consolidated Billing scenarios. Time is always represented as Eastern prevailing time.
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME	Customer name
REF*12*8771441829	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*LDC	Bill type
REF*PC*DUAL	Bill Calculator
PTD*BB	Monthly Billed Summary loop
DTM*150*20130114	Start period
DTM*151*20130213	End period
QTY*D1*7187*KH	Monthly billed kWh
PTD*SU	Metered services Summary loop
DTM*150*20130114	Start period
DTM*151*20130213	End period
QTY*QD*7187*KH	Calculated summary of all metered for kWh / kvarh only
PTD*PM	Meter detail loop
DTM*150*20130114	Start period
DTM*514*20130117	Meter Change Out Date
REF*MG*OLDMETER1	Old Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*710*KH	Consumption
MEA*AA*PRQ*710*KH***51	Consumption
PTD*PM	Meter detail loop
DTM*514*20130117	Start period
DTM*514*20130119	End period
REF*MG*MTREXCHG1	Meter Number of 1 <sup>st</sup> Meter Exchange
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*0*KH	Consumption
MEA*AA*PRQ*0*KH***51	Total consumption, with begin/end readings
PTD*PM	Meter detail loop
DTM*514*20130119	Start period
DTM*151*20130213	End period
REF*MG* MTREXCHG2	Meter Number of 2 <sup>nd</sup> Meter Exchange
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*6477*KH	Consumption
MEA*AA*PRQ*6477*KH***51	Total consumption, with begin/end readings

**Maryland (BGE)- Examples of regular Net Metered Accounts with PTD\*BJ loop (non-TOU/TOU)**  
(these do not include Aggregate Net Energy Metered (ANEM) account scenarios)

**BGE Scenario A - Non-TOU net meter account. Starting banked amount applied to current usage. Not enough banked generation to cover current usage. Remaining consumption amount billed and no ending banked amount.**

**Current usage amount in PM loop**  
+800 kWh

**Starting banked amount (QTY\*QH)**  
-600 kWh

**Self-generation applied from Starting Bank (QTY\*79)**  
-600 kWh

**Ending banked amounts (QTY\*QE)**  
0 kWh

<b>Non TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*200*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*800*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*800*KH	Consumption
MEA*AA*PRQ*800*KH*59245*60045*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*600*KH	Starting Bank
MEA*AF*PRQ*600*KH***51	Starting Bank
QTY*79*600*KH	Self-Generation
MEA*AF*PRQ*600*KH***51	Self-Generation Applied

QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***51	Ending Bank

**BGE Scenario B - Non-TOU account. Meter exchange (old meter is non-net meter; new meter is net meter). No starting banked amount. Old meter reflects positive usage; new meter reflects net negative usage. Zero billed usage. Account has an ending banked amount. Meter exchange on 12/18/17.**

**Current usage amount in PM loop**

+500 kWh old meter

-1000 kWh new meter

**Starting banked amount (QTY\*QH)**

0 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

0 kWh

**Ending banked amounts (QTY\*QE)**

-500 kWh

<b>Non TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*87*500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop – Meter 1
DTM*150*20171208	Start period
DTM*514*20171218	End period
REF*MG*11111111	Old Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*500*KH	Consumption
MEA*AA*PRQ*500*KH*59545*60045*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – Meter 2
DTM*514*20171218	Start period
DTM*151*20180110	End period
REF*MG*22222222	New Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*1000*KH	Consumption

MEA*AA*PRQ*1000*KH*59245*58245*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***51	Starting Bank
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***51	Self-Generation Applied from Starting Bank
QTY*QE*500*KH	Ending Bank
MEA*AF*PRQ*500*KH***51	Ending Bank

**BGE Scenario C - Non-TOU account. Meter exchange (old meter is net meter; new meter is net meter). Account has starting banked amount. Old meter reflects negative usage; new meter reflects negative usage. Zero billed usage. Account has ending banked amount. Meter exchange on 12/18/17.**

**Current usage amount in PM loop**

-500 kWh old meter

-1000 kWh new meter

**Starting banked amount (QTY\*QH)**

600 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

0 kWh

**Ending banked amounts (QTY\*QE)**

-2100 kWh

<b>Non TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*87*1500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop – Meter 1
DTM*150*20171208	Start period
DTM*514*20171218	End period
REF*MG*11111111	Old Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits

QTY*87*500*KH	Consumption
MEA*AA*PRQ*500*KH*59545*59045*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – Meter 2
DTM*514*20171218	Start period
DTM*151*20180110	End period
REF*MG*22222222	New Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*1000*KH	Consumption
MEA*AA*PRQ*1000*KH*32145*31145*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*QH*600*KH	Starting Bank
MEA*AF*PRQ*600*KH***51	Starting Bank
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***51	Self-Generation Applied from Starting Bank
QTY*QE*2100*KH	Ending Bank
MEA*AF*PRQ*2100*KH***51	Ending Bank

**BGE Scenario D - Non-TOU account. Account has two meters. One meter is net metered; the other meter is not net metered. Account has starting banked amount. The net meter reflects negative usage. The other meter reflects positive usage. Current consumption of +500 is offset by current generation of -1000. Zero billed usage. No generation was applied from starting banked amount. Account has ending banked amount.**

**Current usage amount in PM loop**

-1000 kWh for the net meter  
+500 kWh for the non-net meter

**Starting banked amount (QTY\*QH)**

600 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

0 kWh

**Ending banked amounts (QTY\*QE)**

-1100 kWh

<b>Non TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20171208	Start period
DTM*151*20180110	End period

QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*87*500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop – Meter 1 (Net Meter)
DTM*150*20171208	Start period
DTM*151*20180110	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*1000*KH	Consumption
MEA*AA*PRQ*1000*KH*59545*58545*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – Meter 2 (Non-net Meter)
DTM*150*20171208	Start period
DTM*151*20180110	End period
REF*MG*22222222	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*500*KH	Consumption
MEA*AA*PRQ*500*KH*32145*32645*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*QH*600*KH	Starting Bank
MEA*AF*PRQ*600*KH***51	Starting Bank
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***51	Self-Generation Applied from Starting Bank
QTY*QE*1100*KH	Ending Bank
MEA*AF*PRQ*1100*KH***51	Ending Bank

**BGE Scenario E - TOU net meter account with consumption for current month and starting/ending banked amounts. Zero usage billed.**

**Current usage amounts in PM loop**

Off Peak +1000 kWh

On Peak +1400 kWh

Int Peak +1200 kWh

**Starting banked amounts (QTY\*QH)**

Off Peak -2000 kWh

On Peak -3000 kWh

Int Peak -1500 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

Off Peak – 1000 kWh

On Peak – 1400 kWh

Int Peak – 1200 kWh

**Ending banked amounts (QTY\*QE)**

Off Peak -1000 kWh

On Peak -1600 kWh

Int Peak -300 kWh

Note: For a regular net meter account (non-NMA/ANEM), BGE will only apply generation from an individual peak period to consumption from the same peak period. There will be no cross-peak pollination as done with BGE ANEM TOU accounts. Excess generation will roll forward at the peak level.

<b>TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*3600*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1000*KH	Consumption - Off Peak
MEA*AA*PRQ*1000*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*1400*KH	Consumption - On Peak
MEA*AA*PRQ*1400*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*1200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*1200*KH*0*0*43	Total consumption, with begin/end readings

PTD*BJ	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*2000*KH	Starting Bank
MEA*AF*PRQ*2000*KH***41	Starting Bank – Off Peak
QTY*QH*3000*KH	Starting Bank
MEA*AF*PRQ*3000*KH***42	Starting Bank – On Peak
QTY*QH*1500*KH	Starting Bank
MEA*AF*PRQ*1500*KH***43	Starting Bank – Intermediate Peak
QTY*79*1000*KH	Self-Generation
MEA*AF*PRQ*1000*KH***41	Self-Generation Applied – Off Peak
QTY*79*1400*KH	Self-Generation
MEA*AF*PRQ*1400*KH***42	Self-Generation Applied – On Peak
QTY*79*1200*KH	Self-Generation
MEA*AF*PRQ*1200*KH***43	Self-Generation Applied – Intermediate Peak
QTY*QE*1000*KH	Ending Bank
MEA*AF*PRQ*1000*KH***41	Ending Bank – Off Peak
QTY*QE*1600*KH	Ending Bank
MEA*AF*PRQ*1600*KH***42	Ending Bank – On Peak
QTY*QE*300*KH	Ending Bank
MEA*AF*PRQ*300*KH***43	Ending Bank – Intermediate Peak

**BGE Scenario F - TOU net meter account. On and Intermediate Peak excess generation rolls forward; Off Peak consumption billed. No self-application.**

**Current usage amounts in PM loop**

Off Peak +500 kWh  
On Peak -1000 kWh  
Int Peak -800 kWh

**Starting banked amounts (QTY\*QH)**

Off Peak 0 kWh  
On Peak -2000 kWh  
Int Peak -1000 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

Off Peak 0 kWh  
On Peak 0 kWh  
Int Peak 0 kWh

**Ending banked amounts (QTY\*QE)**

Off Peak = 0 kWh  
On Peak -3000 kWh  
Int Peak -1800 kWh

Note: For a regular net meter account (non-NMA/ANEM), BGE will only apply generation from an individual peak period to consumption from the same peak period. There will be no cross-peak pollination as done with BGE ANEM TOU accounts. Excess generation will roll forward at the peak level.

<b>TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*500*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*1300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*500*KH	Consumption - Off Peak
MEA*AA*PRQ*500*KH*0*0*41	Total consumption, with begin/end readings
QTY*87*1000*KH	Consumption - On Peak
MEA*AA*PRQ*1000*KH*0*0*42	Total consumption, with begin/end readings
QTY*87*800*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*800*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***41	Starting Bank – Off Peak
QTY*QH*2000*KH	Starting Bank
MEA*AF*PRQ*2000*KH***42	Starting Bank – On Peak
QTY*QH*1000*KH	Starting Bank
MEA*AF*PRQ*1000*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***41	Self-Generation Applied – Off Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***42	Self-Generation Applied – On Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***43	Self-Generation Applied – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*3000*KH	Ending Bank
MEA*AF*PRQ*3000*KH***42	Ending Bank – On Peak

QTY*QE*1800*KH	Ending Bank
MEA*AF*PRQ*1800*KH***43	Ending Bank – Intermediate Peak

**BGE Scenario G - TOU net meter account. On Peak excess generation rolls forward. Self-generation applied to Intermediate and Off Peak. Remaining consumption for Intermediate and Off Peak billed.**

**Current usage amounts in PM loop**

Off Peak +800 kWh  
On Peak -1000 kWh  
Int Peak +700 kWh

**Starting banked amounts (QTY\*QH)**

Off Peak -200 kWh  
On Peak -500 kWh  
Int Peak -200 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

Off Peak -200 kWh  
On Peak 0 kWh  
Int Peak -200 kWh

**Ending banked amounts (QTY\*QE)**

Off Peak 0 kWh  
On Peak -1500 kWh  
Int Peak 0 kWh

Note: For a regular net meter account (non-NMA/ANEM), BGE will only apply generation from an individual peak period to consumption from the same peak period. There will be no cross-peak pollination as done with BGE ANEM TOU accounts. Excess generation will roll forward at the peak level.

<b>TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*1100*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*800*KH	Consumption - Off Peak
MEA*AA*PRQ*800*KH*0*0*41	Total consumption, with begin/end readings

QTY*87*1000*KH	Consumption - On Peak
MEA*AA*PRQ*1000*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*700*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*700*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*200*KH	Starting Bank
MEA*AF*PRQ*200*KH***41	Starting Bank – Off Peak
QTY*QH*500*KH	Starting Bank
MEA*AF*PRQ*500*KH***42	Starting Bank – On Peak
QTY*QH*200*KH	Starting Bank
MEA*AF*PRQ*200*KH***43	Starting Bank – Intermediate Peak
QTY*79*200*KH	Self-Generation
MEA*AF*PRQ*200*KH***41	Self-Generation Applied – Off Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***42	Self-Generation Applied – On Peak
QTY*79*200*KH	Self-Generation
MEA*AF*PRQ*200*KH***43	Self-Generation Applied – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*1500*KH	Ending Bank
MEA*AF*PRQ*1500*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**BGE Scenario H - TOU net meter account. No starting banked amounts for any peak period. On Peak excess generation rolls forward. Consumption for Intermediate and Off Peak billed.**

**Current usage amounts in PM loop**

Off Peak +800 kWh

On Peak -500 kWh

Int Peak +700 kWh

**Starting banked amounts (QTY\*QH)**

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

**Ending banked amounts (QTY\*QE) Off Peak 0 kWh**

Off Peak 0 kWh

On Peak -500 kWh

Int Peak 0 kWh

Note: For a regular net meter account (non-NMA/ANEM), BGE will only apply generation from an individual peak period to consumption from the same peak period. There will be no cross-peak pollination as done with BGE ANEM TOU accounts. Excess generation will roll forward at the peak level.

<b>TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*1500*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*1000*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*800*KH	Consumption - Off Peak
MEA*AA*PRQ*800*KH*0*0*41	Total consumption, with begin/end readings
QTY*87*500*KH	Consumption - On Peak
MEA*AA*PRQ*500*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*700*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*700*KH*0*0*43	Total consumption, with begin/end readings

PTD*BJ	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***41	Starting Bank – Off Peak
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***42	Starting Bank – On Peak
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***41	Self-Generation Applied – Off Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***42	Self-Generation Applied – On Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***43	Self-Generation Applied – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*500*KH	Ending Bank
MEA*AF*PRQ*500*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**BGE Scenario I - TOU net meter account. On Peak excess generation rolls forward. Self-generation applied to Intermediate and Off Peak. Remaining consumption for Intermediate and Off Peak billed. Example for end of year net metering True-Up of excess generation.**

*Note this is like Scenario G, except the utility cashes out the customer for the year end excess generation.*

**Current usage amounts in PM loop**

Off Peak +800 kWh

On Peak -1000 kWh

Int Peak +700 kWh

**Starting banked amounts (QTY\*QH)**

Off Peak -200 kWh

On Peak -500 kWh

Int Peak -200 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

Off Peak -200 kWh

On Peak 0 kWh

Int Peak -200 kWh

**True-up of Excess Generation (QTY\*QB)**

Off Peak 0 kWh

On Peak -1500 kWh

Int Peak 0 kWh

**Ending banked amounts (QTY\*QE)**

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

Note 1: For a regular net meter account (non-NMA/ANEM), BGE will only apply generation from an individual peak period to consumption from the same peak period. There will be no cross-peak pollination as done with BGE ANEM TOU accounts. Excess generation will roll forward at the peak level and eventually be cashed out (true-up).  
 Note 2: During True-Up for TOU, if one TOU peak contains excess generation passed in QTY\*QB, all TOU peaks must be sent even when 0 kWh. For non-TOU, if there is no excess generation during the True-Up event, the QTY\*QB will NOT be sent.

<b>TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*1100*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role

REF*IX*5.0	Number of dials or digits
QTY*QD*800*KH	Consumption - Off Peak
MEA*AA*PRQ*800*KH*0*0*41	Total consumption, with begin/end readings
QTY*87*1000*KH	Consumption - On Peak
MEA*AA*PRQ*1000*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*700*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*700*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*200*KH	Starting Bank
MEA*AF*PRQ*200*KH***41	Starting Bank – Off Peak
QTY*QH*500*KH	Starting Bank
MEA*AF*PRQ*500*KH***42	Starting Bank – On Peak
QTY*QH*200*KH	Starting Bank
MEA*AF*PRQ*200*KH***43	Starting Bank – Intermediate Peak
QTY*79*200*KH	Self-Generation
MEA*AF*PRQ*200*KH***41	Self-Generation Applied – Off Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***42	Self-Generation Applied – On Peak
QTY*79*200*KH	Self-Generation
MEA*AF*PRQ*200*KH***43	Self-Generation Applied – Intermediate Peak
QTY*QB*0*KH	True-Up
MEA*AF*PRQ*0*KH***41	True-Up – Off Peak
QTY*QB*1500*KH	True-Up
MEA*AF*PRQ*1500*KH***42	True-Up – On Peak
QTY*QB*0*KH	True-Up
MEA*AF*PRQ*0*KH***43	True-Up – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**Maryland (PHI/Potomac Edison)- Examples of regular Net Metered Accounts w/PTD\*BJ loop (non-TOU/TOU)**  
**(these do not include Aggregate Net Energy Metered (ANEM) accounts.**

**PHI/PE Scenario A - Non-TOU net meter account.** Starting banked amount applied to current usage. Not enough banked generation to cover current usage. Remaining consumption amount billed and no ending banked amount.

**Current consumption in PM loop**

+1800 kWh

**Current generation in PM loop**

-1000 kWh

**Starting banked amount (QTY\*QH)**

-600 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

-600 kWh

**Ending banked amounts (QTY\*QE)**

0 kWh

<b>Non TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*200*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*800*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1800*KH	Consumption
MEA*AA*PRQ*1800*KH*59245*61045*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits

QTY*87*1000*KH	Generation
MEA*AA*PRQ*1000*KH*42101*41101*51	Total Generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*600*KH	Starting Bank
MEA*AF*PRQ*600*KH***51	Starting Bank
QTY*79*600*KH	Self-Generation
MEA*AF*PRQ*600*KH***51	Self-Generation Applied
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***51	Ending Bank

**PHI/PE Scenario B - Non-TOU account.** Meter exchange (old meter is non-net meter; new meter is net meter). No starting banked amount. Old meter reflects positive usage; new meter reflects net negative usage. Zero billed usage. Account has an ending banked amount. Meter exchange on 12/18/17.

**OLD METER - Current consumption in PM loop**

+500 kWh

**NEW METER - Current consumption in PM loop**

+500 kWh

**NEW METER - Current generation in PM loop**

-1500 kWh

**Starting banked amount (QTY\*QH)**

0 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

0 kWh

**Ending banked amounts (QTY\*QE)**

-500 kWh

<b>Non TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*87*500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop – OLD Meter 1
DTM*150*20171208	Start period
DTM*514*20171218	End period

REF*MG*11111111	Old Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*500*KH	Consumption
MEA*AA*PRQ*500*KH*59545*60045*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – NEW Meter 2
DTM*514*20171218	Start period
DTM*151*20180110	End period
REF*MG*22222222	New Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*500*KH	Consumption
MEA*AA*PRQ*500*KH*59245*59745*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – NEW Meter 2
DTM*514*20171218	Start period
DTM*151*20180110	End period
REF*MG*22222222	New Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*1500*KH	Generation
MEA*AA*PRQ*1500*KH*12122*10622*51	Total Generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***51	Starting Bank
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***51	Self-Generation Applied from Starting Bank
QTY*QE*500*KH	Ending Bank
MEA*AF*PRQ*500*KH***51	Ending Bank

**PHI/PE Scenario C - Non-TOU account.** Meter exchange (old meter is net meter; new meter is net meter). Account has starting banked amount. Old meter reflects negative usage; new meter reflects negative usage. Zero billed usage. Account has ending banked amount. Meter exchange on 12/18/17.

**OLD METER - Current consumption in PM loop**

+500 kWh

**OLD METER - Current generation in PM loop**

-1000 kWh

**NEW METER - Current consumption in PM loop**

+1000 kWh

**NEW METER - Current generation in PM loop**

-2000 kWh

**Starting banked amount (QTY\*QH)**

600 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

0 kWh

**Ending banked amounts (QTY\*QE)**

-2100 kWh

<b>Non TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*87*1500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop – Meter 1
DTM*150*20171208	Start period
DTM*514*20171218	End period
REF*MG*11111111	Old Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*500*KH	Consumption
MEA*AA*PRQ*500*KH*59545*59045*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – Meter 1
DTM*150*20171208	Start period
DTM*514*20171218	End period
REF*MG*11111111	Old Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*1000*KH	Generation

MEA*AA*PRQ*1000*KH*12122*11122*51	Total Generation, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – Meter 2
DTM*514*20171218	Start period
DTM*151*20180110	End period
REF*MG*22222222	New Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1000*KH	Consumption
MEA*AA*PRQ*1000*KH*32145*33145*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – Meter 2
DTM*514*20171218	Start period
DTM*151*20180110	End period
REF*MG*22222222	New Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*2000*KH	Generation
MEA*AA*PRQ*2000*KH*32145*30145*51	Total Generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*QH*600*KH	Starting Bank
MEA*AF*PRQ*600*KH***51	Starting Bank
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***51	Self-Generation Applied from Starting Bank
QTY*QE*2100*KH	Ending Bank
MEA*AF*PRQ*2100*KH***51	Ending Bank

**PHI/PE Scenario D - Non-TOU account.** Account has two meters. One meter is net metered; the other meter is **not** net metered. Account has starting banked amount. The net meter reflects negative usage. The other meter reflects positive usage. Current consumption of +500 is offset by current generation of -1000. Zero billed usage. No generation was applied from starting banked amount. Account has ending banked amount.

**NET METER - Current consumption in PM loop**

+1000 kWh

**NET METER - Current generation in PM loop**

-2000 kWh

**NON-NET METER - Current consumption in PM loop**

+500 kWh

**Starting banked amount (QTY\*QH)**

600 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

0 kWh

**Ending banked amounts (QTY\*QE)**

-1100 kWh

<b>Non TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*87*500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop – Meter 1 (Net Meter)
DTM*150*20171208	Start period
DTM*151*20180110	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1000*KH	Consumption
MEA*AA*PRQ*1000*KH*59545*60545*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – Meter 1 (Net Meter)
DTM*150*20171208	Start period
DTM*151*20180110	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*2000*KH	Generation

MEA*AA*PRQ*2000*KH*59545*57545*51	Total Generation, with begin/end readings
<b>PTD*PM</b>	Meter detail loop – Meter 2 (Non-net Meter)
DTM*150*20171208	Start period
DTM*151*20180110	End period
REF*MG*22222222	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*500*KH	Consumption
MEA*AA*PRQ*500*KH*32145*32645*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20171208	Start period
DTM*151*20180110	End period
QTY*QH*600*KH	Starting Bank
MEA*AF*PRQ*600*KH***51	Starting Bank
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***51	Self-Generation Applied from Starting Bank
QTY*QE*1100*KH	Ending Bank
MEA*AF*PRQ*1100*KH***51	Ending Bank

**PHI/PE Scenario E - TOU net meter account with consumption for current month and starting/ending banked amounts. Zero usage billed.**

**Current consumption in PM loop**

Off Peak +1800 kWh  
On Peak +2400 kWh  
Int Peak +1700 kWh

**Current generation in PM loop**

Off Peak -800 kWh  
On Peak -1000 kWh  
Int Peak -500 kWh

**Starting banked amounts (QTY\*QH)**

Off Peak -2000 kWh  
On Peak -3000 kWh  
Int Peak -1500 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

Off Peak –1000 kWh  
On Peak –1400 kWh  
Int Peak –1200 kWh

**Ending banked amounts (QTY\*QE)**

Off Peak -1000 kWh  
On Peak -1600 kWh  
Int Peak -300 kWh

Note: For a regular net meter account (non-NMA/ANEM), the utility will only apply generation from an individual peak period to consumption from the same peak period. Excess generation will roll forward at the peak level.

<b>TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*3600*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1800*KH	Consumption - Off Peak
MEA*AA*PRQ*1800*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*2400*KH	Consumption - On Peak
MEA*AA*PRQ*2400*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*1700*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*1700*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*800*KH	Generation - Off Peak
MEA*AA*PRQ*800*KH*0*0*41	Total Generation, with begin/end readings
QTY*87*1000*KH	Generation - On Peak
MEA*AA*PRQ*1000*KH*0*0*42	Total Generation, with begin/end readings
QTY*87*500*KH	Generation - Intermediate Peak
MEA*AA*PRQ*500*KH*0*0*43	Total Generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*2000*KH	Starting Bank
MEA*AF*PRQ*2000*KH***41	Starting Bank – Off Peak
QTY*QH*3000*KH	Starting Bank
MEA*AF*PRQ*3000*KH***42	Starting Bank – On Peak

QTY*QH*1500*KH	Starting Bank
MEA*AF*PRQ*1500*KH***43	Starting Bank – Intermediate Peak
QTY*79*1000*KH	Self-Generation
MEA*AF*PRQ*1000*KH***41	Self-Generation Applied – Off Peak
QTY*79*1400*KH	Self-Generation
MEA*AF*PRQ*1400*KH***42	Self-Generation Applied – On Peak
QTY*79*1200*KH	Self-Generation
MEA*AF*PRQ*1200*KH***43	Self-Generation Applied – Intermediate Peak
QTY*QE*1000*KH	Ending Bank
MEA*AF*PRQ*1000*KH***41	Ending Bank – Off Peak
QTY*QE*1600*KH	Ending Bank
MEA*AF*PRQ*1600*KH***42	Ending Bank – On Peak
QTY*QE*300*KH	Ending Bank
MEA*AF*PRQ*300*KH***43	Ending Bank – Intermediate Peak

**PHI/PE Scenario F - TOU net meter account. On and Intermediate Peak excess generation rolls forward; Off Peak consumption billed. No self-application.**

**Current consumption in PM loop**

Off Peak +1300 kWh

On Peak +200 kWh

Int Peak +100 kWh

**Current generation in PM loop**

Off Peak -800 kWh

On Peak -1200 kWh

Int Peak -900 kWh

**Starting banked amounts (QTY\*QH)**

Off Peak = 0 kWh

On Peak -2000 kWh

Int Peak -1000 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

**Ending banked amounts (QTY\*QE)**

Off Peak = 0 kWh

On Peak -3000 kWh

Int Peak -1800 kWh

Note: For a regular net meter account, the utility will only apply generation from an individual peak period to consumption from the same peak period. Excess generation will roll forward at the peak level.

**Proposed EDI Transaction**

<b>TOU Net Meter account</b>	
PTD*BB	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period

QTY*D1*500*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*1300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1300*KH	Consumption - Off Peak
MEA*AA*PRQ*1300*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*200*KH	Consumption - On Peak
MEA*AA*PRQ*200*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*100*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*100*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*800*KH	Generation - Off Peak
MEA*AA*PRQ*800*KH*0*0*41	Total Generation, with begin/end readings
QTY*87*1200*KH	Generation - On Peak
MEA*AA*PRQ*1200*KH*0*0*42	Total Generation, with begin/end readings
QTY*87*900*KH	Generation - Intermediate Peak
MEA*AA*PRQ*900*KH*0*0*43	Total Generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***41	Starting Bank – Off Peak
QTY*QH*2000*KH	Starting Bank
MEA*AF*PRQ*2000*KH***42	Starting Bank – On Peak
QTY*QH*1000*KH	Starting Bank
MEA*AF*PRQ*1000*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***41	Self-Generation Applied – Off Peak

QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***42	Self-Generation Applied – On Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***43	Self-Generation Applied – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*3000*KH	Ending Bank
MEA*AF*PRQ*3000*KH***42	Ending Bank – On Peak
QTY*QE*1800*KH	Ending Bank
MEA*AF*PRQ*1800*KH***43	Ending Bank – Intermediate Peak

**PHI/PE Scenario G - TOU net meter account. On Peak excess generation rolls forward. Self-generation applied to Intermediate and Off Peak. Remaining consumption for Intermediate and Off Peak billed.**

**Current consumption in PM loop**

Off Peak +1600 kWh

On Peak +200 kWh

Int Peak +1550 kWh

**Current generation in PM loop**

Off Peak -800 kWh

On Peak -1200 kWh

Int Peak -850 kWh

**Starting banked amounts (QTY\*QH)**

Off Peak -200 kWh

On Peak -500 kWh

Int Peak -200 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

Off Peak -200 kWh

On Peak = 0 kWh

Int Peak -200 kWh

**Ending banked amounts (QTY\*QE)**

Off Peak = 0 kWh

On Peak -1500 kWh

Int Peak = 0 kWh

Note: For a regular net meter account, the utility will only apply generation from an individual peak period to consumption from the same peak period. Excess generation will roll forward at the peak level.

<b>TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*1100*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period

QTY*QD*500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1600*KH	Consumption - Off Peak
MEA*AA*PRQ*1600*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*200*KH	Consumption - On Peak
MEA*AA*PRQ*200*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*1550*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*1550*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*800*KH	Generation - Off Peak
MEA*AA*PRQ*800*KH*0*0*41	Total Generation, with begin/end readings
QTY*87*1200*KH	Generation - On Peak
MEA*AA*PRQ*1200*KH*0*0*42	Total Generation, with begin/end readings
QTY*87*850*KH	Generation - Intermediate Peak
MEA*AA*PRQ*850*KH*0*0*43	Total Generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*200*KH	Starting Bank
MEA*AF*PRQ*200*KH***41	Starting Bank – Off Peak
QTY*QH*500*KH	Starting Bank
MEA*AF*PRQ*500*KH***42	Starting Bank – On Peak
QTY*QH*200*KH	Starting Bank
MEA*AF*PRQ*200*KH***43	Starting Bank – Intermediate Peak
QTY*79*200*KH	Self-Generation
MEA*AF*PRQ*200*KH***41	Self-Generation Applied – Off Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***42	Self-Generation Applied – On Peak
QTY*79*200*KH	Self-Generation
MEA*AF*PRQ*200*KH***43	Self-Generation Applied – Intermediate Peak

QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*1500*KH	Ending Bank
MEA*AF*PRQ*1500*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**Scenario H - TOU net meter account. No starting banked amounts for any peak period. On Peak excess generation rolls forward. Consumption for Intermediate and Off Peak billed.**

**Current consumption in PM loop**

Off Peak +1600 kWh

On Peak +700 kWh

Int Peak +1550 kWh

**Current generation in PM loop**

Off Peak -800 kWh

On Peak -1200 kWh

Int Peak -850 kWh

**Starting banked amounts (QTY\*QH)**

Off Peak = 0 kWh

On Peak = 0 kWh

Int Peak = 0 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

Off Peak = 0 kWh

On Peak = 0 kWh

Int Peak = 0 kWh

**Ending banked amounts (QTY\*QE)**

Off Peak = 0 kWh

On Peak -500 kWh

Int Peak = 0 kWh

Note: For a regular net meter account, the utility will only apply generation from an individual peak period to consumption from the same peak period. Excess generation will roll forward at the peak level.

<b>TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*1500*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*1000*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period

REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1600*KH	Consumption - Off Peak
MEA*AA*PRQ*1600*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*700*KH	Consumption - On Peak
MEA*AA*PRQ*700*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*1550*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*1550*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*800*KH	Generation - Off Peak
MEA*AA*PRQ*800*KH*0*0*41	Total Generation, with begin/end readings
QTY*87*1200*KH	Generation - On Peak
MEA*AA*PRQ*1200*KH*0*0*42	Total Generation, with begin/end readings
QTY*87*850*KH	Generation - Intermediate Peak
MEA*AA*PRQ*850*KH*0*0*43	Total Generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***41	Starting Bank – Off Peak
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***42	Starting Bank – On Peak
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***41	Self-Generation Applied – Off Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***42	Self-Generation Applied – On Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***43	Self-Generation Applied – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*500*KH	Ending Bank
MEA*AF*PRQ*500*KH***42	Ending Bank – On Peak

QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**PHI/PE Scenario I - TOU net meter account. On Peak excess generation rolls forward. Self-generation applied to Intermediate and Off Peak. Remaining consumption for Intermediate and Off Peak billed. Example for end of year net metering True-Up of excess generation.**

*Note this is like Scenario G, except the utility cashes out the customer for the year end excess generation.*

**Current consumption in PM loop**

Off Peak +1600 kWh

On Peak +200 kWh

Int Peak +1550 kWh

**Current generation in PM loop**

Off Peak -800 kWh

On Peak -1200 kWh

Int Peak -850 kWh

**Starting banked amounts (QTY\*QH)**

Off Peak -200 kWh

On Peak -500 kWh

Int Peak -200 kWh

**Self-generation applied from Starting Bank (QTY\*79)**

Off Peak -200 kWh

On Peak = 0 kWh

Int Peak -200 kWh

**True-up of Excess Generation (QTY\*QB)**

Off Peak 0 kWh

On Peak -1500 kWh

Int Peak 0 kWh

**Ending banked amounts (QTY\*QE)**

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

Note 1: For a regular net meter account, the utility will only apply generation from an individual peak period to consumption from the same peak period. Excess generation will roll forward at the peak level and eventually be cashed out (true-up).

Note 2: During True-Up for TOU, if one TOU peak contains excess generation passed in QTY\*QB, all TOU peaks must be sent even when 0 kWh. For non-TOU, if there is no excess generation during the True-Up event, the QTY\*QB will NOT be sent.

<b>TOU Net Meter account</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*1100*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period

DTM*151*20160504	End period
QTY*QD*500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1600*KH	Consumption - Off Peak
MEA*AA*PRQ*1600*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*200*KH	Consumption - On Peak
MEA*AA*PRQ*200*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*1550*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*1550*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*800*KH	Generation - Off Peak
MEA*AA*PRQ*800*KH*0*0*41	Total Generation, with begin/end readings
QTY*87*1200*KH	Generation - On Peak
MEA*AA*PRQ*1200*KH*0*0*42	Total Generation, with begin/end readings
QTY*87*850*KH	Generation - Intermediate Peak
MEA*AA*PRQ*850*KH*0*0*43	Total Generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*200*KH	Starting Bank
MEA*AF*PRQ*200*KH***41	Starting Bank – Off Peak
QTY*QH*500*KH	Starting Bank
MEA*AF*PRQ*500*KH***42	Starting Bank – On Peak
QTY*QH*200*KH	Starting Bank
MEA*AF*PRQ*200*KH***43	Starting Bank – Intermediate Peak
QTY*79*200*KH	Self-Generation
MEA*AF*PRQ*200*KH***41	Self-Generation Applied – Off Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***42	Self-Generation Applied – On Peak
QTY*79*200*KH	Self-Generation

MEA*AF*PRQ*200*KH***43	Self-Generation Applied – Intermediate Peak
QTY*QB*0*KH	True-Up
MEA*AF*PRQ*0*KH***41	True-Up – Off Peak
QTY*QB*1500*KH	True-Up
MEA*AF*PRQ*1500*KH***42	True-Up – On Peak
QTY*QB*0*KH	True-Up
MEA*AF*PRQ*0*KH***43	True-Up – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**Maryland (BGE) - Examples of PTD\*BJ Loop for Aggregate Net Energy Metering (ANEM), Non-TOU**

**Example #1** – Parent Host Net Metered Account, No Beginning Bank, No Self-generation applied from Starting Bank, Excess Generation Transferred to 1 Child Account, Remaining Banked

**Parent Host Account**

- Starting Bank = 0 kWh
- Net Generation = 300 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred to Child Account = 200 kWh
- Ending Bank = 100 kWh

**PTD\*BB = 0**

**PTD\*SU = 300 Net Generation**

**PTD\*PM = 300 Net Generation**

**PTD\*BJ (QH) = 0 Starting Bank**

**PTD\*BJ (79) = 0 Self-generation Applied from Starting Bank**

**PTD\*BJ (78) = 200 Net Transferred Out**

**PTD\*BJ (QE) = 100 Banked**

**0 Starting Bank + 300 Net Generation - 200 Net Transferred -100 Ending Bank = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*87*300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*300*KH	<b>Generation</b>
MEA*AA*PRQ*300*KH*4300*4000*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*0*KH	<b>Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied From Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied From Starting Bank – Total Non TOU
QTY*78*200*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*100*KH	<b>Ending Bank</b>
MEA*AF*PRQ*100*KH***51	Ending Bank – Total Non TOU

**Child Account – Not Net Metered**

- Consumption = 200 kWh
- Generation Transferred In = 200 kWh
- Billed Consumption – 0 kWh

**PTD\*BB = 0 Billed Consumption****PTD\*SU = 200 Net Consumption****PTD\*PM = 200 Net Consumption****PTD\*BJ (77) = 200 Generation Transferred In****300 Net Consumption - 200 Net Transferred In = PTD\*BB Loop of 100 kWh Billed**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*200*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*200*KH	<b>Consumption</b>
MEA*AA*PRQ*200*KH*20000*20200*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*200*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred In – Total Non TOU

*Non-TOU reporting only net kWh (BGE)*

*Example #2 – Parent Host Net Metered Account, Beginning Bank, No Self-generation applied from Starting Bank, Excess Generation Transferred to 1 Child Account, Remaining Banked*

#### Parent Host Account

- Starting Bank = 50 kWh
- Net Generation = 300 kWh
- Net Generation Available = 350 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred to Child Account = 200 kWh
- Ending Bank = 150 kWh

**PTD\*BB = 0**

**PTD\*SU = 300 Net Generation**

**PTD\*PM = 300 Net Generation**

**PTD\*BJ (QH) = 50 Starting Bank**

**PTD\*BJ (79) = 0 Self-generation Applied from Starting Bank**

**PTD\*BJ (78) = 200 Net Transferred Out**

**PTD\*BJ (QE) = 150 Banked**

**50 Starting Bank + 300 Net Generation - 200 Net Transferred -150 Ending Bank = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*87*300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*300*KH	<b>Generation</b>
MEA*AA*PRQ*300*KH*4600*4300*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*50*KH	<b>Starting Bank</b>
MEA*AF*PRQ*50*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied From Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied From Starting Bank – Total Non TOU
QTY*78*200*KH	<b>Generation Transferred Out</b>
MEA*AF*PRO*200*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*150*KH	<b>Ending Bank</b>
MEA*AF*PRQ*150*KH***51	Ending Bank – Total Non TOU

**Child Account – Not Net Metered**

- Consumption = 200 kWh
- Generation Transferred In = 200 kWh
- Billed Consumption – 0 kWh

**PTD\*BB = 0 Billed Consumption****PTD\*SU = 200 Net Consumption****PTD\*PM = 200 Net Consumption****PTD\*BJ (77) = 200 Generation Transferred In****200 Net Consumption - 200 Net Transferred In = PTD\*BB Loop of 0 kWh Billed**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*200*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*200*KH	<b>Consumption</b>
MEA*AA*PRQ*200*KH*20000*20200*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*200*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred In – Total Non TOU

*Non-TOU reporting only net kWh (BGE)*

*Example #3 – Parent Host Net Metered Account, Beginning Bank, No Self-generation applied from Starting Bank, All Excess Generation/Banked kWh Transferred to 1 Child Account, No Ending Bank*

**Parent Host Account**

- Starting Bank = 50 kWh
- Net Generation = 150 kWh
- Net Generation Available = 200 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred to Child Account = 200 kWh
- Ending Bank = 0 kWh

**PTD\*BB = 0****PTD\*SU = 150 Net Generation****PTD\*PM = 150 Net Generation****PTD\*BJ (QH) = 50 Starting Bank****PTD\*BJ (79) = 0 Self-generation Applied from Starting Bank****PTD\*BJ (78) = 200 Net Transferred Out****PTD\*BJ (QE) = 0 Ending Bank**

**50 Starting Bank + 150 Net Generation - 200 Net Transferred - 0 Ending Bank = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*87*150*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*150*KH	<b>Generation</b>
MEA*AA*PRQ*150*KH*12450*12300*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*50*KH	<b>Starting Bank</b>
MEA*AF*PRQ*50*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied From Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied From Starting Bank – Total Non TOU
QTY*78*200*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*0*KH	<b>Ending Bank</b>
MEA*AF*PRQ*0*KH***51	Ending Bank – Total Non TOU

**Child Account – Not Net Metered**

- Consumption = 300 kWh
- Generation Transferred In = 200 kWh
- Billed Consumption – 100 kWh

**PTD\*BB = 100 Billed Consumption****PTD\*SU = 300 Net Consumption****PTD\*PM = 300 Net Consumption****PTD\*BJ (77) = 200 Generation Transferred In****300 Net Consumption - 200 Net Transferred In = PTD\*BB Loop of 100 kWh Billed**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*100*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*300*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*300*KH	<b>Consumption</b>
MEA*AA*PRQ*300*KH*20000*20300*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*200*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred In – Total Non TOU

*Non-TOU reporting only net kWh (BGE)*

*Example #4 – Parent Host Generation Only Account, Beginning Bank, No Self-generation applied from Starting Bank. Child Account #1 Net Metered with Bank, Child Account #2 Net Metered without Bank.*

#### Parent Host Account

- Starting Bank = 1,500 kWh
- Generation = 8,000 kWh
- Net Generation Available = 9,500 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred to Child Account #1 = 3,200 kWh
- Generation Transferred to Child Account #2 = 3,300 kWh
- Ending Bank = 3,000 kWh

**PTD\*BB = 0**

**PTD\*SU = 8,000 Net Generation**

**PTD\*PM = 8,000 Net Generation**

**PTD\*BJ (QH) = 1,500 Starting Bank**

**PTD\*BJ (79) = 0 Self-generation Applied from Starting Bank**

**PTD\*BJ (78) = 6,500 Net Transferred Out**

**PTD\*BJ (QE) = 3,000 Ending Bank**

**1,500 Starting Bank + 8,000 Net Generation – 6,500 Net Transferred – 3,000 Ending Bank = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*87*8000*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*8000*KH	<b>Generation</b>
MEA*AA*PRQ*8000*KH*28300*20300*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*1500*KH	<b>Starting Bank</b>
MEA*AF*PRQ*1500*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied From Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied From Starting Bank – Total Non TOU
QTY*78*6500*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*6500*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*3000*KH	<b>Ending Bank</b>
MEA*AF*PRQ*3000*KH***51	Ending Bank – Total Non TOU

**Child Account #1– Net Metered with Starting Bank (BGE Net Metered Child Accounts retain their OWN excess generation, carried over to the following month. It is NOT transferred out to the Total Generation for the family during the period. BGE Net Metered Child must first exhaust all of its own generation before receiving any generation from the Parent Host)**

- Starting Bank = 500 kWh
- Net Consumption = 3,700 kWh
- Self-generation applied from Starting Bank = 500 kWh
- Generation Transferred In = 3,200 kWh
- Ending Bank = 0 kWh

**PTD\*BB = 0**

**PTD\*SU = 3,700 Net Consumption**

**PTD\*PM = 3,700 Net Consumption**

**PTD\*BJ (QH) = 500 Starting Bank**

**PTD\*BJ (79) = 500 Self-generation Applied from Starting Bank**

**PTD\*BJ (77) = 3,200 Net Transferred In**

**PTD\*BJ (QE) = 0 Ending Bank**

**500 Starting Bank - 3,700 Net Consumption + 3,200 Net Transferred In – 0 Ending Bank = PTD\*BB  
Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*DI*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*3700*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*3700*KH	<b>Consumption</b>
MEA*AA*PRQ*3700*KH*20000*23700*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*500*KH	<b>Starting Bank</b>
MEA*AF*PRQ*500*KH***51	Starting Bank – Total Non TOU
QTY*79*500*KH	<b>Self-generation Applied From Starting Bank</b>
MEA*AF*PRQ*500*KH***51	Self-generation Applied From Starting Bank – Total Non TOU
QTY*77*3200*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*3200*KH***51	Generation Transferred In – Total Non TOU
QTY*QE*0*KH	<b>Ending Bank</b>
MEA*AF*PRQ*0*KH***51	Ending Bank – Total Non TOU

**Child Account #2– Net Metered without Starting Bank or Ending Bank**

- Starting Bank = 0 kWh
- Net Consumption = 3,300 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred In = 3,300 kWh
- Ending Bank = 0 kWh

**PTD\*BB = 0**

**PTD\*SU = 3,300 Net Consumption**

**PTD\*PM = 3,300 Net Consumption**

**PTD\*BJ (QH) = 0 Starting Bank**

**PTD\*BJ (79) = 0 Self-generation Applied from Starting Bank**

**PTD\*BJ (77) = 3,300 Net Transferred In**

**PTD\*BJ (QE) = 0 Ending Bank**

**0 Starting Bank - 3,300 Net Consumption + 3,300 Net Transferred In – 0 Ending Bank = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*3300*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*3300*KH	<b>Consumption</b>
MEA*AA*PRQ*3300*KH*40000*43300*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*0*KH	<b>Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied From Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied From Starting Bank – Total Non TOU
QTY*77*3300*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*3300*KH***51	Generation Transferred In – Total Non TOU
QTY*QE*0*KH	<b>Ending Bank</b>
MEA*AF*PRQ*0*KH***51	Ending Bank – Total Non TOU

*Non-TOU reporting only net kWh (BGE)*

*Example #5 – Parent Host Net Metered Account, Beginning Bank, No Self-generation applied from Starting Bank, Excess Generation Transferred to 1 Child Account with Multiple Meters, Remaining Banked*

**Parent Host Account**

- Starting Bank = 50 kWh
- Net Generation = 300 kWh
- Net Generation Available = 350 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred to Child Account = 200 kWh
- Ending Bank = 150 kWh

**PTD\*BB = 0****PTD\*SU = 300 Net Generation****PTD\*PM = 300 Net Generation****PTD\*BJ (QH) = 50 Starting Bank****PTD\*BJ (79) = 0 Self-generation Applied from Starting Bank****PTD\*BJ (78) = 200 Net Transferred Out****PTD\*BJ (QE) = 150 Banked**

**50 Starting Bank + 300 Net Generation - 200 Net Transferred -150 Ending Bank = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*87*300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*300*KH	<b>Generation</b>
MEA*AA*PRQ*300*KH*4600*4300*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*50*KH	<b>Starting Bank</b>
MEA*AF*PRQ*50*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied From Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied From Starting Bank – Total Non TOU
QTY*78*200*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*150*KH	<b>Ending Bank</b>
MEA*AF*PRQ*150*KH***51	Ending Bank – Total Non TOU

**Child Account – Not Net Metered**

- Consumption = 200 kWh
- Generation Transferred In = 200 kWh
- Billed Consumption – 0 kWh

**PTD\*BB = 0 Billed Consumption**

**PTD\*SU = 200 Net Consumption**

**PTD\*PM = 200 Net Consumption**

**PTD\*BJ = 200 Generation Transferred In**

**200 Net Consumption - 200 Net Transferred In = PTD\*BB Loop of 0 kWh Billed**

**Two meters -Meter 1111111 – Consumption 125, Meter 2222222 – Consumption 75**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*200*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*125*KH	<b>Consumption</b>
MEA*AA*PRQ*125*KH*20000*20125*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*22222222	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*75*KH	<b>Consumption</b>
MEA*AA*PRQ*75*KH*20000*20075*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*200*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred In – Totalizer (Non TOU)

*Non-TOU reporting only net kWh (BGE)*

**Example #6** – Parent Host Net Metered Account, example for end of year net metering True-Up of excess generation. (Showing Parent Host accounts only)

**Parent Host Account – April reporting month (Ending bank true up month).**

NOTE: During True-Up for TOU, if one TOU peak contains excess generation, the QTY\*QB must be sent for all TOU's even when others contain 0 kWh. For non-TOU, if there is no excess generation during the True-Up event, the QTY\*QB will NOT be sent.

- Starting Bank = 0 kWh
- Net Generation = 300 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred to Child Account = 200 kWh
- True-Up = 100 kWh
- Ending Bank = 0 kWh

**PTD\*BB = 0**

**PTD\*SU = 300 Net Generation**

**PTD\*PM = 300 Net Generation**

**PTD\*BJ (QH) = 0 Starting Bank**

**PTD\*BJ (79) = 0 Self-generation Applied from Starting Bank**

**PTD\*BJ (78) = 200 Net Transferred Out**

**PTD\*BJ (QB) = 100 True-up (Cashed Out)**

**PTD\*BJ (QE) = 0 Banked (Trued up, will NOT appear in May's Starting Bank)**

**0 Starting Bank + 300 Net Generation - 200 Net Transferred -100 Trued up = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160401	Start period
DTM*151*20160430	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160401	Start period
DTM*151*20160430	End period
QTY*87*300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160401	Start period
DTM*151*20160430	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*300*KH	<b>Generation</b>
MEA*AA*PRQ*300*KH*4300*4000*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160401	Start period
DTM*151*20160430	End period
QTY*QH*0*KH	<b>Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied From Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied From Starting Bank – Total Non TOU
QTY*78*200*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred Out – Total Non TOU
QTY*QB*100*KH	<b>True-Up</b>
MEA*AF*PRQ*100*KH***51	True-Up – Total Non TOU
QTY*QE*0*KH	<b>Ending Bank</b>
MEA*AF*PRQ*0*KH***51	Ending Bank – Total Non TOU

**Parent Host Account – May reporting month (Ending bank from April trued up, no Starting Bank)**

- Starting Bank = 0 kWh
- Net Generation = 300 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred to Child Account = 100 kWh
- Ending Bank = 200 kWh

**PTD\*BB = 0****PTD\*SU = 300 Net Generation****PTD\*PM = 300 Net Generation****PTD\*BJ (QH) = 0 Starting Bank****PTD\*BJ (79) = 0 Self-generation Applied from Starting Bank****PTD\*BJ (78) = 100 Net Transferred Out****PTD\*BJ (QE) = 200 Banked****0 Starting Bank + 300 Net Generation - 100 Net Transferred -200 Ending Bank = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160430	Start period
DTM*151*20160530	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160430	Start period
DTM*151*20160530	End period
QTY*87*300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160430	Start period
DTM*151*20160530	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*300*KH	<b>Generation</b>
MEA*AA*PRQ*300*KH*4300*4000*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160430	Start period
DTM*151*20160530	End period
QTY*QH*0*KH	<b>Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied From Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied From Starting Bank – Total Non TOU
QTY*78*100*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*100*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*200*KH	<b>Ending Bank</b>
MEA*AF*PRQ*200*KH***51	Ending Bank – Total Non TOU

*Non-TOU reporting consumption kWh (BGE)*

**Example #7** – Parent Host Net Metered Account, Beginning Bank, Records consumption for current billing period, Self-generation applied from Starting Bank, Part of Reduced Excess Generation Transferred to 1 Child Account, Remaining Generation Banked

#### Parent Host Account

- Starting Bank = 1000 kWh
- Net Consumption = 200 kWh
- Self-generation applied from Starting Bank = 200 kWh
- Adjusted Net Generation Available = 800 kWh
- Generation Transferred to Child Account = 300 kWh
- Ending Bank = 500 kWh

**PTD\*BB = 0**

**PTD\*SU = 200 Net Consumption**

**PTD\*PM = 200 Net Consumption**

**PTD\*BJ (QH) = 1000 Starting Bank**

**PTD\*BJ (79) = 200 Self-generation Applied from Starting Bank**

**PTD\*BJ (78) = 300 Net Transferred Out**

**PTD\*BJ (QE) = 500 Ending Bank**

**1000 Starting Bank – 200 Self-generation applied - 300 Net Transferred Out - 500 Ending Bank =**  
**PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*200*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*200*KH	<b>Generation</b>
MEA*AA*PRQ*200*KH*12450*12650*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*1000*KH	<b>Starting Bank</b>
MEA*AF*PRQ*1000*KH***51	Starting Bank – Total Non TOU
QTY*79*200*KH	<b>Self-generation Applied From Starting Bank</b>
MEA*AF*PRQ*200*KH***51	Self-generation Applied From Starting Bank – Total Non TOU
QTY*78*300*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*300*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*500*KH	<b>Ending Bank</b>
MEA*AF*PRQ*500*KH***51	Ending Bank – Total Non TOU

**Child Account – Not Net Metered**

- Consumption = 300 kWh
- Generation Transferred In = 300 kWh
- Billed Consumption – 0 kWh

**PTD\*BB = 0 Billed Consumption****PTD\*SU = 300 Net Consumption****PTD\*PM = 300 Net Consumption****PTD\*BJ (77) = 300 Generation Transferred In****300 Net Consumption - 300 Net Transferred In = PTD\*BB Loop of 0 kWh Billed**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*300*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*300*KH	<b>Consumption</b>
MEA*AA*PRQ*300*KH*20000*20300*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*300*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*300*KH***51	Generation Transferred In – Total Non TOU

**Maryland (PHI/PE) - Examples of PTD\*BJ Loop for Aggregate Net Energy Metering (ANEM), Non-TOU**

*Non-TOU with Separate Consumption & Generation (PHI & FirstEnergy)*

**Example #1** – Parent Host Net Metered Account, No Beginning Bank, No Self-generation applied from Starting Bank, Excess Generation Transferred to 1 Child Account, Remaining Banked

**Parent Host Account**

- Starting Bank = 0 kWh
- Consumption = 1,000 kWh
- Generation = 1,300 kWh
- Net Generation Available = 300 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred to Child Account = 200 kWh
- Ending Bank = 100 kWh

**PTD\*BB = 0**

**PTD\*SU = 300 Net Generation**

**PTD\*PM = 1000 Consumption**

**PTD\*PM = 1300 Generation**

**PTD\*BJ (QH) = 0 Starting Bank**

**PTD\*BJ (79) = 0 Self-generation Applied from Starting Bank**

**PTD\*BJ (78) = 200 Net Transferred Out**

**PTD\*BJ (QE) = 100 Banked**

**0 Starting Bank + 300 Net Generation - 200 Net Transferred -100 Ending Bank = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*87*300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*1000*KH	<b>Consumption</b>
MEA*AA*PRQ*1000*KH*20000*21000*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*1300*KH	<b>Generation</b>
MEA*AA*PRQ*1300*KH*4300*3000*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*0*KH	<b>Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied from Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied from Starting Bank – Total Non TOU
QTY*78*200*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*100*KH	<b>Ending Bank</b>
MEA*AF*PRQ*100*KH***51	Ending Bank – Total Non TOU

**Child Account – Not Net Metered**

- Consumption = 300 kWh
- Generation Transferred In = 200 kWh
- Billed Consumption – 100 kWh

**PTD\*BB = 0 Billed Consumption**

**PTD\*SU = 200 Consumption**

**PTD\*PM = 200 Consumption**

**PTD\*BJ = 200 Generation Transferred In**

**200 Net Consumption - 200 Net Transferred In = PTD\*BB Loop of 0 kWh Billed**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*200*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*200*KH	<b>Consumption</b>
MEA*AA*PRQ*200*KH*20000*20200*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*200*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred In – Total Non TOU

*Non-TOU with Separate Consumption & Generation (PHI & FirstEnergy)*

**Example #2** – Parent Host Net Metered Account, Beginning Bank, No Self-generation applied from Starting Bank, Excess Generation Transferred to 1 Child Account, Remaining Banked

**Parent Host Account**

- Starting Bank = 50 kWh
- Consumption = 1,000 kWh
- Generation = 1,300 kWh
- Net Generation Available = 350 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred to Child Account = 200 kWh
- Ending Bank = 150 kWh

**PTD\*BB = 0**

**PTD\*SU = 300 Net Generation**

**PTD\*PM = 1000 Consumption**

**PTD\*PM = 1300 Generation**

**PTD\*BJ (QH) = 50 Starting Bank**

**PTD\*BJ (79) = 0 Self Generation Applied from Starting Bank**

**PTD\*BJ (78) = 200 Net Transferred Out**

**PTD\*BJ (QE) = 150 Banked**

**50 Starting Bank + 300 Net Generation - 200 Net Transferred -150 Ending Bank = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*87*300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*1000*KH	<b>Consumption</b>
MEA*AA*PRQ*1000*KH*20000*21000*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*1300*KH	<b>Generation</b>
MEA*AA*PRQ*1300*KH*4600*3300*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*50*KH	<b>Starting Bank</b>
MEA*AF*PRQ*50*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied from Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied from Starting Bank – Total Non TOU
QTY*78*200*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*150*KH	<b>Ending Bank</b>
MEA*AF*PRQ*150*KH***51	Ending Bank – Total Non TOU

**Child Account – Not Net Metered**

- Consumption = 200 kWh
- Generation Transferred In = 200 kWh
- Billed Consumption – 0 kWh

**PTD\*BB = 0 Billed Consumption**

**PTD\*SU = 200 Consumption**

**PTD\*PM = 200 Consumption**

**PTD\*BJ = 200 Generation Transferred In**

**200 Net Consumption - 200 Net Transferred In = PTD\*BB Loop of 0 kWh Billed**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*200*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*200*KH	<b>Consumption</b>
MEA*AA*PRQ*200*KH*20000*20200*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*200*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred In – Total Non TOU

*Non-TOU with Separate Consumption & Generation (PHI & FirstEnergy)*

**Example #3** – Parent Host Net Metered Account, Beginning Bank, No Self-generation applied from Starting Bank, All Excess Generation/Banked kWh Transferred to 1 Child Account, No Ending Bank

**Parent Host Account**

- Starting Bank = 50 kWh
- Consumption = 1,000 kWh
- Generation = 1,150 kWh
- Net Generation Available = 200 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred to Child Account = 200 kWh
- Ending Bank = 0 kWh

**PTD\*BB = 0**

**PTD\*SU = 150 Net Generation**

**PTD\*PM = 1000 Consumption**

**PTD\*PM = 1150 Generation**

**PTD\*BJ (QH) = 50 Starting Bank**

**PTD\*BJ (79) = 0 Self Generation Applied from Starting Bank**

**PTD\*BJ (78) = 200 Net Transferred Out**

**PTD\*BJ (QE) = 0 Ending Bank**

**50 Starting Bank + 150 Net Generation - 200 Net Transferred - 0 Ending Bank = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*87*150*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*1000*KH	<b>Consumption</b>
MEA*AA*PRQ*1000*KH*20000*21000*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*1150*KH	<b>Generation</b>
MEA*AA*PRQ*1150*KH*13450*12300*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*50*KH	<b>Starting Bank</b>
MEA*AF*PRQ*50*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied from Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied from Starting Bank – Total Non TOU
QTY*78*200*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*0*KH	<b>Ending Bank</b>
MEA*AF*PRQ*0*KH***51	Ending Bank – Total Non TOU

**Child Account – Not Net Metered**

- Consumption = 300 kWh
- Generation Transferred In = 200 kWh
- Billed Consumption – 100 kWh

**PTD\*BB = 100 Billed Consumption****PTD\*SU = 300 Consumption****PTD\*PM = 300 Consumption****PTD\*BJ = 200 Generation Transferred In****300 Net Consumption - 200 Net Transferred In = PTD\*BB Loop of 100 kWh Billed**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*100*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*300*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*300*KH	<b>Consumption</b>
MEA*AA*PRQ*300*KH*20000*20300*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*200*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred In – Total Non TOU

*Non-TOU with Separate Consumption & Generation (PHI & FirstEnergy)*

**Example #4** – Parent Host Net Metered Account, Beginning Bank, No Self-generation applied from Starting Bank, Excess Generation Transferred to 1 Child Account with Multiple Meters, Remaining Banked

**Parent Host Account**

- Starting Bank = 50 kWh
- Consumption = 1,000 kWh
- Generation = 1,300 kWh
- Net Generation Available = 350 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred to Child Account = 200 kWh
- Ending Bank = 150 kWh

**PTD\*BB = 0**

**PTD\*SU = 300 Net Generation**

**PTD\*PM = 1000 Consumption**

**PTD\*PM = 1300 Generation**

**PTD\*BJ (QH) = 50 Starting Bank**

**PTD\*BJ (79) = 0 Self Generation Applied from Starting Bank**

**PTD\*BJ (78) = 200 Net Transferred Out**

**PTD\*BJ (QE) = 150 Banked**

**50 Starting Bank + 300 Net Generation - 200 Net Transferred -150 Ending Bank = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*87*300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*1000*KH	<b>Consumption</b>
MEA*AA*PRQ*1000*KH*20000*21000*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*1300*KH	<b>Generation</b>
MEA*AA*PRQ*1300*KH*4600*3300*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*50*KH	<b>Starting Bank</b>
MEA*AF*PRQ*50*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied from Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied from Starting Bank – Total Non TOU
QTY*78*200*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*150*KH	<b>Ending Bank</b>
MEA*AF*PRQ*150*KH***51	Ending Bank – Total Non TOU

**Child Account – Not Net Metered**

- Consumption = 200 kWh
- Generation Transferred In = 200 kWh
- Billed Consumption – 0 kWh

**PTD\*BB = 0 Billed Consumption****PTD\*SU = 200 Net Consumption****PTD\*PM = 125 Net Consumption (Meter 11111111)****PTD\*PM = 75 Net Consumption (Meter 22222222)****PTD\*BJ = 200 Generation Transferred In****200 Net Consumption - 200 Net Transferred In = PTD\*BB Loop of 0 kWh Billed****Two meters -Meter 11111111 – Consumption 125, Meter 22222222 – Consumption 75**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*200*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*125*KH	<b>Consumption</b>
MEA*AA*PRQ*125*KH*20000*20125*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*22222222	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*75*KH	<b>Consumption</b>
MEA*AA*PRQ*75*KH*20000*20075*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*200*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred In – Totalizer (Non TOU)

*Non-TOU reporting Separate Consumption & Generation (PHI & FirstEnergy)*

**Example #5** – Parent Host Net Metered Account, Beginning Bank, Records consumption for current billing period, Self-generation applied from Starting Bank, Part of Reduced Excess Generation Transferred to 1 Child Account, Remaining Generation Banked

**Parent Host Account**

- Starting Bank = 1000 kWh
- Consumption = 400 kWh
- Generation = 200 kWh
- Self-generation applied from Starting Bank = 200 kWh
- Adjusted Net Generation Available = 800 kWh
- Generation Transferred to Child Account = 300 kWh
- Ending Bank = 500 kWh

**PTD\*BB = 0**

**PTD\*SU = 200 Net Consumption**

**PTD\*PM = 400 Consumption**

**PTD\*PM = 200 Generation**

**PTD\*BJ (QH) = 1000 Starting Bank**

**PTD\*BJ (79) = 200 Self-generation Applied from Starting Bank**

**PTD\*BJ (78) = 300 Net Transferred Out**

**PTD\*BJ (QE) = 500 Ending Bank**

**200 Net Consumption - 200 Self-generation applied = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*200*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160401	Start period
DTM*151*20160430	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*400*KH	<b>Consumption</b>
MEA*AA*PRQ*400*KH*20000*20400*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*200*KH	<b>Generation</b>
MEA*AA*PRQ*200*KH*12450*12650*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*1000*KH	<b>Starting Bank</b>
MEA*AF*PRQ*1000*KH***51	Starting Bank – Total Non TOU
QTY*79*200*KH	<b>Self-generation Applied from Starting Bank</b>
MEA*AF*PRQ*200*KH***51	Self-generation Applied from Starting Bank – Total Non TOU
QTY*78*300*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*300*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*500*KH	<b>Ending Bank</b>
MEA*AF*PRQ*500*KH***51	Ending Bank – Total Non TOU

**Child Account – Not Net Metered**

- Consumption = 300 kWh
- Generation Transferred In = 300 kWh
- Billed Consumption – 0 kWh

**PTD\*BB = 0 Billed Consumption**

**PTD\*SU = 300 Net Consumption**

**PTD\*PM = 300 Net Consumption**

**PTD\*BJ (77) = 300 Generation Transferred In**

**300 Net Consumption - 300 Net Transferred In = PTD\*BB Loop of 0 kWh Billed**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*300*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*300*KH	<b>Consumption</b>
MEA*AA*PRQ*300*KH*20000*20300*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*300*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*300*KH***51	Generation Transferred In – Total Non TOU

*Non-TOU with Separate Consumption & Generation*

**Example #6** – Parent Host Generation Only Account, Two Parent Accounts with Generation, Two Child Accounts, remaining banked. **(PHI only scenario, neither BGE nor FirstEnergy use Parent accounts)**

**Parent Host Account**

- Starting Bank = 1,500 kWh
- Generation = 8,000 kWh
- Generation Transferred In from 1<sup>st</sup> Parent Account = 1000 kWh
- Net Generation Available = 10,500 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred Out to 2<sup>nd</sup> Parent Account = 500 kWh
- Generation Transferred Out to 1<sup>st</sup> Child Account = 4,700 kWh
- Generation Transferred Out to 2<sup>nd</sup> Child Account = 4,300 kWh
- Ending Bank = 1,000 kWh

**PTD\*BB = 0**

**PTD\*SU = 8,000 Generation**

**PTD\*PM = 1,000 Consumption**

**PTD\*PM = 9,000 Generation**

**PTD\*BJ (QH) = 1,500 Starting Bank**

**PTD\*BJ (77) = 1,000 Net Transferred In (from Parent #1)**

**PTD\*BJ (79) = 0 Self Generation Applied from Starting Bank**

**PTD\*BJ (78) = 9,500 Net Transferred Out**

**PTD\*BJ (QE) = 1,000 Ending Bank**

**1,500 Starting Bank + 8,000 Net Generation + 1,000 Net Generation from 1<sup>st</sup> Parent – 500 Net Transferred to 2<sup>nd</sup> Parent – 4,700 Transferred to 1<sup>st</sup> Child – 4,300 Transferred to 2<sup>nd</sup> Child – 1,000 Ending Bank = PTD\*BB Loop 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*87*8000*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*1000*KH	<b>Consumption</b>
MEA*AA*PRQ*1000*KH*28300*29300*51	Total generation, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*9000*KH	<b>Generation</b>
MEA*AA*PRQ*9000*KH*29300*20300*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QH*1500*KH	<b>Starting Bank</b>
MEA*AF*PRQ*1500*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied from Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied from Starting Bank – Total Non TOU

QTY*77*1000*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*1000*KH***51	Generation Transferred In – Totalizer (Non TOU)
QTY*78*9500*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*500*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*1000*KH	<b>Ending Bank</b>
MEA*AF*PRQ*1000*KH***51	Ending Bank – Total Non TOU

**Parent Account #1 – PHI parent account's excess generation is transferred out to the total net generation available for the family during the reporting period. Does not utilize any starting bank or ending bank to carry over to itself for use during the following month.**

- Consumption = 2,000 kWh
- Generation = 3,000 kWh
- Net Generation Available = 1,000 kWh
- Generation Transferred In = 0 kWh
- Generation Transferred Out = 1,000 kWh

**PTD\*BB = 0**

**PTD\*SU = 1,000 Net Generation**

**PTD\*PM = 2,000 Consumption**

**PTD\*PM – 3,000 Generation**

**PTD\*BJ (77) = 0 Net Transferred In (from ParentHost)**

**PTD\*BJ (78) = 1,000 Net Transferred Out**

**1000 Net Generation – 1,000 Net Transferred = PTD\*BB Loop of 0**

**Total Generation Available for period is now – 10,500 (Parent Host 9,500 + 1<sup>st</sup> Parent 1,000)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*87*1000*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*2000*KH	<b>Consumption</b>
MEA*AA*PRQ*2000*KH*26300*28300*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*3000*KH	<b>Generation</b>
MEA*AA*PRQ*3000*KH*28300*25300*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*0*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*0*KH***51	Generation Transferred In – Totalizer (Non TOU)
QTY*78*1000*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*1000*KH***51	Generation Transferred Out – Total Non TOU

**Parent Account #2 - Does not utilize any starting bank or ending bank to carry over to itself for use during the following month.**

- Consumption = 2,500 kWh
- Generation = 2,000 kWh
- Generation Transferred In = 500 kWh
- Generation Transferred Out = 0 kWh

**PTD\*BB = 0**

**PTD\*SU = 500 Net Consumption**

**PTD\*PM = 2,500 Consumption**

**PTD\*PM – 2,000 Generation**

**PTD\*BJ (77) = 500 Net Generation Transferred In**

**PTD\*BJ (78) = 1,000 Net Transferred Out**

**500 Net Consumption – 500 Net Transferred = PTD\*BB Loop of 0**

**Total Generation Available for period is now – 10,000 (Parent Host 9,500 + 1<sup>st</sup> Parent 1,000 – 2<sup>nd</sup> Parent 500)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*2500*KH	<b>Consumption</b>
MEA*AA*PRQ*2500*KH*26300*28800*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*2000*KH	<b>Generation</b>
MEA*AA*PRQ*3000*KH*28800*26800*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*500*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*500*KH***51	Generation Transferred In – Total Non TOU
QTY*78*0*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*0*KH***51	Generation Transferred Out – Total Non TOU

**Child Account #1**

- Consumption = 4,700 kWh
- Generation Transferred In = 4,700 kWh

**PTD\*BB = 0**

**PTD\*SU = 4,700 Consumption**

**PTD\*PM = 4,700 Consumption**

**PTD\*BJ (77) = 4,700 Transferred In**

**4,700 Consumption - 4,700 Transferred In – 0 Ending Bank = PTD\*BB Loop of 0**

**Total Generation Available for period is now – 5,300 (Parent Host 9,500 + Parent1 1,000 – Parent2 500 – Child1 4700)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*4700*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*4700*KH	<b>Consumption</b>
MEA*AA*PRQ*4700*KH*20000*24700*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*4700*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*4700*KH***51	Generation Transferred In – Total Non TOU

**Child Account #2**

- Consumption = 4,300 kWh
- Generation Transferred In = 4,300 kWh

**PTD\*BB = 0**

**PTD\*SU = 4,300 Net Consumption**

**PTD\*PM = 4,300 Consumption**

**PTD\*BJ (77) = 4,300 Net Transferred In**

**4,300 Consumption - 4,300 Transferred In – 0 Ending Bank = PTD\*BB Loop of 0**

**Total Generation Ending Bank on Parent Host = 1,000 (Parent Host 9,500 + 1<sup>st</sup> Parent 1,000 – 2<sup>nd</sup> Parent 500 – 1<sup>st</sup> Child 4700 – 2<sup>nd</sup> Child 4300)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*QD*4300*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*4300*KH	<b>Consumption</b>
MEA*AA*PRQ*4300*KH*40000*44300*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160101	Start period
DTM*151*20160131	End period
QTY*77*4300*KH	<b>Generation Transferred In</b>
MEA*AF*PRQ*4300*KH***51	Generation Transferred In – Total Non TOU

*Non-TOU reporting Separate Consumption & Generation (PHI & FirstEnergy)*

**Example #7** – Parent Host Net Metered Account, example for end of year net metering True-Up of excess generation. (Showing Parent Host accounts only)

**Parent Host Account - April reporting month (Ending bank true up month)**

NOTE: During True-Up for TOU, if one TOU peak contains excess generation, the QTY\*QB must be sent for all TOU's even when others contain 0 kWh. For non-TOU, if there is no excess generation during the True-Up event, the QTY\*QB will NOT be sent.

- Starting Bank = 0 kWh
- Consumption = 1,000 kWh
- Generation = 1,300 kWh
- Net Generation Available = 300 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred to Child Account = 200 kWh
- True-Up = 100 kWh
- Ending Bank = 0 kWh

**PTD\*BB = 0**

**PTD\*SU = 300 Net Generation**

**PTD\*PM = 1000 Consumption**

**PTD\*PM = 1300 Generation**

**PTD\*BJ (QH) = 0 Starting Bank**

**PTD\*BJ (79) = 0 Self Generation Applied from Starting Bank**

**PTD\*BJ (78) = 200 Net Transferred Out**

**PTD\*BJ (QB) = 100 True-Up (Cashed Out)**

**PTD\*BJ (QE) = 0 Banked**

**0 Starting Bank + 300 Net Generation - 200 Net Transferred -100 True-Up= PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160401	Start period
DTM*151*20160430	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160401	Start period
DTM*151*20160430	End period
QTY*87*300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160401	Start period
DTM*151*20160430	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*1000*KH	<b>Consumption</b>
MEA*AA*PRQ*1000*KH*20000*21000*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160401	Start period
DTM*151*20160430	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*1300*KH	<b>Generation</b>
MEA*AA*PRQ*1300*KH*4300*3000*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160401	Start period
DTM*151*20160430	End period
QTY*QH*0*KH	<b>Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied from Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied from Starting Bank – Total Non TOU
QTY*78*200*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred Out – Total Non TOU
QTY*QB*100*KH	<b>True Up</b>
MEA*AF*PRQ*100*KH***51	True Up – Total Non TOU

QTY*QE*0*KH	<b>Ending Bank</b>
MEA*AF*PRQ*0*KH***51	Ending Bank – Total Non TOU

**Parent Host Account – May reporting month (Ending bank from April trued up, no Starting Bank)**

- Starting Bank = 0 kWh
- Consumption = 1,000 kWh
- Generation = 1,300 kWh
- Net Generation Available = 300 kWh
- Self-generation applied from Starting Bank = 0 kWh
- Generation Transferred to Child Account = 200 kWh
- Ending Bank = 100 kWh

**PTD\*BB = 0**

**PTD\*SU = 300 Net Generation**

**PTD\*PM = 1000 Consumption**

**PTD\*PM = 1300 Generation**

**PTD\*BJ (QH) = 0 Starting Bank (Bank Trued up, does not match prior month's ending bank)**

**PTD\*BJ (79) = 0 Self Generation Applied from Starting Bank**

**PTD\*BJ (78) = 200 Net Transferred Out**

**PTD\*BJ (QE) = 100 Banked**

**0 Starting Bank + 300 Net Generation - 200 Net Transferred -100 Ending Bank = PTD\*BB Loop of 0**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160430	Start period
DTM*151*20160531	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160430	Start period
DTM*151*20160531	End period
QTY*87*300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160430	Start period
DTM*151*20160531	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*QD*1000*KH	<b>Consumption</b>
MEA*AA*PRQ*1000*KH*20000*21000*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160430	Start period
DTM*151*20160531	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*6.0	Number of dials or digits
QTY*87*1300*KH	<b>Generation</b>
MEA*AA*PRQ*1300*KH*4300*3000*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160430	Start period
DTM*151*20160531	End period
QTY*QH*0*KH	<b>Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Starting Bank – Total Non TOU
QTY*79*0*KH	<b>Self-generation Applied from Starting Bank</b>
MEA*AF*PRQ*0*KH***51	Self-generation Applied from Starting Bank – Total Non TOU
QTY*78*200*KH	<b>Generation Transferred Out</b>
MEA*AF*PRQ*200*KH***51	Generation Transferred Out – Total Non TOU
QTY*QE*100*KH	<b>Ending Bank</b>
MEA*AF*PRQ*100*KH***51	Ending Bank – Total Non TOU

**Maryland (BGE) - Examples of PTD\*BJ Loop for Aggregate Net Energy Metering (ANEM), TOU**

**BGE Scenario A - Host is TOU, Child # 1 is Non-TOU, Child # 2 is TOU. Neither Child is net metered.**

**Parent Host Account**

Starting Banked amounts for Host

Off Peak -300 kWh

On Peak -500 kWh

Int Peak -400 kWh

Host's current usage for 04/05/16 to 05/04/16

Off Peak -50 kWh

On Peak -100 kWh

Int Peak -75 kWh

So the host now has the following excess generation to apply to his children:

-350 kWh from Off Peak

-600 kWh from On Peak

-475 kWh from Int Peak

Ending Banked amounts for Host

Off Peak 0 kWh

On Peak -325 kWh

Int Peak 0 kWh

**Child #1 (NON-TOU)**

Current usage for 04/05/16 to 05/04/16 is +400 kWh (350 kWh from Host's Off Peak and 50 kWh from Host's Int Peak applied)

**Child #2 (TOU)**

Current usage for 04/05/16 to 05/04/16

Off Peak +200 kWh (200 kwh from Host's On Peak applied)

On Peak +300 kWh (300 kWh from Host's Int Peak applied)

Int Peak +200 kWh (125 kWh from Host's Int Peak and 75 kWh from Host's On Peak applied)

Notes:

4. BGE applies generation from the host using Off Peak first, then Intermediate and lastly On Peak.
5. BGE applies generation to a child in the opposite order (On Peak first, then Intermediate and lastly Off Peak).

**Parent Account (Net Meter TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*225*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period

REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*50*KH	Generation - Off Peak
MEA*AA*PRQ*50*KH*0*0*41	Total generation, with begin/end readings
QTY*87*100*KH	Generation - On Peak
MEA*AA*PRQ*100*KH*0*0*42	Total consumption, with begin/end readings
QTY*87*75*KH	Generation - Intermediate Peak
MEA*AA*PRQ*75*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*300*KH	Starting Bank
MEA*AF*PRQ*300*KH***41	Starting Bank – Off Peak
QTY*QH*500*KH	Starting Bank
MEA*AF*PRQ*500*KH***42	Starting Bank – On Peak
QTY*QH*400*KH	Starting Bank
MEA*AF*PRQ*400*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*78*350*KH	Generation Transferred Out
MEA*AF*PRQ*350*KH***41	Generation Transferred Out – Off Peak
QTY*78*275*KH	Generation Transferred Out
MEA*AF*PRQ*275*KH***42	Generation Transferred Out – On Peak
QTY*78*475*KH	Generation Transferred Out
MEA*AF*PRQ*475*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*325*KH	Ending Bank
MEA*AF*PRQ*325*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**Child #1 (Non-TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*400*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*400*KH	Consumption
MEA*AA*PRQ*400*KH*20000*20400*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*400*KH	Generation Transferred In
MEA*AF*PRQ*400*KH***51	Generation Transferred In – Total Non TOU

**Child #2 (TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*700*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits

QTY*QD*200*KH	Consumption - Off Peak
MEA*AA*PRQ*200*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*300*KH	Consumption - On Peak
MEA*AA*PRQ*300*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
PTD*BJ	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***41	Generation Transferred In – Off Peak
QTY*77*300*KH	Generation Transferred In
MEA*AF*PRQ*300*KH***42	Generation Transferred In – On Peak
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***43	Generation Transferred In – Intermediate Peak

## BGE Scenario B - Host is TOU, Child # 1 is TOU, Child # 2 is Non-TOU

### Parent Host Account

Starting Banked amounts for Host

Off Peak -300 kWh

On Peak -500 kWh

Int Peak -400 kWh

Host's current usage for 04/05/16 to 05/04/16

Off Peak -50 kWh

On Peak -100 kWh

Int Peak -75 kWh

So the host now has the following excess generation to apply to his children:

-350 kWh from Off Peak

-600 kWh from On Peak

-475 kWh from Int Peak

Ending Banked amounts for Host

Off Peak 0 kWh

On Peak -325 kWh

Int Peak 0 kWh

### Child #1 (TOU)

Current usage for 04/05/16 to 05/04/16

Off Peak +200 kWh (200 kwh from Host's Int Peak applied)

On Peak +300 kWh (300 kWh from Host's Off Peak applied)

Int Peak +200 kWh (50 kWh from Host's Off Peak and 150 kWh from Host's Int Peak applied)

### Child #2 (NON-TOU)

Current usage for 04/05/16 to 05/04/16 is +400 kWh (125 kWh from Host's Int Peak and 275 kWh from Host's On Peak applied)

Notes:

4. BGE applies generation from the host using Off Peak first, then Intermediate and lastly On Peak.
5. BGE applies generation to a child in the opposite order (On Peak first, then Intermediate and lastly Off Peak).

**Parent Account (Net Meter TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*225*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*50*KH	Generation - Off Peak
MEA*AA*PRQ*50*KH*0*0*41	Total generation, with begin/end readings
QTY*87*100*KH	Generation - On Peak
MEA*AA*PRQ*100*KH*0*0*42	Total consumption, with begin/end readings
QTY*87*75*KH	Generation - Intermediate Peak
MEA*AA*PRQ*75*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*300*KH	Starting Bank
MEA*AF*PRQ*300*KH***41	Starting Bank – Off Peak
QTY*QH*500*KH	Starting Bank
MEA*AF*PRQ*500*KH***42	Starting Bank – On Peak
QTY*QH*400*KH	Starting Bank
MEA*AF*PRQ*400*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak

QTY*78*350*KH	Generation Transferred Out
MEA*AF*PRQ*350*KH***41	Generation Transferred Out – Off Peak
QTY*78*275*KH	Generation Transferred Out
MEA*AF*PRQ*275*KH***42	Generation Transferred Out – On Peak
QTY*78*475*KH	Generation Transferred Out
MEA*AF*PRQ*475*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*325*KH	Ending Bank
MEA*AF*PRQ*325*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

#### Child #1 (TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*700*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*200*KH	Consumption - Off Peak
MEA*AA*PRQ*200*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*300*KH	Consumption - On Peak
MEA*AA*PRQ*300*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop

DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***41	Generation Transferred In – Off Peak
QTY*77*300*KH	Generation Transferred In
MEA*AF*PRQ*300*KH***42	Generation Transferred In – On Peak
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***43	Generation Transferred In – Intermediate Peak

**Child #2 (Non-TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*400*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*400*KH	Consumption
MEA*AA*PRQ*400*KH*20000*20400*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*400*KH	Generation Transferred In
MEA*AF*PRQ*400*KH***51	Generation Transferred In – Total Non TOU

### BGE Scenario C - Host is TOU, Child # 1 is TOU, Child # 2 is TOU (Host's generation is exhausted on Child # 2)

#### Parent Host Account

Starting Banked amounts for Host

Off Peak -300 kWh

On Peak -500 kWh

Int Peak -400 kWh

Host's current usage for 04/05/16 to 05/04/16

Off Peak -50 kWh

On Peak -100 kWh

Int Peak -75 kWh

So the host now has the following excess generation to apply to his children:

-350 kWh from Off Peak

-600 kWh from On Peak

-475 kWh from Int Peak

Ending Banked amounts for Host

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

#### Child #1 (TOU)

Current usage for 04/05/16 to 05/04/16

Off Peak +200 kWh (200 kWh from Host's Int Peak applied)

On Peak +300 kWh (300 kWh from Host's Off Peak applied)

Int Peak +200 kWh (50 kWh from Host's Off Peak and 150 kWh from Host's Int Peak applied)

#### Child #2 (TOU)

Current usage for 04/05/16 to 05/04/16

Off Peak +300 kWh (Child will be billed for 300 kWh from Off Peak)

On Peak +500 kWh (125 kWh from Host's Int Peak applied and 375 kWh from Host's On Peak applied)

Int Peak +400 kWh (225 kWh from Host's On Peak applied; Child will be billed for 175 kWh from Int Peak)

Notes:

4. BGE applies generation from the host using Off Peak first, then Intermediate and lastly On Peak.
5. BGE applies generation to a child in the opposite order (On Peak first, then Intermediate and lastly Off Peak).

#### ParentHost Account (Net Meter TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*225*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop

DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*50*KH	Generation - Off Peak
MEA*AA*PRQ*50*KH*0*0*41	Total generation, with begin/end readings
QTY*87*100*KH	Generation - On Peak
MEA*AA*PRQ*100*KH*0*0*42	Total consumption, with begin/end readings
QTY*87*75*KH	Generation - Intermediate Peak
MEA*AA*PRQ*75*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*300*KH	Starting Bank
MEA*AF*PRQ*300*KH***41	Starting Bank – Off Peak
QTY*QH*500*KH	Starting Bank
MEA*AF*PRQ*500*KH***42	Starting Bank – On Peak
QTY*QH*400*KH	Starting Bank
MEA*AF*PRQ*400*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*78*350*KH	Generation Transferred Out
MEA*AF*PRQ*350*KH***41	Generation Transferred Out – Off Peak
QTY*78*600*KH	Generation Transferred Out
MEA*AF*PRQ*600*KH***42	Generation Transferred Out – On Peak
QTY*78*475*KH	Generation Transferred Out
MEA*AF*PRQ*475*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**Child #1 (TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*700*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*200*KH	Consumption - Off Peak
MEA*AA*PRQ*200*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*300*KH	Consumption - On Peak
MEA*AA*PRQ*300*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***41	Generation Transferred In – Off Peak
QTY*77*300*KH	Generation Transferred In
MEA*AF*PRQ*300*KH***42	Generation Transferred In – On Peak
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***43	Generation Transferred In – Intermediate Peak

**Child #2 (TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*475*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period

DTM*151*20160504	End period
QTY*QD*1200*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*300*KH	Consumption - Off Peak
MEA*AA*PRQ*300*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*500*KH	Consumption - On Peak
MEA*AA*PRQ*500*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*400*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*400*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*0*KH	Generation Transferred In
MEA*AF*PRQ*0*KH***41	Generation Transferred In – Off Peak
QTY*77*500*KH	Generation Transferred In
MEA*AF*PRQ*500*KH***42	Generation Transferred In – On Peak
QTY*77*225*KH	Generation Transferred In
MEA*AF*PRQ*225*KH***43	Generation Transferred In – Intermediate Peak

**BGE Scenario D - Host is TOU, Child # 1 is TOU Net Meter, Child # 2 is TOU**

**Parent Host Account**

Starting Banked amounts for Host

Off Peak -500 kWh

On Peak -1000 kWh

Int Peak -800 kWh

Host's current usage for 04/05/16 to 05/04/16

Off Peak -100 kWh

On Peak -500 kWh

Int Peak -200 kWh

So the host now has the following excess generation to apply to his children:

-600 kWh from Off Peak

-1500 kWh from On Peak

-1000 kWh from Int Peak

Ending Banked amounts for Host

Off Peak 0 kWh

On Peak -200 kWh

Int Peak 0 kWh

**Child #1 (TOU- Net Meter)**

Starting Banked amounts for Child # 1

Off Peak 0 kWh

On Peak -200 kWh

Int Peak -100 kWh

Current usage for 04/05/16 to 05/04/16 for Child # 1

Off Peak +100 kWh (100 kWh from Host's Off Peak applied)

On Peak +400 kWh (100 kWh from Child's Int Peak applied, 200 kWh from Child's On Peak applied and 100 kWh from Host's Off Peak applied)

Int Peak +200 kWh (200 kWh from Host's Off Peak applied)

Ending Banked amounts for Child # 1

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

**Child #2 (TOU)**

Current usage for 04/05/16 to 05/04/16

Off Peak +700 kWh (700 kWh from Host's On Peak applied)

On Peak +1000 kWh (200 kWh from Host's Off Peak applied and 800 kWh from Host's Int Peak applied)

Int Peak +800 kWh (200 kWh from Host's Int Peak applied and 600 kWh from Host's On Peak applied)

Notes:

5. BGE applies generation from the host using Off Peak first, then Intermediate and lastly On Peak.
6. BGE applies generation to a child in the opposite order (On Peak first, then Intermediate and lastly Off Peak).
7. A net metered Child account must first exhaust his own excess generation across all peaks before tapping into the Host's excess generation. A net metered Child will first use any excess generation from his Off peak, then Int Peak and lastly On Peak. This excess generation will be applied first to his On Peak, then Int Peak and lastly Off Peak. Once the Child's excess generation has been exhausted, the Child can receive excess generation from the Host account.

**Parent Account (Net Meter TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*800*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*100*KH	Generation - Off Peak
MEA*AA*PRQ*100*KH*0*0*41	Total generation, with begin/end readings
QTY*87*500*KH	Generation - On Peak
MEA*AA*PRQ*500*KH*0*0*42	Total consumption, with begin/end readings
QTY*87*200*KH	Generation - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*500*KH	Starting Bank
MEA*AF*PRQ*500*KH***41	Starting Bank – Off Peak
QTY*QH*1000*KH	Starting Bank
MEA*AF*PRQ*1000*KH***42	Starting Bank – On Peak
QTY*QH*800*KH	Starting Bank
MEA*AF*PRQ*800*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*78*600*KH	Generation Transferred Out

MEA*AF*PRQ*600*KH***41	Generation Transferred Out – Off Peak
QTY*78*1300*KH	Generation Transferred Out
MEA*AF*PRQ*1300*KH***42	Generation Transferred Out – On Peak
QTY*78*1000*KH	Generation Transferred Out
MEA*AF*PRQ*1000*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*200*KH	Ending Bank
MEA*AF*PRQ*200*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**Child #1 (TOU Net Meter)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*700*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*100*KH	Consumption - Off Peak
MEA*AA*PRQ*100*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*400*KH	Consumption - On Peak
MEA*AA*PRQ*400*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***41	Starting Bank – Off Peak
QTY*QH*200*KH	Starting Bank

MEA*AF*PRQ*200*KH***42	Starting Bank – On Peak
QTY*QH*100*KH	Starting Bank
MEA*AF*PRQ*100*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*300*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*300*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*77*100*KH	Generation Transferred In
MEA*AF*PRQ*100*KH***41	Generation Transferred In – Off Peak
QTY*77*100*KH	Generation Transferred In
MEA*AF*PRQ*100*KH***42	Generation Transferred In – On Peak
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***43	Generation Transferred In – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

## Child #2 (TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*2500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*700*KH	Consumption - Off Peak
MEA*AA*PRQ*700*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*1000*KH	Consumption - On Peak

MEA*AA*PRQ*1000*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*800*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*800*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*700*KH	Generation Transferred In
MEA*AF*PRQ*700*KH***41	Generation Transferred In – Off Peak
QTY*77*1000*KH	Generation Transferred In
MEA*AF*PRQ*1000*KH***42	Generation Transferred In – On Peak
QTY*77*800*KH	Generation Transferred In
MEA*AF*PRQ*800*KH***43	Generation Transferred In – Intermediate Peak

**BGE Scenario E - Host Net Meter TOU, Child #1 Net Meter TOU (Child uses his own generation to offset current month's consumption. Child's generation is not exhausted). Child #1 receives nothing from the Host account. Child #2 is Non-TOU and receives generation from the Host.**

**Parent Host Account**

Starting Banked amounts for Host

Off Peak -300 kWh

On Peak -500 kWh

Int Peak -400 kWh

Host's current usage for 04/05/16 to 05/04/16

Off Peak -50 kWh

On Peak -100 kWh

Int Peak -75 kWh

So the host now has the following excess generation to apply to his children:

-350 kWh from Off Peak

-600 kWh from On Peak

-475 kWh from Int Peak

Ending Banked amounts for Host

Off Peak 0 kWh

On Peak -600 kWh

Int Peak -425 kWh

**Child #1 (TOU- Net Meter)**

Starting Banked amounts for Child # 1

Off Peak 0 kWh

On Peak -2000 kWh

Int Peak -100 kWh

Current usage for 04/05/16 to 05/04/16 for Child # 1

Off Peak +1000 kWh (1000 kwh from Child's On Peak applied)

On Peak +400 kWh (100 kWh from Child's Int Peak applied, 300 kWh from Child's On Peak applied)

Int Peak +200 kWh (200 kWh from Child's On Peak applied)

Ending Banked amounts for Child # 1

Off Peak 0 kWh

On Peak 500 kWh

Int Peak 0 kWh

**Child #2 (Non-TOU)**

Current usage for 04/05/16 to 05/04/16 is +400 kWh (350 kWh from Host's Off Peak and 50 kWh from Host's Int Peak applied).

Notes:

1. BGE applies generation from the host using Off Peak first, then Intermediate and lastly On Peak.
2. BGE applies generation to a child in the opposite order (On Peak first, then Intermediate and lastly Off Peak).
3. A net metered Child account must first exhaust his own excess generation across all peaks before tapping into the Host's excess generation. A net metered Child will first use any excess generation from his Off peak, then Int Peak and lastly On Peak. This excess generation will be applied first to his On Peak, then Int Peak and lastly Off Peak. Once the Child's excess generation has been exhausted, the Child can receive excess generation from the Host account.

**Parent Account (Net Meter TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*225*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*50*KH	Generation - Off Peak
MEA*AA*PRQ*50*KH*0*0*41	Total generation, with begin/end readings
QTY*87*100*KH	Generation - On Peak
MEA*AA*PRQ*100*KH*0*0*42	Total consumption, with begin/end readings
QTY*87*75*KH	Generation - Intermediate Peak
MEA*AA*PRQ*75*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*300*KH	Starting Bank
MEA*AF*PRQ*300*KH***41	Starting Bank – Off Peak
QTY*QH*500*KH	Starting Bank
MEA*AF*PRQ*500*KH***42	Starting Bank – On Peak
QTY*QH*400*KH	Starting Bank
MEA*AF*PRQ*400*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*78*350*KH	Generation Transferred Out
MEA*AF*PRQ*350*KH***41	Generation Transferred Out – Off Peak
QTY*78*0*KH	Generation Transferred Out
MEA*AF*PRQ*0*KH***42	Generation Transferred Out – On Peak

QTY*78*50*KH	Generation Transferred Out
MEA*AF*PRQ*50*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*600*KH	Ending Bank
MEA*AF*PRQ*600*KH***42	Ending Bank – On Peak
QTY*QE*425*KH	Ending Bank
MEA*AF*PRQ*425*KH***43	Ending Bank – Intermediate Peak

**Child #1 (TOU Net Meter)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*1600*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1000*KH	Consumption - Off Peak
MEA*AA*PRQ*1000*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*400*KH	Consumption - On Peak
MEA*AA*PRQ*400*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***41	Starting Bank – Off Peak
QTY*QH*2000*KH	Starting Bank
MEA*AF*PRQ*2000*KH***42	Starting Bank – On Peak
QTY*QH*100*KH	Starting Bank
MEA*AF*PRQ*100*KH***43	Starting Bank – Intermediate Peak
QTY*79*1000*KH	Self-Generation

MEA*AF*PRQ*1000*KH***41	Self-Generation Applied to Off Peak
QTY*79*400*KH	Self-Generation
MEA*AF*PRQ*400*KH***42	Self-Generation Applied to On Peak
QTY*79*200*KH	Self-Generation
MEA*AF*PRQ*200*KH***43	Self-Generation Applied to Intermediate Peak
QTY*77*0*KH	Generation Transferred In
MEA*AF*PRQ*0*KH***41	Generation Transferred In – Off Peak
QTY*77*0*KH	Generation Transferred In
MEA*AF*PRQ*0*KH***42	Generation Transferred In – On Peak
QTY*77*0*KH	Generation Transferred In
MEA*AF*PRQ*0*KH***43	Generation Transferred In – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*500*KH	Ending Bank
MEA*AF*PRQ*500*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**Child #2 (Non-TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*400*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*400*KH	Consumption
MEA*AA*PRQ*400*KH*20000*20400*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*400*KH	Generation Transferred In
MEA*AF*PRQ*400*KH***51	Generation Transferred In – Total Non TOU

**BGE Scenario F - Host TOU, Child is TOU and Net Meter. Child applies his own generation to himself first, then receives the remaining available generation from the Host. Child has consumption left over after generation from Host and Child applied to current month's usage.**

**Parent Host Account**

Starting Banked amounts for Host

Off Peak -0 kWh

On Peak -4900 kWh

Int Peak -0 kWh

Host's current usage for 04/05/16 to 05/04/16

Off Peak +500 kWh

On Peak +1000 kWh

Int Peak +2000 kWh

Host applied 4900 kWh excess generation from On Peak to: 1000 kWh from On Peak, 2000 kWh from Intermediate Peak and lastly to 500 kWh from Off Peak using up 3500 kWh of generation. This leaves 1400 kWh generation from On Peak to apply to his child. Host applied 1100 kWh to Child's On Peak and then 300 kWh to Child's Intermediate Peak. Host has no remaining banked amount in any peak period.

Ending Banked amounts for Host

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

**Child (TOU- Net Meter)**

Starting Banked amounts for Child

Off Peak 0 kWh

On Peak -200 kWh

Int Peak -100 kWh

Current usage for 04/05/16 to 05/04/16 for Child

Off Peak +1000 kWh (Nothing applied from either Child or Host leaving 1000 kwh to be billed)

On Peak +1400 kWh (100 kWh from Child's Int Peak applied, 200 kWh from Child's On Peak applied, 1100 kWh from Host's On Peak applied)

Int Peak +1200 kWh (300 kWh from Host's On Peak applied, leaving 900 kWh to be billed)

Child has 1900 kWh left to bill at the peak level below.

Off Peak = 1000

On Peak = 0

Int Peak = 900

Ending Banked amounts for Child

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

**Notes:**

1. BGE applies generation from the host using Off Peak first, then Intermediate and lastly On Peak.
2. BGE applies generation to a child in the opposite order (On Peak first, then Intermediate and lastly Off Peak).
3. A net metered Child account must first exhaust his own excess generation across all peaks before tapping into the Host's excess generation. A net metered Child will first use any excess generation from his Off peak, then Int Peak and lastly On Peak. This excess generation will be applied first to his On Peak, then Int Peak and lastly Off Peak. Once the Child's excess generation has been exhausted, the Child can receive excess generation from the Host account.

**Parent Account (Net Meter TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*3500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*500*KH	Generation - Off Peak
MEA*AA*PRQ*500*KH*0*0*41	Total generation, with begin/end readings
QTY*QD*1000*KH	Generation - On Peak
MEA*AA*PRQ*1000*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*2000*KH	Generation - Intermediate Peak
MEA*AA*PRQ*2000*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***41	Starting Bank – Off Peak
QTY*QH*4900*KH	Starting Bank
MEA*AF*PRQ*4900*KH***42	Starting Bank – On Peak
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***43	Starting Bank – Intermediate Peak
QTY*79*500*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*500*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*1000*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*1000*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*2000*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*2000*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*78*0*KH	Generation Transferred Out
MEA*AF*PRQ*0*KH***41	Generation Transferred Out – Off Peak
QTY*78*1400*KH	Generation Transferred Out

MEA*AF*PRQ*1400*KH***42	Generation Transferred Out – On Peak
QTY*78*0*KH	Generation Transferred Out
MEA*AF*PRQ*0*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

<b>Child (TOU Net Meter)</b>	
<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*1900*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*3600*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1000*KH	Consumption - Off Peak
MEA*AA*PRQ*1000*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*1400*KH	Consumption - On Peak
MEA*AA*PRQ*1400*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*1200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*1200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***41	Starting Bank – Off Peak
QTY*QH*200*KH	Starting Bank
MEA*AF*PRQ*200*KH***42	Starting Bank – On Peak
QTY*QH*100*KH	Starting Bank
MEA*AF*PRQ*100*KH***43	Starting Bank – Intermediate Peak

QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***41	Self-Generation Applied to Off Peak
QTY*79*300*KH	Self-Generation
MEA*AF*PRQ*300*KH***42	Self-Generation Applied to On Peak
QTY*79*0*KH	Self-Generation
MEA*AF*PRQ*0*KH***43	Self-Generation Applied to Intermediate Peak
QTY*77*0*KH	Generation Transferred In
MEA*AF*PRQ*0*KH***41	Generation Transferred In – Off Peak
QTY*77*1100*KH	Generation Transferred In
MEA*AF*PRQ*1100*KH***42	Generation Transferred In – On Peak
QTY*77*300*KH	Generation Transferred In
MEA*AF*PRQ*300*KH***43	Generation Transferred In – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**BGE Scenario G - Host is TOU, Child # 1 is TOU Net Meter, Child # 2 is TOU. April True-up month. Host has excess generation after the April billing and needs a True-up. Child #1 does not have any excess generation left so there is no True-up. Please note: Since Child #1 does not need a True-up, we will not send the Qty\*QB section in the BJ loop.**

**Parent Host Account**

Starting Banked amounts for Host

Off Peak -500 kWh

On Peak -1000 kWh

Int Peak -800 kWh

Host's current usage for 03/05/16 to 04/04/16

Off Peak -100 kWh

On Peak -500 kWh

Int Peak -200 kWh

So the host now has the following excess generation to apply to his children:

-600 kWh from Off Peak

-1500 kWh from On Peak

-1000 kWh from Int Peak

True-Up amounts for Host (cashed out to customer)

Off Peak 0 kWh

On Peak 200 kWh

Int Peak 0 kWh

Ending Banked amounts for Host

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

**Child #1 (TOU- Net Meter)**

Starting Banked amounts for Child # 1

Off Peak 0 kWh

On Peak -200 kWh

Int Peak -100 kWh

Current usage for 03/05/16 to 04/04/16 for Child # 1

Off Peak +100 kWh (100 kwh from Host's Off Peak applied)

On Peak +400 kWh (100 kWh from Child's Int Peak applied, 200 kWh from Child's On Peak applied and 100 kWh from Host's Off Peak applied)

Int Peak +200 kWh (200 kWh from Host's Off Peak applied)

Ending Banked amounts for Child # 1

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

**Child #2 (TOU)**

Current usage for 03/05/16 to 04/04/16

Off Peak +700 kWh (700 kWh from Host's On Peak applied)

On Peak +1000 kWh (200 kWh from Host's Off Peak applied and 800 kWh from Host's Int Peak applied)

Int Peak +800 kWh (200 kWh from Host's Int Peak applied and 600 kWh from Host's On Peak applied)

Notes:

1. BGE applies generation from the host using Off Peak first, then Intermediate and lastly On Peak.

2. BGE applies generation to a child in the opposite order (On Peak first, then Intermediate and lastly Off Peak).
3. A net metered Child account must first exhaust his own excess generation across all peaks before tapping into the Host's excess generation. A net metered Child will first use any excess generation from his Off peak, then Int Peak and lastly On Peak. This excess generation will be applied first to his On Peak, then Int Peak and lastly Off Peak. Once the Child's excess generation has been exhausted, the Child can receive excess generation from the Host account.
4. During True-Up for TOU, if one TOU peak contains excess generation passed in QTY\*QB, all TOU peaks must be sent even when 0 kWh.

#### Parent Account (Net Meter TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*87*800*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*100*KH	Generation - Off Peak
MEA*AA*PRQ*100*KH*0*0*41	Total generation, with begin/end readings
QTY*87*500*KH	Generation - On Peak
MEA*AA*PRQ*500*KH*0*0*42	Total consumption, with begin/end readings
QTY*87*200*KH	Generation - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*QH*500*KH	Starting Bank
MEA*AF*PRQ*500*KH***41	Starting Bank – Off Peak
QTY*QH*1000*KH	Starting Bank
MEA*AF*PRQ*1000*KH***42	Starting Bank – On Peak
QTY*QH*800*KH	Starting Bank
MEA*AF*PRQ*800*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank

MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*78*600*KH	Generation Transferred Out
MEA*AF*PRQ*600*KH***41	Generation Transferred Out – Off Peak
QTY*78*1300*KH	Generation Transferred Out
MEA*AF*PRQ*1300*KH***42	Generation Transferred Out – On Peak
QTY*78*1000*KH	Generation Transferred Out
MEA*AF*PRQ*1000*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QB*0*KH	True-Up
MEA*AF*PRQ*0*KH***41	True-Up – Off Peak
QTY*QB*200*KH	True-Up
MEA*AF*PRQ*200*KH***42	True-Up – On Peak
QTY*QB*0*KH	True-Up
MEA*AF*PRQ*0*KH***43	True-Up – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY* QE *0*KH	Ending Bank
MEA*AF*PRQ*0*KH***42	Ending Bank – On Peak
QTY* QE *0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

#### Child #1 (TOU Net Meter)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*QD*700*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits

QTY*QD*100*KH	Consumption - Off Peak
MEA*AA*PRQ*100*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*400*KH	Consumption - On Peak
MEA*AA*PRQ*400*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***41	Starting Bank – Off Peak
QTY*QH*200*KH	Starting Bank
MEA*AF*PRQ*200*KH***42	Starting Bank – On Peak
QTY*QH*100*KH	Starting Bank
MEA*AF*PRQ*100*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*300*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*300*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*77*100*KH	Generation Transferred In
MEA*AF*PRQ*100*KH***41	Generation Transferred In – Off Peak
QTY*77*100*KH	Generation Transferred In
MEA*AF*PRQ*100*KH***42	Generation Transferred In – On Peak
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***43	Generation Transferred In – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

## Child #2 (TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop

DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*QD*2500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*700*KH	Consumption - Off Peak
MEA*AA*PRQ*700*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*1000*KH	Consumption - On Peak
MEA*AA*PRQ*1000*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*800*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*800*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*77*700*KH	Generation Transferred In
MEA*AF*PRQ*700*KH***41	Generation Transferred In – Off Peak
QTY*77*1000*KH	Generation Transferred In
MEA*AF*PRQ*1000*KH***42	Generation Transferred In – On Peak
QTY*77*800*KH	Generation Transferred In
MEA*AF*PRQ*800*KH***43	Generation Transferred In – Intermediate Peak

**BGE Scenario H - Host is TOU, Child # 1 is TOU Net Meter, Child # 2 is TOU. April True-up month. Both Host and Child have excess generation after the April billing and need a True-up.**

**Parent Host Account**

Starting Banked amounts for Host

Off Peak -500 kWh

On Peak -1000 kWh

Int Peak -800 kWh

Host's current usage for 03/05/16 to 04/04/16

Off Peak -100 kWh

On Peak -500 kWh

Int Peak -200 kWh

So the host now has the following excess generation to apply to his children:

-600 kWh from Off Peak

-1500 kWh from On Peak

-1000 kWh from Int Peak

True-Up amounts for Host (cashed out to customer)

Off Peak 0 kWh

On Peak 600 kWh

Int Peak 0 kWh

Ending Banked amounts for Host

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

**Child #1 (TOU- Net Meter)**

Starting Banked amounts for Child # 1

Off Peak 0 kWh

On Peak -1200 kWh

Int Peak -100 kWh

Current usage for 03/05/16 to 04/04/16 for Child # 1

Off Peak +100 kWh (100 kwh from Child's On Peak applied)

On Peak +400 kWh (100 kWh from Child's Int Peak applied, 300 kWh from Child's On Peak applied)

Int Peak +200 kWh (200 kWh from Child's On Peak applied)

True-Up amounts for Child#1 (cashed out to customer)

Off Peak 0 kWh

On Peak 600 kWh

Int Peak 0 kWh

Ending Banked amounts for Child # 1

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

### Child #2 (TOU)

Current usage for 03/05/16 to 04/04/16

Off Peak +700 kWh (700 kWh from Host's On Peak applied)

On Peak +1000 kWh (600 kWh from Host's Off Peak applied and 400 kWh from Host's Int Peak applied)

Int Peak +800 kWh (600 kWh from Host's Int Peak applied and 200 kWh from Host's On Peak applied)

### Notes:

1. BGE applies generation from the host using Off Peak first, then Intermediate and lastly On Peak.
2. BGE applies generation to a child in the opposite order (On Peak first, then Intermediate and lastly Off Peak).
3. A net metered Child account must first exhaust his own excess generation across all peaks before tapping into the Host's excess generation. A net metered Child will first use any excess generation from his Off peak, then Int Peak and lastly On Peak. This excess generation will be applied first to his On Peak, then Int Peak and lastly Off Peak. Once the Child's excess generation has been exhausted, the Child can receive excess generation from the Host account.
4. During True-Up for TOU, if one TOU peak contains excess generation passed in QTY\*QB, all TOU peaks must be sent even when 0 kWh.

### Parent Account (Net Meter TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*87*800*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*100*KH	Generation - Off Peak
MEA*AA*PRQ*100*KH*0*0*41	Total generation, with begin/end readings
QTY*87*500*KH	Generation - On Peak
MEA*AA*PRQ*500*KH*0*0*42	Total consumption, with begin/end readings
QTY*87*200*KH	Generation - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160305	Start period

DTM*151*20160404	End period
QTY*QH*500*KH	Starting Bank
MEA*AF*PRQ*500*KH***41	Starting Bank – Off Peak
QTY*QH*1000*KH	Starting Bank
MEA*AF*PRQ*1000*KH***42	Starting Bank – On Peak
QTY*QH*800*KH	Starting Bank
MEA*AF*PRQ*800*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*78*600*KH	Generation Transferred Out
MEA*AF*PRQ*600*KH***41	Generation Transferred Out – Off Peak
QTY*78*900*KH	Generation Transferred Out
MEA*AF*PRQ*900*KH***42	Generation Transferred Out – On Peak
QTY*78*1000*KH	Generation Transferred Out
MEA*AF*PRQ*1000*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QB*0*KH	True-Up
MEA*AF*PRQ*0*KH***41	True-Up – Off Peak
QTY*QB*600*KH	True-Up
MEA*AF*PRQ*600*KH***42	True-Up – On Peak
QTY*QB*0*KH	True-Up
MEA*AF*PRQ*0*KH***43	True-Up – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**Child #1 (TOU Net Meter)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160305	Start period

DTM*151*20160404	End period
QTY*QD*700*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*100*KH	Consumption - Off Peak
MEA*AA*PRQ*100*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*400*KH	Consumption - On Peak
MEA*AA*PRQ*400*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***41	Starting Bank – Off Peak
QTY*QH*1200*KH	Starting Bank
MEA*AF*PRQ*1200*KH***42	Starting Bank – On Peak
QTY*QH*100*KH	Starting Bank
MEA*AF*PRQ*100*KH***43	Starting Bank – Intermediate Peak
QTY*79*100*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*100*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*400*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*400*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*200*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*200*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*77*0*KH	Generation Transferred In
MEA*AF*PRQ*0*KH***41	Generation Transferred In – Off Peak
QTY*77*0*KH	Generation Transferred In
MEA*AF*PRQ*0*KH***42	Generation Transferred In – On Peak
QTY*77*0*KH	Generation Transferred In
MEA*AF*PRQ*0*KH***43	Generation Transferred In – Intermediate Peak
QTY*QB*0*KH	True-Up
MEA*AF*PRQ*0*KH***41	True-Up – Off Peak
QTY*QB*600*KH	True-Up
MEA*AF*PRQ*600*KH***42	True-Up – On Peak

QTY*QB*0*KH	True-Up
MEA*AF*PRQ*0*KH***43	True-Up – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***43	Ending Bank – Intermediate Peak

## Child #2 (TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*QD*2500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*700*KH	Consumption - Off Peak
MEA*AA*PRQ*700*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*1000*KH	Consumption - On Peak
MEA*AA*PRQ*1000*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*800*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*800*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160305	Start period
DTM*151*20160404	End period
QTY*77*700*KH	Generation Transferred In
MEA*AF*PRQ*700*KH***41	Generation Transferred In – Off Peak
QTY*77*1000*KH	Generation Transferred In
MEA*AF*PRQ*1000*KH***42	Generation Transferred In – On Peak
QTY*77*800*KH	Generation Transferred In
MEA*AF*PRQ*800*KH***43	Generation Transferred In – Intermediate Peak

**Maryland (PHI/PE) - Examples of PTD\*BJ Loop for Aggregate Net Energy Metering (ANEM), TOU****PHI/PE Scenario A - Host is TOU, Child # 1 is Non-TOU, Child # 2 is TOU****Parent Host Account**

Starting Bank = -1200 kWh

Off Peak -300 kWh

On Peak -500 kWh

Int Peak -400 kWh

Current usage for 04/05/16 to 05/04/16 = -225 kWh, 0 kWh Billed

Off Peak -50 kWh

On Peak -100 kWh

Int Peak -75 kWh

Excess generation for family = -1425 kWh

-350 kWh from Off Peak

-600 kWh from On Peak

-475 kWh from Int Peak

Transferred Out = -1000 kWh

-200 kWh from Off Peak

-600 kWh from On Peak

-200 kWh from Int Peak

Ending Bank = -425 kWh

Off Peak -150 kWh

On Peak 0 kWh

Int Peak -275 kWh

**Child #1 (NON-TOU)**

Current usage for 04/05/16 to 05/04/16 is 400 kWh, -400 kWh applied from ParentHost's On Peak = 0 kWh billed

**Child #2 (TOU)**

Current usage for 04/05/16 to 05/04/16 = 100 kWh billed

Off Peak +200 kWh (200 kwh from ParentHost's Off Peak applied) = 0 kWh

On Peak +300 kWh (200 kWh from ParentHost's On Peak applied) = 100 kWh billed

Int Peak +200 kWh (200 kWh from ParentHost's Int Peak applied) = 0 kWh

**Notes:**

1. Applies TOU generation using the "waterfall" method. Off Peak to Off Peak, On Peak to On Peak & Intermediate Peak to Intermediate Peak.
2. When applying TOU excess generation to a non-TOU account will use the On Peak energy first, followed by the Intermediate Peak and finally the Off-Peak.

**Parent Account (Net Meter TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH

<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*225*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*100*KH	Consumption - Off Peak
MEA*AA*PRQ*100*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*0*KH	Consumption - On Peak
MEA*AA*PRQ*0*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*150*KH	Generation - Off Peak
MEA*AA*PRQ*150*KH*0*0*41	Total generation, with begin/end readings
QTY*87*100*KH	Generation - On Peak
MEA*AA*PRQ*100*KH*0*0*42	Total generation, with begin/end readings
QTY*87*275*KH	Generation - Intermediate Peak
MEA*AA*PRQ*275*KH*0*0*43	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*300*KH	Starting Bank
MEA*AA*PRQ*300*KH***41	Starting Bank – Off Peak
QTY*QH*500*KH	Starting Bank
MEA*AA*PRQ*500*KH***42	Starting Bank – On Peak
QTY*QH*400*KH	Starting Bank
MEA*AA*PRQ*400*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank

MEA*AF*PRQ*0*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*78*200*KH	Generation Transferred Out
MEA*AF*PRQ*200*KH***41	Generation Transferred Out – Off Peak
QTY*78*600*KH	Generation Transferred Out
MEA*AF*PRQ*600*KH***42	Generation Transferred Out – On Peak
QTY*78*200*KH	Generation Transferred Out
MEA*AF*PRQ*200*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QE*150*KH	Ending Bank
MEA*AA*PRQ*150*KH***41	Ending Bank – Off Peak
QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*275*KH	Ending Bank
MEA*AA*PRQ*275*KH***43	Ending Bank – Intermediate Peak

#### Child #1 (Non-TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*400*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*400*KH	Consumption
MEA*AA*PRQ*400*KH*20000*20810*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*400*KH	Generation Transferred In
MEA*AF*PRQ*400*KH***51	Generation Transferred In – Total Non TOU

**Child #2 (TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*100*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*100*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*200*KH	Consumption - Off Peak
MEA*AA*PRQ*200*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*300*KH	Consumption - On Peak
MEA*AA*PRQ*300*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***41	Generation Transferred In – Off Peak
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***42	Generation Transferred In – On Peak
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***43	Generation Transferred In – Intermediate Peak

**PHI/PE Scenario B - Host is TOU, Child # 1 is TOU, Child # 2 is Non-TOU**

**Parent Host Account**

Starting Bank = -1200 kWh

Off Peak -300 kWh

On Peak -500 kWh

Int Peak -400 kWh

Current usage for 04/05/16 to 05/04/16 = -225 kWh, 0 kWh Billed

Off Peak -50 kWh

On Peak -100 kWh

Int Peak -75 kWh

Excess generation for family = -1425 kWh

-350 kWh from Off Peak

-600 kWh from On Peak

-475 kWh from Int Peak

Transferred Out = -1100 kWh

-200 kWh from Off Peak

-600 kWh from On Peak

-300 kWh from Int Peak

Ending Bank = -325 kWh

Off Peak -150 kWh

On Peak 0 kWh

Int Peak -175 kWh

**Child #1 (TOU)**

Current usage for 04/05/16 to 05/04/16, 700 kWh, -700 kWh applied from ParentHost's On Peak = 0 kWh billed

Off Peak +200 kWh (200 kwh from ParentHost's Off Peak applied) = 0 kWh

On Peak +300 kWh (300 kWh from ParentHost's On Peak applied) = 0 kWh

Int Peak +200 kWh (200 kWh from ParentHost's Int Peak applied) = 0 kWh

**Child #2 (NON-TOU)**

Current usage for 04/05/16 to 05/04/16 is +400 kWh (300 kWh from ParentHost's On Peak and 100 kWh from ParentHost's Int Peak applied)

**Notes:**

1. Applies TOU generation using the "waterfall" method. Off Peak to Off Peak, On Peak to On Peak & Intermediate Peak to Intermediate Peak.
2. When applying TOU excess generation to a non-TOU account PHI will use the On Peak energy first, followed by the Intermediate Peak and finally the Off-Peak.

**Parent Account (Net Meter TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*225*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*300*KH	Consumption - Off Peak
MEA*AA*PRQ*300*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*400*KH	Consumption - On Peak
MEA*AA*PRQ*400*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*325*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*325*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*350*KH	Generation - Off Peak
MEA*AA*PRQ*350*KH*0*0*41	Total generation, with begin/end readings
QTY*87*500*KH	Generation - On Peak
MEA*AA*PRQ*500*KH*0*0*42	Total generation, with begin/end readings
QTY*87*400*KH	Generation - Intermediate Peak
MEA*AA*PRQ*400*KH*0*0*43	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*300*KH	Starting Bank
MEA*AA*PRQ*300*KH***41	Starting Bank – Off Peak
QTY*QH*500*KH	Starting Bank
MEA*AA*PRQ*500*KH***42	Starting Bank – On Peak
QTY*QH*400*KH	Starting Bank

MEA*AA*PRQ*400*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*78*200*KH	Generation Transferred Out
MEA*AF*PRQ*200*KH***41	Generation Transferred Out – Off Peak
QTY*78*600*KH	Generation Transferred Out
MEA*AF*PRQ*600*KH***42	Generation Transferred Out – On Peak
QTY*78*300*KH	Generation Transferred Out
MEA*AF*PRQ*300*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QE*150*KH	Ending Bank
MEA*AA*PRQ*150*KH***41	Ending Bank – Off Peak
QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*175*KH	Ending Bank
MEA*AA*PRQ*175*KH***43	Ending Bank – Intermediate Peak

#### Child #1 (TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*700*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*200*KH	Consumption - Off Peak
MEA*AA*PRQ*200*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*300*KH	Consumption - On Peak
MEA*AA*PRQ*300*KH*0*0*42	Total consumption, with begin/end readings

QTY*QD*200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***41	Generation Transferred In – Off Peak
QTY*77*300*KH	Generation Transferred In
MEA*AF*PRQ*300*KH***42	Generation Transferred In – On Peak
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***43	Generation Transferred In – Intermediate Peak

## Child #2 (Non-TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*400*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*400*KH	Consumption
MEA*AA*PRQ*400*KH*20000*20400*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*400*KH	Generation Transferred In
MEA*AF*PRQ*400*KH***51	Generation Transferred In – Total Non TOU

**PHI/PE Scenario C - Host is TOU, Child # 1 is TOU, Child # 2 is TOU (Host's generation is exhausted on Child # 2)**

**Parent Host Account**

Starting Bank = -1200 kWh

Off Peak -300 kWh

On Peak -500 kWh

Int Peak -400 kWh

Current usage for 04/05/16 to 05/04/16 = -225 kWh, 0 kWh Billed

Off Peak -50 kWh

On Peak -100 kWh

Int Peak -75 kWh

Excess generation for family = -1425 kWh

-350 kWh from Off Peak

-600 kWh from On Peak

-475 kWh from Int Peak

Transferred Out = -1425 kWh

-350 kWh from Off Peak

-600 kWh from On Peak

-475 kWh from Int Peak

Ending Bank = 0 kWh

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

**Child #1 (TOU)**

Current usage for 04/05/16 to 05/04/16 (700 kWh, -700kWh applied = 0 kWh billed)

Off Peak +200 kWh (200 kwh from ParentHost's Off Peak applied) = 0 kWh

On Peak +300 kWh (300 kWh from ParentHost's On Peak applied) = 0 kWh

Int Peak +200 kWh (200 kWh from ParentHost's Int Peak applied) = 0 kWh

**Child #2 (TOU)**

Current usage for 04/05/16 to 05/04/16 (1200 kWh, -725kWh applied = 475 kWh billed)

Off Peak +300 kWh (150 kwh from ParentHost's Off Peak applied) = 150 kWh billed

On Peak +500 kWh (300 kwh from ParentHost's Off Peak applied) = 200 kWh billed

Int Peak +400 kWh (275 kwh from ParentHost's Int Peak applied) = 125 kWh billed

Note: Applies TOU generation using the "waterfall" method. Off Peak to Off Peak, On Peak to On Peak & Intermediate Peak to Intermediate Peak.

**Parent Account (Net Meter TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*225*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*300*KH	Consumption - Off Peak
MEA*AA*PRQ*300*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*1000*KH	Consumption - On Peak
MEA*AA*PRQ*1000*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*275*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*275*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*350*KH	Generation - Off Peak
MEA*AA*PRQ*350*KH*0*0*41	Total generation, with begin/end readings
QTY*87*1100*KH	Generation - On Peak
MEA*AA*PRQ*1100*KH*0*0*42	Total consumption, with begin/end readings
QTY*87*350*KH	Generation - Intermediate Peak
MEA*AA*PRQ*350*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*300*KH	Starting Bank
MEA*AA*PRQ*300*KH***41	Starting Bank – Off Peak
QTY*QH*500*KH	Starting Bank
MEA*AA*PRQ*500*KH***42	Starting Bank – On Peak

QTY*QH*400*KH	Starting Bank
MEA*AA*PRQ*400*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*78*350*KH	Generation Transferred Out
MEA*AF*PRQ*350*KH***41	Generation Transferred Out – Off Peak
QTY*78*600*KH	Generation Transferred Out
MEA*AF*PRQ*600*KH***42	Generation Transferred Out – On Peak
QTY*78*475*KH	Generation Transferred Out
MEA*AF*PRQ*475*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***43	Ending Bank – Intermediate Peak

#### Child #1 (TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*700*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*200*KH	Consumption - Off Peak
MEA*AA*PRQ*200*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*300*KH	Consumption - On Peak
MEA*AA*PRQ*300*KH*0*0*42	Total consumption, with begin/end readings

QTY*QD*200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***41	Generation Transferred In – Off Peak
QTY*77*300*KH	Generation Transferred In
MEA*AF*PRQ*300*KH***42	Generation Transferred In – On Peak
QTY*77*200*KH	Generation Transferred In
MEA*AF*PRQ*200*KH***43	Generation Transferred In – Intermediate Peak

## Child #2 (TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*475*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*1200*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*300*KH	Consumption - Off Peak
MEA*AA*PRQ*300*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*500*KH	Consumption - On Peak
MEA*AA*PRQ*500*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*400*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*400*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*150*KH	Generation Transferred In
MEA*AF*PRQ*150*KH***41	Generation Transferred In – Off Peak
QTY*77*300*KH	Generation Transferred In
MEA*AF*PRQ*300*KH***42	Generation Transferred In – On Peak

QTY*77*275*KH	Generation Transferred In
MEA*AF*PRQ*275*KH***43	Generation Transferred In – Intermediate Peak

**PHI/PE Scenario D - ParentHost TOU & current period is net consumption. Starting bank contains single TOU**

**Parent Host Account (TOU)**

Starting Banked amounts for Host

Off Peak 0 kWh

On Peak -4900 kWh

Int Peak 0 kWh

Host's current usage for 04/05/16 to 05/04/16 = 3500 kWh

Off Peak +500 kWh

On Peak +1000 kWh

Int Peak +2000 kWh

Self-generation applied to Host (-1000 kWh On Peak applied, 500 kWh Off Peak & 2000 kWh Int Peak remain) = 2500 kwh Billed

Off Peak 0 kWh = 500 kWh

On Peak -1000 kWh = 0 kWh

Int Peak 0 kWh = 2000 kWh

Excess generation for family = -3900 kWh

0 kWh from Off Peak

-3900 kWh from On Peak

0 kWh from Int Peak

Transferred Out = -1000 kWh

0 kWh from Off Peak

-1000 kWh from On Peak

0 kWh from Int Peak

Ending Bank = -2900 kWh

Off Peak 0 kWh

On Peak -2900 kWh

Int Peak 0 kWh

**Child #1 (TOU)**

Current usage for 04/05/16 to 05/04/16, 2600 kWh, -1000 kWh applied from ParentHost = 1600 kWh billed

Off Peak +800 kWh = 800 kWh billed

On Peak +1000 kWh (1000 kWh from Host's On Peak applied) = 0 kWh

Int Peak +800 kWh = 800 kWh billed

**ParentHost Account (Net Meter TOU)**

PTD*BB	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*2500*KH	Monthly billed KH

<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*3500*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*1500*KH	Consumption - Off Peak
MEA*AA*PRQ*1500*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*2000*KH	Consumption - On Peak
MEA*AA*PRQ*2000*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*2600*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*2600*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*1000*KH	Generation - Off Peak
MEA*AA*PRQ*1000*KH*0*0*41	Total generation, with begin/end readings
QTY*87*1000*KH	Generation - On Peak
MEA*AA*PRQ*1000*KH*0*0*42	Total generation, with begin/end readings
QTY*87*600*KH	Generation - Intermediate Peak
MEA*AA*PRQ*600*KH*0*0*43	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*0*KH	Starting Bank
MEA*AA*PRQ*0*KH***41	Starting Bank – Off Peak
QTY*QH*4900*KH	Starting Bank
MEA*AA*PRQ*4900*KH***42	Starting Bank – On Peak
QTY*QH*0*KH	Starting Bank
MEA*AA*PRQ*0*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank

MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*1000*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*1000*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*78*0*KH	Generation Transferred Out
MEA*AF*PRQ*0*KH***41	Generation Transferred Out – Off Peak
QTY*78*1000*KH	Generation Transferred Out
MEA*AF*PRQ*1000*KH***42	Generation Transferred Out – On Peak
QTY*78*0*KH	Generation Transferred Out
MEA*AF*PRQ*0*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*2900*KH	Ending Bank
MEA*AA*PRQ*2900*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***43	Ending Bank – Intermediate Peak

#### Child #1 (TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*1600*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*2600*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*800*KH	Consumption - Off Peak
MEA*AA*PRQ*800*KH*0*0*41	Total consumption, with begin/end readings

QTY*QD*1000*KH	Consumption - On Peak
MEA*AA*PRQ*1000*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*800*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*800*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*0*KH	Generation Transferred In
MEA*AF*PRQ*0*KH***41	Generation Transferred In – Off Peak
QTY*77*1000*KH	Generation Transferred In
MEA*AF*PRQ*1000*KH***42	Generation Transferred In – On Peak
QTY*77*0*KH	Generation Transferred In
MEA*AF*PRQ*0*KH***43	Generation Transferred In – Intermediate Peak

**PHI Scenario E - ParentHost is TOU, Parent is TOU, Child is TOU (only PHI uses Parent accounts)**

**Parent Host Account**

Starting Bank = -2300 kWh

Off Peak -500 kWh

On Peak -1000 kWh

Int Peak -800 kWh

Current usage for 04/05/16 to 05/04/16 = -1800 kWh, 0 kWh Billed

Off Peak -100 kWh

On Peak -1500 kWh

Int Peak -200 kWh

Transferred In (from Parent) = -800 kWh

-100 kWh from Off Peak

-500 kWh from On Peak

-200 kWh from Int Peak

Excess generation for family = -4900 kWh (sum of Starting Bank, Current Period Excess & transferred in from Parent)

-700 kWh from Off Peak

-3000 kWh from On Peak

-1200 kWh from Int Peak

Transferred Out = -2500 kWh

-700 kWh from Off Peak

-1000 kWh from On Peak

-800 kWh from Int Peak

Ending Bank = -2400 kWh

Off Peak 0 kWh

On Peak -2000 kWh

Int Peak -400 kWh

**Parent Account TOU w/Net Meter (does not utilize starting or ending bank, all excess transfers out to ParentHost)**

Current usage for 04/05/16 to 05/04/16 = -800 kWh, 0 kWh Billed

Off Peak -100 kWh

On Peak -500 kWh

Int Peak -200 kWh

Transferred Out (to ParentHost into Generation available for family) = -800 kWh

-100 kWh from Off Peak

-500 kWh from On Peak

-200 kWh from Int Peak

**Child #1 (TOU)**

Current usage for 04/05/16 to 05/04/16, 2600 kWh, -2500 kWh applied from ParentHost = 100 kWh billed

Off Peak +800 kWh (700 kWh from Host's Off Peak applied) = 100 kWh billed

On Peak +1000 kWh (1000 kWh from Host's On Peak applied) = 0 kWh

Int Peak +800 kWh (800 kWh from Host's Int Peak applied) = 0 kWh

**Notes:**

1. Applies TOU generation using the "waterfall" method. Off Peak to Off Peak, On Peak to On Peak & Intermediate Peak to Intermediate Peak.

2. For TOU Parent, excess generation from an individual peak period transfers to ParentHost's available generation.

**ParentHost Account (Net Meter TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*800*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*500*KH	Consumption - Off Peak
MEA*AA*PRQ*500*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*1500*KH	Consumption - On Peak
MEA*AA*PRQ*1500*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*600*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*600*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*600*KH	Generation - Off Peak
MEA*AA*PRQ*600*KH*0*0*41	Total generation, with begin/end readings
QTY*87*3000*KH	Generation - On Peak
MEA*AA*PRQ*3000*KH*0*0*42	Total generation, with begin/end readings
QTY*87*800*KH	Generation - Intermediate Peak
MEA*AA*PRQ*800*KH*0*0*43	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period

DTM*151*20160504	End period
QTY*QH*500*KH	Starting Bank
MEA*AA*PRQ*500*KH***41	Starting Bank – Off Peak
QTY*QH*1000*KH	Starting Bank
MEA*AA*PRQ*1000*KH***42	Starting Bank – On Peak
QTY*QH*800*KH	Starting Bank
MEA*AA*PRQ*800*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*77*100*KH	Generation Transferred In – From Parent
MEA*AF*PRQ*100*KH***41	Generation Transferred In – Off Peak
QTY*77*500*KH	Generation Transferred In – From Parent
MEA*AF*PRQ*500*KH***42	Generation Transferred In – On Peak
QTY*77*200*KH	Generation Transferred In – From Parent
MEA*AF*PRQ*200*KH***43	Generation Transferred In – Intermediate Peak
QTY*78*700*KH	Generation Transferred Out
MEA*AF*PRQ*700*KH***41	Generation Transferred Out – Off Peak
QTY*78*1000*KH	Generation Transferred Out
MEA*AF*PRQ*1000*KH***42	Generation Transferred Out – On Peak
QTY*78*800*KH	Generation Transferred Out
MEA*AF*PRQ*800*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*2000*KH	Ending Bank
MEA*AA*PRQ*2000*KH***42	Ending Bank – On Peak
QTY*QE*400*KH	Ending Bank
MEA*AA*PRQ*400*KH***43	Ending Bank – Intermediate Peak

**Parent #1 (Net Meter)**

PTD*BB	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH

<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*800*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*400*KH	Consumption - Off Peak
MEA*AA*PRQ*400*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*100*KH	Consumption - On Peak
MEA*AA*PRQ*100*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*200*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*200*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*500*KH	Generation - Off Peak
MEA*AA*PRQ*500*KH*0*0*41	Total generation, with begin/end readings
QTY*87*1100*KH	Generation - On Peak
MEA*AA*PRQ*1100*KH*0*0*42	Total generation, with begin/end readings
QTY*87*400*KH	Generation - Intermediate Peak
MEA*AA*PRQ*400*KH*0*0*43	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*0*KH	Generation Transferred In – From ParentHost
MEA*AF*PRQ*0*KH***41	Generation Transferred In – Off Peak
QTY*77*0*KH	Generation Transferred In – From ParentHost
MEA*AF*PRQ*0*KH***42	Generation Transferred In – On Peak
QTY*77*0*KH	Generation Transferred In – From ParentHost

MEA*AF*PRQ*0*KH***43	Generation Transferred In – Intermediate Peak
QTY*78*100*KH	Generation Transferred Out – To ParentHost
MEA*AF*PRQ*100*KH***41	Generation Transferred Out – Off Peak
QTY*78*500*KH	Generation Transferred Out – To ParentHost
MEA*AF*PRQ*500*KH***42	Generation Transferred Out – On Peak
QTY*78*200*KH	Generation Transferred Out – To ParentHost
MEA*AF*PRQ*200*KH***43	Generation Transferred Out – Intermediate Peak

**Child #1 (TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*100*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*2600*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*800*KH	Consumption - Off Peak
MEA*AA*PRQ*800*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*1000*KH	Consumption - On Peak
MEA*AA*PRQ*1000*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*800*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*800*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*700*KH	Generation Transferred In
MEA*AF*PRQ*700*KH***41	Generation Transferred In – Off Peak
QTY*77*1000*KH	Generation Transferred In

MEA*AF*PRQ*1000*KH***42	Generation Transferred In – On Peak
QTY*77*800*KH	Generation Transferred In
MEA*AF*PRQ*800*KH***43	Generation Transferred In – Intermediate Peak

**PHI Scenario F - ParentHost is TOU, Parent #1 is TOU, Parent #2 is non-TOU, Child #1 is TOU, Child #2 is non-TOU (only PHI uses Parent accounts)**

**Parent Host Account**

Starting Bank = -2300 kWh

Off Peak -500 kWh

On Peak -1000 kWh

Int Peak -800 kWh

Current usage for 04/05/16 to 05/04/16 = -800 kWh, 0 kWh Billed

Off Peak -100 kWh

On Peak -1500 kWh

Int Peak -200 kWh

Transferred In (from Parent #1 & Parent #2) = -1000 kWh

-800 kWh from Off Peak (from Parent #2)

-200 kWh from On Peak (from Parent #1)

0 kWh from Int Peak

Excess generation for family = -5100 kWh (sum of Starting Bank, Current Period Excess & transferred in from Parent)

-1400 kWh from Off Peak

-2700 kWh from On Peak

-1000 kWh from Int Peak

Transferred Out = -5100 kWh

-1400 kWh from Off Peak

-2700 kWh from On Peak

-1000 kWh from Int Peak

Ending Bank = 0 kWh

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

**Parent Account #1: TOU w/Net Meter (does not utilize starting or ending bank, all excess transfers out to ParentHost)**

Current usage for 04/05/16 to 05/04/16 = 300 kWh, -300 applied from ParentHost, -200 transferred out = 0 kWh billed

Off Peak +100 kWh (100 kWh from Host's Off Peak applied) = 0 kWh

On Peak -200 kWh (200 kWh transferred out to Host, see below) = 0 kWh

Int Peak +200 kWh (200 kWh from Host's Int Peak applied) = 0 kWh

Transferred Out (to ParentHost into Generation available for family) = -200 kWh

0 kWh from Off Peak

-200 kWh from On Peak

0 kWh from Int Peak

**Parent Account #2: non-TOU w/Net Meter (does not utilize starting or ending bank, all excess transfers out to ParentHost)**

Current usage for 04/05/16 to 05/04/16 = -800 kWh, 0 kWh Billed

-800 kWh

Transferred Out (to ParentHost into Generation available for family) = -800 kWh

-800 kWh

**Child #1 (TOU)**

Current usage for 04/05/16 to 05/04/16, 2600 kWh, -2600 kWh applied from ParentHost = 0 kWh billed

Off Peak +800 kWh (800 kWh from Host's Off Peak applied) = 0 kWh  
 On Peak +1000 kWh (1000 kWh from Host's On Peak applied) = 0 kWh  
 Int Peak +800 kWh (800 kWh from Host's Int Peak applied) = 0 kWh

**Child #2 (NON-TOU)**

Current usage for 04/05/16 to 05/04/16 is 4000 kWh, -1700 kWh applied from ParentHost's On Peak, 0 kWh applied from ParentHost's Int Peak, -500 kWh applied from ParentHost's Off Peak = 1800 kWh billed

## Notes:

1. Applies TOU generation using the "waterfall" method. Off Peak to Off Peak, On Peak to On Peak & Intermediate Peak to Intermediate Peak.
2. For TOU Parent, excess generation from an individual peak period transfers to ParentHost's individual peak
3. For non-TOU Parent, excess generation transfers to TOU ParentHost's Off Peak level
4. When applying TOU excess generation to a non-TOU account will use the On Peak energy first, followed by the Intermediate Peak and finally the Off-Peak.

**ParentHost Account (Net Meter TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*800*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*500*KH	Consumption - Off Peak
MEA*AA*PRQ*500*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*1500*KH	Consumption - On Peak
MEA*AA*PRQ*1500*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*600*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*600*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number

REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*600*KH	Generation - Off Peak
MEA*AA*PRQ*600*KH*0*0*41	Total generation, with begin/end readings
QTY*87*3000*KH	Generation - On Peak
MEA*AA*PRQ*3000*KH*0*0*42	Total generation, with begin/end readings
QTY*87*800*KH	Generation - Intermediate Peak
MEA*AA*PRQ*800*KH*0*0*43	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*500*KH	Starting Bank
MEA*AA*PRQ*500*KH***41	Starting Bank – Off Peak
QTY*QH*1000*KH	Starting Bank
MEA*AA*PRQ*1000*KH***42	Starting Bank – On Peak
QTY*QH*800*KH	Starting Bank
MEA*AA*PRQ*800*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*77*800*KH	Generation Transferred In – From Parent
MEA*AF*PRQ*800*KH***41	Generation Transferred In – Off Peak
QTY*77*200*KH	Generation Transferred In – From Parent
MEA*AF*PRQ*200*KH***42	Generation Transferred In – On Peak
QTY*77*0*KH	Generation Transferred In – From Parent
MEA*AF*PRQ*0*KH***43	Generation Transferred In – Intermediate Peak
QTY*78*1400*KH	Generation Transferred Out
MEA*AF*PRQ*1400*KH***41	Generation Transferred Out – Off Peak
QTY*78*2700*KH	Generation Transferred Out
MEA*AF*PRQ*2700*KH***42	Generation Transferred Out – On Peak
QTY*78*1000*KH	Generation Transferred Out
MEA*AF*PRQ*1000*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***41	Ending Bank – Off Peak

QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**Parent #1 (TOU w/Net Meter)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*300*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*400*KH	Consumption - Off Peak
MEA*AA*PRQ*400*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*900*KH	Consumption - On Peak
MEA*AA*PRQ*900*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*600*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*600*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*300*KH	Generation - Off Peak
MEA*AA*PRQ*300*KH*0*0*41	Total generation, with begin/end readings
QTY*87*1100*KH	Generation - On Peak
MEA*AA*PRQ*1100*KH*0*0*42	Total generation, with begin/end readings

QTY*87*400*KH	Generation - Intermediate Peak
MEA*AA*PRQ*400*KH*0*0*43	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*100*KH	Generation Transferred In – From ParentHost
MEA*AF*PRQ*100*KH***41	Generation Transferred In – Off Peak
QTY*77*0*KH	Generation Transferred In – From ParentHost
MEA*AF*PRQ*0*KH***42	Generation Transferred In – On Peak
QTY*77*200*KH	Generation Transferred In – From ParentHost
MEA*AF*PRQ*200*KH***43	Generation Transferred In – Intermediate Peak
QTY*78*0*KH	Generation Transferred Out - To ParentHost
MEA*AF*PRQ*0*KH***41	Generation Transferred Out – Off Peak
QTY*78*200*KH	Generation Transferred Out - To ParentHost
MEA*AF*PRQ*200*KH***42	Generation Transferred Out – On Peak
QTY*78*0*KH	Generation Transferred Out - To ParentHost
MEA*AF*PRQ*0*KH***43	Generation Transferred Out – Intermediate Peak

**Parent #2 (non-TOU w/Net Meter)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*800*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*500*KH	Consumption - Totalized
MEA*AA*PRQ*500*KH*0*0*51	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period

REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*1300*KH	Generation - Totalized
MEA*AA*PRQ*300*KH*0*0*51	Total generation, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*800*KH	Generation Transferred In – From ParentHost
MEA*AF*PRQ*800*KH***51	Generation Transferred Out – Totalized
QTY*78*800*KH	Generation Transferred Out – To ParentHost
MEA*AF*PRQ*800*KH***51	Generation Transferred Out – Totalized

#### Child #1 (TOU)

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*2600*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*800*KH	Consumption - Off Peak
MEA*AA*PRQ*800*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*1000*KH	Consumption - On Peak
MEA*AA*PRQ*1000*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*800*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*800*KH*0*0*43	Total consumption, with begin/end readings

<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*800*KH	Generation Transferred In
MEA*AF*PRQ*800*KH***41	Generation Transferred In – Off Peak
QTY*77*1000*KH	Generation Transferred In
MEA*AF*PRQ*1000*KH***42	Generation Transferred In – On Peak
QTY*77*800*KH	Generation Transferred In
MEA*AF*PRQ*800*KH***43	Generation Transferred In – Intermediate Peak

**Child #2 (Non-TOU)**

<b>PTD*BB</b>	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*1800*KH	Monthly billed KH
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QD*4000*KH	Measured Net Consumption
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*400*KH	Consumption
MEA*AA*PRQ*400*KH*20000*20810*51	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*77*2200*KH	Generation Transferred In
MEA*AF*PRQ*2200*KH***51	Generation Transferred In – Total Non TOU

**PHI/PE Scenario G - ParentHost True-up Event. Host has excess generation and needs a True-up.  
(Showing ParentHost accounts only)**

**Parent Host Account – True Up Event**

Starting Bank = -1200 kWh

Off Peak -300 kWh

On Peak -500 kWh

Int Peak -400 kWh

Current usage for 04/05/16 to 05/04/16 = -225 kWh, 0 kWh Billed

Off Peak -50 kWh

On Peak -100 kWh

Int Peak -75 kWh

Excess generation for family = -1425 kWh

-350 kWh from Off Peak

-600 kWh from On Peak

-475 kWh from Int Peak

Transferred Out = -700 kWh

-200 kWh from Off Peak

-300 kWh from On Peak

-200 kWh from Int Peak

True-Up amounts for Host (cashed out to customer) = -725 kWh

Off Peak -150 kWh

On Peak -300 kWh

Int Peak -275 kWh

Ending Bank = 0 kWh

Off Peak 0 kWh

On Peak 0 kWh

Int Peak 0 kWh

**Notes:**

1. Applies TOU generation using the “waterfall” method. Off Peak to Off Peak, On Peak to On Peak & Intermediate Peak to Intermediate Peak.
2. For TOU Parent, excess generation from an individual peak period transfers to ParentHost’s available generation.
3. During True-Up for TOU, if one TOU peak contains excess generation passed in QTY\*QB, all TOU peaks must be sent even when 0 kWh.
4. During True-Up event, if there is nothing to True-up, the QTY\*QB will NOT be sent.

**Proposed EDI Transactions**

**Parent Account (Net Meter TOU)**

PTD*BB	Monthly Billed Summary Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*D1*0*KH	Monthly billed KH

<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*87*225*KH	Calculated net KH
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*A	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*QD*300*KH	Consumption - Off Peak
MEA*AA*PRQ*300*KH*0*0*41	Total consumption, with begin/end readings
QTY*QD*1000*KH	Consumption - On Peak
MEA*AA*PRQ*1000*KH*0*0*42	Total consumption, with begin/end readings
QTY*QD*275*KH	Consumption - Intermediate Peak
MEA*AA*PRQ*275*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*PM</b>	Meter detail loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
REF*MG*11111111	Meter Number
REF*JH*S	Meter Role
REF*IX*5.0	Number of dials or digits
QTY*87*350*KH	Generation - Off Peak
MEA*AA*PRQ*350*KH*0*0*41	Total generation, with begin/end readings
QTY*87*1100*KH	Generation - On Peak
MEA*AA*PRQ*1100*KH*0*0*42	Total consumption, with begin/end readings
QTY*87*350*KH	Generation - Intermediate Peak
MEA*AA*PRQ*350*KH*0*0*43	Total consumption, with begin/end readings
<b>PTD*BJ</b>	Generation Transferred Loop
DTM*150*20160405	Start period
DTM*151*20160504	End period
QTY*QH*300*KH	Starting Bank
MEA*AA*PRQ*300*KH***41	Starting Bank – Off Peak
QTY*QH*500*KH	Starting Bank
MEA*AA*PRQ*500*KH***42	Starting Bank – On Peak
QTY*QH*400*KH	Starting Bank
MEA*AA*PRQ*400*KH***43	Starting Bank – Intermediate Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***41	Self-generation Applied From Starting Bank to Off Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank

MEA*AF*PRQ*0*KH***42	Self-generation Applied From Starting Bank to On Peak
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***43	Self-generation Applied From Starting Bank to Intermediate Peak
QTY*78*200*KH	Generation Transferred Out
MEA*AF*PRQ*200*KH***41	Generation Transferred Out – Off Peak
QTY*78*300*KH	Generation Transferred Out
MEA*AF*PRQ*300*KH***42	Generation Transferred Out – On Peak
QTY*78*200*KH	Generation Transferred Out
MEA*AF*PRQ*200*KH***43	Generation Transferred Out – Intermediate Peak
QTY*QB*150*KH	True-Up
MEA*AF*PRQ*150*KH***41	True-Up – Off Peak
QTY*QB*300*KH	True-Up
MEA*AF*PRQ*300*KH***42	True-Up – On Peak
QTY*QB*275*KH	True-Up
MEA*AF*PRQ*275*KH***43	True-Up – Intermediate Peak
QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***41	Ending Bank – Off Peak
QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***42	Ending Bank – On Peak
QTY*QE*0*KH	Ending Bank
MEA*AA*PRQ*0*KH***43	Ending Bank – Intermediate Peak

**Maryland SCB Example – 1: Single Meter Consumption Only**

Metered consumption is 763, Meter Multiplier =1.

This demonstrates adding the MU to the BP when it is equal to 1 or missing.

BPT*00*REF09-990201*20230201*DD	Meter detail loop
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT9	Customer name
REF*12*99999999999	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*ESP	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*20230101	Start period
DTM*151*20230131	End period
QTY*D1*763*KH	Monthly billed kWh
PTD*SU	Metered services Summary loop
DTM*150*20230101	Start period
DTM*151*20230131	End period
QTY*QD*763*KH	Calculated summary of all metered for kWh / kvarh only
PTD*PM	Meter detail loop
DTM*150*20230101	Start period
DTM*151*20230131	End period
REF*MG*2222299S	Meter Number

REF*JH*A	Additive meter
REF*IX*6.0	Number of dials or digits
QTY*QD*763*KH	Consumption
MEA*AA*PRQ*763*KH*12000*12763*51	Total consumption, with begin/end readings
<b>PTD*BP</b>	Meter detail loop
DTM*150*20230101	Start period
DTM*151*20230131	End period
REF*MG*2222299S	Meter Number
REF*K6*Y*Rate Description	LDC Rate Description
REF*IX*6.0	Number of dials or digits
REF*JH*A	Additive Meter
QTY*QD*763*KH	Consumption
MEA*AA*PRQ*763*KH*12000*12763*51	Total consumption with begin/end readings
MEA**MU*1	Meter Multiplier

**Maryland SCB Example – 2: Single Meter On/Off Peak**

Following example is for an account with one meter. Meter multiplier is 1, Power factor is 1.9999, and no transformer loss. The meter measures on and off-peak consumption, and the meter readings are at the on / off peak consumption level. The meter also measures on and off-peak demand. The assumption here is that the Meter Multiplier and the Power factor are not currently being passed in the PM loop, so they are included in the BP loop for inclusion on the bill.

- Total consumption is 100 KWH (60 on peak / 40 off-peak). Demand: On peak 4.7, Off peak 4.1 (billed 4.7).
- This example includes the Summary loop which summarizes kWh (and KVARH, if it existed), and the Monthly Billed Summary for billed kWh, kW (and kvarh if relevant).

This example demonstrates adding the MU and ZA information when missing from the PM loops or equal to 1.0.

BPT*00*REF1-990125*20230125*DD	Meter detail loop
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME	Customer name
REF*12*1234567891	LDC Account number
REF*11*1394951	ESP Account number
REF*BLT*ESP	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTM*BB</b>	Monthly Billed Summary loop
DTM*150*20230101	Start period
DTM*151*20230131	End period
QTY*D1*100*KH	Monthly billed kWh
QTY*D1*4.7*K1	Monthly derived (billed) demand
QTY*QD*4.7*K1	Monthly measured demand
PTD*SU	Metered services Summary loop
DTM*150*20230101	Start period
DTM*151*20230131	End period
QTY*QD*100*KH	Calculated summary of all meters for kWh / kvarh only
<b>PTD*PM</b>	Meter detail loop for kWh
DTM*150*20230101	Start period
DTM*151*20230131	End period
REF*MG*11111111	Meter number
REF*NH*RES	LDC Rate
REF*PR*RESRT	LDC Rate Subclass
REF*JH*A	Additive meter
REF*IX*6.0	Number of dials or digits
QTY*QD*100*KH	Consumption
MEA*AA*PRQ*100*KH***51	Total consumption with begin/end reads
QTY*QD*60*KH	Consumption
MEA*AA*PRQ*60*KH***42	(On peak with consumption and begin/end reads)
QTY*QD*40*KH	Consumption
MEA*AA*PRQ*40*KH***41	(Off peak with consumption and begin/end reads)
<b>PTD*BP</b>	Meter detail loop for kWh
DTM*150*20230101	Start period
DTM*151*20230131	End period
REF*NH*RES	LDC Rate
REF*PR*RESRT	LDC Rate Subclass
REF*JH*A	Additive meter
REF*NH*RES	LDC Rate
REF*K6*Y*Rate Description	LDC Rate Description
QTY*QD*100*KH	Consumption
MEA**MU*1	Meter multiplier = 1
MEA*AA*PRQ*100*KH*1201*1300*51	Total consumption with begin/end reads

QTY*QD*60*KH	On Peak Consumption
MEA**MU*1	Meter multiplier = 1
MEA*AA*PRQ*60*KH*1201*1260*42	Total On Peak Consumption with begin/end reads
QTY*QD*40*KH	Off Peak Consumption
MEA**MU*1	Meter multiplier = 1
MEA*AA*PRQ*40*KH*11001*11060*41	Total Off peak with consumption and begin/end reads
<b>PTD*PM</b>	Meter detail loop for kW
DTM*150*20230101	Start period
DTM*151*20230131	End period
REF*MG*11111111	Meter number
REF*NH*RES	LDC Rate
REF*PR*RESRT	LDC Rate Subclass
REF*JH*A	Additive meter
REF*IX*6.0	Number of dials or digits
QTY*QD*4.7*K1	Demand
MEA*AA*PRQ*4.7*K1***42	On peak demand – readings not required since reset each month
QTY*QD*4.2*K1	Demand
MEA*AA*PRQ*4.2*K1***41	Off peak demand
<b>PTD*BP</b>	Meter detail loop for kW
DTM*150*20230101	Start period
DTM*151*20230131	End period
REF*MG*11111111	Meter number
REF*K6*Y*Rate Description	LDC Rate Description
REF*JH*A	Additive meter
QTY*QD*4.7*K1	Demand
MEA**MU*1	Meter multiplier = 1
MEA**ZA*1.9999	Power factor = 1.9999
MEA*AA*PRQ*4.7*K1***42	On peak demand – readings not required since reset each month
QTY*QD*4.2*K1	Demand
MEA**MU*1	Meter multiplier = 1
MEA**ZA*1.9999	Power factor = 1.9999
MEA*AA*PRQ*4.2*K1***41	Off peak demand

**Maryland SCB Example – 3: Multiple Unmetered Services**

PHI Unmetered Street Lighting for multiple device types. Unmetered consumption is 15,689 kh across 380 unmetered devices representing 5 unmetered device types.

This example shows the individual unmetered device detail added to the BP loops. Detail about each group of unmetered devices is required to be passed to provide the level of detail currently printed on customer bills by PE and PHI. The total unmetered consumption will be passed in the BC loop as is done today.

The Meter Number - REF\*MG\*UNMETERED is defaulted to UNMETERED so that the required segments needed to pass the unmetered account detail in the BP loop can be identified as they are different than the PM loop content

Street Lighting Account Usage Information as example on Customer Bill...

Lamp Size	Quantity	Total Usage
100 WATT HPS	186	8122
150 WATT HPS	24	1528
400 WATT HPS	8	1368
70 WATT HPS	151	4671
ATTACHED TO C&P TEL CO POLE	11	0
Total	380	15689

BPT*00*REF09-990201*20230401*DD	Meter detail loop
N1*8S*LDC COMPANY*1*007909411	LDC Company
N1*SJ*ESP COMPANY*9*007909422ESP1	ESP Company
N1*8R*CUSTOMER NAME – ACCT9	Customer name
REF*12*99999999999	LDC Account number
REF*11*13949594	ESP Account number
REF*BLT*ESP	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*20230301	Start period
DTM*151*20230331	End period
QTY*D1*15689*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20230301	Start period
DTM*151*20230331	End period
QTY*QD*15689*KH	Calculated summary of all metered for kWh / kvarh only
<b>PTD*BP</b>	Unmetered Services Detail
DTM*150*20230301	Start period
DTM*151*20230331	End period
REF*MG*UNMETERED	Meter Number
REF*K6*Y*Unmetered Street Lighting	Rate Description
REF*PRT*UNMETERED*100 WATT HPS	Unmetered device description
QTY*QD*8122*EA>>186>KH>>	Unmetered device usage
<b>PTD*BP</b>	Unmetered Services Detail
DTM*150*20230301	Start period
DTM*151*20230331	End period
REF*MG*UNMETERED	Meter Number
REF*K6*Y*Unmetered Street Lighting	Rate Description
REF*PRT*UNMETERED*150 WATT HPS	Unmetered device description
QTY*QD*1528*EA>>24>KH>>	Unmetered device usage
<b>PTD*BP</b>	Unmetered Services Detail
DTM*150*20230301	Start period

DTM*151*20230331	End period
REF*MG*UNMETERED	Meter Number
REF*K6*Y*Unmetered Street Lighting	Rate Description
REF*PRT*UNMETERED*400 Watt HPS	Unmetered device description
QTY*QD*368*EA>>8>KH>>	Unmetered device usage
<b>PTD*BP</b>	Unmetered Services Detail
DTM*150*20230301	Start period
DTM*151*20230331	End period
REF*MG*UNMETERED	Meter Number
REF*K6*Y*Unmetered Street Lighting	Rate Description
REF*PRT*UNMETERED*70 WATT HPS	Unmetered device description
QTY*QD*4671*EA>>151>KH>>	Unmetered device usage
<b>PTD*BP</b>	Unmetered Services Detail
DTM*150*20230301	Start period
DTM*151*20230331	End period
REF*MG*UNMETERED	Meter Number
REF*K6*Y*Unmetered Street Lighting	Rate Description
REF*PRT*UNMETERED*ATTACHED TO C&P TEL CO POLE	Unmetered device description
QTY*QD*0*EA>>11>KH>>	Unmetered device usage
<b>PTD*BC</b>	Unmetered Services Summary
DTM*150*20230301	Start period
DTM*151*20230331	End period
QTY*QD*15689*KH	Unmetered total consumption

**Maryland SCB Example – 4: Telecommunications Network**

No meter summary section

BPT*00*MD867M672304030918596666666666*20230403* DD	Meter detail loop
N1*8S*PEPCO MD*1*006920284	LDC Company
N1*SJ*SUPPLIER NAME*9*9999999999999	ESP Company
N1*8R*CUSTOMER NAME	Customer name
REF*12*999999999999	LDC Account number
REF*11*81111111	ESP Account number
REF*BLT*ESP	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*20230301	Start period
DTM*151*20230331	End period
QTY*D1*95485*KH	Monthly billed kWh
<b>PTD*BP</b>	Unmetered Services Detail
DTM*150*20230301	Start period
DTM*151*20230331	End period
REF*MG*UNMETERED	Meter Number
REF*K6*N*Telecommunications Network	Rate Description
<b>PTD*BC</b>	Unmetered Services Summary
DTM*150*20230301	Start period
DTM*151*20230331	End period
QTY*QD*95485*KH	Unmetered total consumption

## Consumption information as example on Customer Bill...

Meter Number / Energy Type	Current Reading	Previous Reading	Multiplier	Total Use	Total for Billing
KZD357605737	Sept 7	Aug 7			
On-Peak Use (kWh)	029705 (actual)	029362 (actual)	160	54880	54851
Off-Peak Use (kWh)	037075 (actual)	036679 (actual)	160	64320	64304
On-Peak Demand (kW)	1.421 (actual)		160	227.36	227.35
Off-Peak Demand (kW)	1.350 (actual)		160	216.00	215.95
Reactive Use (RkWh)	017862	017480	160	61120	61055
Total Billing Demand					227.00
Total Use-kWh				119200	119155
Load Factor: 68.35%		Power Factor: 88.99%			
The "Total for Billing" column represents data from Interval pulses, which is utilized for billing purposes.					

BPT~00~MD867M902309081823229999999999~20230908~DD	
N1~8S~Delmarva Power (MD)~9~006971618MD	LDC Company
N1*SJ*SUPPLIER NAME*9*999999999	ESP Company
N1*8R*CUSTOMER NAME	Customer name
REF~11~1111111	Supplier Account Number
REF*BLT*ESP	Bill type
REF*PC*DUAL	Bill Calculator
REF~12~999999999999999999999999999999	LDC Account number
PTD*BB	Bill Services Loop
DTM~150~20230807	Start period
DTM~151~20230907	End period
QTY~D1~119154~KH	Monthly billed kWh
QTY~D1~227.36~K1	Monthly derived (billed) demand
QTY~QD~227.36~K1	Monthly measured demand
PTD*SU	Metered services Summary loop
DTM~150~20230807	Start period
DTM~151~20230907	End period
QTY~QD~119154~KH	Monthly billed kWh
QTY~QD~61120~K3	Monthly derived (billed) demand
PTD*PM	Meter detail loop for kWh
DTM~150~20230807	Start period
DTM~151~20230907	End period
REF~MG~KZD357605737	Meter number
REF~NH~ULGSTOU	LDC Rate
REF*JH*A	Additive meter
REF*IX*6.0	Number of dials or digits
QTY~QD~64303~KH	Consumption
MEA~AA~PRQ~64303~KH~0~64303~41	Total consumption with begin/end reads (off Peak)
MEA~~MU~160	Meter multiplier
QTY~QD~54851~KH	Consumption
MEA~AA~PRQ~54851~KH~0~54851~42	Total consumption with begin/end reads (on Peak)

MEA~~MU~160	Meter multiplier
<b>PTD*BP</b>	Bill Presentment loop for kWh
DTM~150~20230807	Start period
DTM~151~20230907	End period
REF~MG~KZD357605737	Meter number
REF~NH~ULGSTOU	LDC Rate
REF*K6*Y*Rate Description	LDC Rate Description
REF~JH~A	Additive meter
REF~IX~6.0	Number of dials or digits
QTY~QD~64304~KH	Consumption
MEA~AA~PRQ~64303~KH~0~64303~41	Total consumption with begin/end reads (off Peak)
QTY~QD~64320~KH	Consumption
MEA~AA~RUD~64320~KH~0~64303~41	Total consumption with begin/end reads (off Peak)
MEA~~MU~160	Meter multiplier
QTY~QD~54851~KH	Consumption
MEA~AA~PRQ~54851~KH~0~54851~42	Total consumption with begin/end reads (on Peak)
QTY~QD~54880~KH	Consumption
MEA~AA~RUD~54880~KH~0~54851~42	Total consumption with begin/end reads (on Peak)
MEA~~MU~160	Meter multiplier
<b>PTD~PM</b>	Meter detail loop for kWh
DTM~150~20230807	Start period
DTM~151~20230907	End period
REF~MG~KZD357605737	Meter number
REF~NH~ULGSTOU	LDC Rate
REF~JH~A	Additive meter
REF~IX~6.0	Number of dials or digits
QTY~QD~61055~K3	Consumption
MEA~AA~PRQ~119154~K3~0~119154~51	Total consumption with begin/end reads (off Peak)
MEA~~MU~160	Meter multiplier
<b>PTD*BP</b>	Bill Presentment loop for kWh
DTM~150~20230807	Start period
DTM~151~20230907	End period
REF~MG~KZD357605737	Meter number
REF~NH~ULGSTOU	LDC Rate
REF*K6*Y*Rate Description	LDC Rate Description
REF~JH~A	Additive meter
REF~IX~6.0	Number of dials or digits
QTY~QD~61055~K3	Consumption
MEA~AA~PRQ~119155~K3~0~119155~51	Total consumption with begin/end reads (off Peak)
MEA~~MU~160	Meter multiplier
QTY~QD~61120~K3	Consumption
MEA~AA~RUD~119200~K3~0~119200~51	Total consumption with begin/end reads (off Peak)
MEA~~MU~160	Meter multiplier
<b>PTD~PM</b>	Meter detail loop for kWh
DTM~150~20230807	Start period
DTM~151~20230907	End period
REF~MG~KZD357605737	Meter number
REF~NH~ULGSTOU	LDC Rate
REF~JH~A	Additive meter

REF~IX~6.0	Number of dials or digits
QTY~QD~227.35~K1	Consumption
MEA~AA~PRQ~227.35~K1~0~227.35~42	Total consumption with begin/end reads (off Peak)
MEA~~MU~160	Meter multiplier
QTY~QD~215.95~K1	Consumption
MEA~AA~PRQ~215.95~K1~0~215.95~41	Total consumption with begin/end reads (on Peak)
MEA~~MU~160	Meter multiplier
<b>PTD*BP</b>	Bill Presentment loop for kWh
DTM~150~20230807	Start period
DTM~151~20230907	End period
REF~MG~KZD357605737	Meter number
REF~NH~ULGSTOU	LDC Rate
REF*K6*Y*Rate Description	LDC Rate Description
REF~JH~A	Additive meter
REF~IX~6.0	Number of dials or digits
QTY~QD~227.35~K1	Consumption
MEA~AA~PRQ~227.35~K1~0~227.35~42	Total consumption with begin/end reads (off Peak)
MEA~~MU~160	Meter multiplier
QTY~QD~227.36~K1	Consumption
MEA~AA~RUD~227.36~K1~0~227.36~42	Total consumption with begin/end reads (off Peak)
MEA~~MU~160	Meter multiplier
QTY~QD~215.95~K1	Consumption
MEA~AA~PRQ~215.95~K1~0~215.95~41	Total consumption with begin/end reads (on Peak)
MEA~~MU~160	Meter multiplier
QTY~QD~216~K1	Consumption
MEA~AA~RUD~216~K1~0~216~41	Total consumption with begin/end reads (on Peak)
MEA~~MU~160	Meter multiplier
MEA~~ZA*0.8899	Power factor =0.8889

**Maryland SCB Example – 6: PEPCO Meter Exchange**

Consumption information as example on Customer Bill...

Meter Number / Energy Type	Current Reading	Previous Reading	Difference	Multiplier	Total Use
99F105746440	Jun 21	Jun 21			
Use (kWh)	051668(removed)	051640 (actual)	28	1	28
Your meter was changed on Jun 22					
TXA172818236	Jul 20	Jun 22			
Use (kWh)	000874	000000	874	1	874
Total Use-kWh					902
Your next meter reading is scheduled for August 18, 2023					

BPT*00*MD867M012307280726479999999999*20230720*DD	Meter detail loop
N1*8S*PEPCO MD*1*006920284	LDC Company
N1*SJ*SUPPLIER NAME*9*999999999999	ESP Company
N1*8R*CUSTOMER NAME	Customer name
REF*12*999999999999	LDC Account number
REF*BLT*ESP	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTD*BB</b>	Monthly Billed Summary loop
DTM*150*20230621	Start period
DTM*151*20230720	End period
QTY*D1*902*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20230621	Start period
DTM*151*20230720	End period
QTY*QD*902*KH	Monthly billed kWh
<b>PTD*PM</b>	Meter detail loop for kWh
DTM*150*20230621	Start period
DTM*514*20230621	End period
REF*MG*99F105746440	Meter number
REF*NH*250	LDC Rate
REF*JH*A	Additive meter
REF*IX*6.0	Number of dials or digits
QTY*QD*28*KH	Consumption
MEA*AA*PRQ*28*KH*51640*51668*51	Total consumption with begin/end reads
<b>PTD*BP</b>	Bill Presentment Loop
DTM*150*20230621	Start period
DTM*514*20230621	End period
REF*MG*99F105746440	Meter number
REF*NH*250	LDC Rate
REF*K6*Y*Residential Service	LDC Rate Description
REF*JH*A	Additive meter
REF*IX*6.0	Number of dials or digits
QTY*QD*28*KH	Consumption
MEA*AA*PRQ*28*KH*51640*51668*51	Total consumption with begin/end reads
MEA**MU*1.0	Meter multiplier
<b>PTD*PM</b>	Meter detail loop for kWh
DTM*514*20230622	Start period
DTM*151*20230720	End period
REF*MG*TXA172818236	Meter number
REF*NH*250	LDC Rate

REF*JH*A	Additive meter
REF*IX*6.0	Number of dials or digits
QTY*QD*874*KH	Consumption
MEA*AA*PRQ*874*KH*0*874*51	Total consumption with begin/end reads
<b>PTD*BP</b>	Bill Presentment Loop
DTM*514*20230622	Start period
DTM*151*20230720	End period
REF*MG*TXA172818236	Meter number
REF*NH*250	LDC Rate
REF*K6*Y*Residential Service	LDC Rate Description
REF*JH*A	Additive meter
REF*IX*6.0	Number of dials or digits
QTY*QD*874*KH	Consumption
MEA*AA*PRQ*874*KH*0*874*51	Total consumption with begin/end reads
MEA**MU*1.0	Meter multiplier

**Maryland SCB Example – 7: PE Community Solar Child Account**

No Self Generation on the Child Account

Allocation of 16,651 kwh from the Host Account

Starting Child Bank QTY\*QH = 0

Child Self Generation QTY\*79 = 0

Child Ending Bank QTY\*QE = 0

Generation transferred from Host to Child account QTY\*77 = 16,650

The REF\*AN Segment (in the PTM\*BJ – QTY\*77 Loop) provides the name of the community Solar program

The following example is for a PE CHILD, Community Solar account that has consumption of 21,120 kwh. The Child account does not have self-generation, but receives an allocation of from the community solar host account of 16,651 kwh resulting in billed usage of 4,469 kwh,

This example demonstrates adding the MU and ZA information when missing from the PM loops or equal to 1.0.

BPT*00*000263518990*20230605*DD	Meter detail loop
DTM*649*20230608*0958	
N1*8S*POTOMAC EDISON MD - DISTRIBUTI*9*043381565EDC	LDC Company
N1*SJ*SUPPLIER NAME*9*123456789PE01	ESP Company
N1*8R*CUSTOMER NAME	Customer name
REF*12*08012345678909876543	LDC Account number
REF*11*9999999	ESP Account number
REF*BLT*ESP	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTM*BB</b>	Monthly Billed Summary loop
DTM*150*20230415	Start period
DTM*151*20230511	End period
QTY*D1*4469.00000*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20230415	Start period
DTM*151*20230511	End period
QTY*QD*21120*KH	Calculated summary of all meters for kWh
<b>PTD*PM</b>	Meter detail loop for kWh
DTM*150*20230415	Start period
DTM*151*20230511	End period
REF*MG*G123456789	Meter number
REF*NH*PE-GSG2D	LDC Rate
REF*JH*A	Additive meter

REF*IX*5.0	Number of dials or digits
QTY*QD*21120*KH	Consumption
MEA*EA*PRQ*21120.00000*KH*16216.00000*16744.00000*51	Total consumption with begin/end reads
MEA**MU*40.00000	Meter Multiplier
<b>PTD*BP</b>	Meter detail loop for kWh
DTM*150*20230415	Start period
DTM*151*20230511	End period
REF*MG*G123456789	Meter number
REF*NH*PE-GSG2D	LDC Rate
REF*JH*A	Additive meter
REF*IX*5.0	Number of dials or digits
QTY*QD*21120*KH	Consumption
MEA*EA*PRQ*21120.00000*KH*16216.00000*16744.00000*51	Total consumption with begin/end reads
MEA**MU*40.00000	Meter Multiplier
<b>PTD*BJ</b>	
DTM*150*20230415	Start period
DTM*151*20230511	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***51	Starting Bank
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***51	Self-generation Applied From Starting Bank Total
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***51	Ending Bank – Total
QTY*77*16651*KH	Generation Transferred In
MEA*AF*PRQ*16651*KH***51	Generation Transferred into Child account from Host - Total
REF*AN*CHILD* Maryland Community Solar Program.	MD Community Solar Program Description

**Maryland SCB Example – 8: PE Community Solar Child Account**

No Self Generation on the Child Account

Allocation of 16,651 kwh from the Host Account – From two Community Solar Programs

Starting Child Bank QTY\*QH = 0

Child Self Generation QTY\*79 = 0

Child Ending Bank QTY\*QE = 0

Generation transferred from Host to Child account QTY\*77 = 10,000 – Community Solar Program 1.

Generation transferred from Host to Child account QTY\*77 = 6,651 – Community Solar Program 2.

The REF\*AN Segment, in the PTM\*BP Loop, provides the name of the Community Solar Programs.

The following example is for a PE CHILD, Community Solar account that has consumption of 21,120 kwh. The Child account does not have self-generation, but receives an allocation of from the community solar host account of 16,651 kwh resulting in billed usage of 4,469 kwh,

This example demonstrates adding the MU and ZA information when missing from the PM loops or equal to 1.0.

BPT*00*000263518990*20230605*DD	Meter detail loop
DTM*649*20230608*0958	
N1*8S*POTOMAC EDISON MD - DISTRIBUTI*9*043381565EDC	LDC Company
N1*SJ*SUPPLIER NAME*9*123456789PE01	ESP Company
N1*8R*CUSTOMER NAME	Customer name
REF*12*08012345678909876543	LDC Account number
REF*11*9999999	ESP Account number

REF*BLT*ESP	Bill type
REF*PC*DUAL	Bill Calculator
<b>PTM*BB</b>	Monthly Billed Summary loop
DTM*150*20230415	Start period
DTM*151*20230511	End period
QTY*D1*4469.00000*KH	Monthly billed kWh
<b>PTD*SU</b>	Metered services Summary loop
DTM*150*20230415	Start period
DTM*151*20230511	End period
QTY*QD*21120*KH	Calculated summary of all meters for kWh
<b>PTD*PM</b>	Meter detail loop for kWh
DTM*150*20230415	Start period
DTM*151*20230511	End period
REF*MG*G123456789	Meter number
REF*NH*PE-GSG2D	LDC Rate
REF*JH*A	Additive meter
REF*IX*5.0	Number of dials or digits
QTY*QD*21120*KH	Consumption
MEA*EA*PRQ*21120.00000*KH*16216.00000*16744.00000*51	Total consumption with begin/end reads
MEA**MU*40.00000	Meter Multiplier
<b>PTD*BP</b>	Meter detail loop for kWh
DTM*150*20230415	Start period
DTM*151*20230511	End period
REF*MG*G123456789	Meter number
REF*NH*PE-GSG2D	LDC Rate
REF*JH*A	Additive meter
REF*IX*5.0	Number of dials or digits
REF*AN*CHILD*CS Program Description	Community Solar Program Description
QTY*QD*21120*KH	Consumption
MEA*EA*PRQ*21120.00000*KH*16216.00000*16744.00000*51	Total consumption with begin/end reads
MEA**MU*40.00000	Meter Multiplier
<b>PTD*BJ</b>	
DTM*150*20230415	Start period
DTM*151*20230511	End period
QTY*QH*0*KH	Starting Bank
MEA*AF*PRQ*0*KH***51	Starting Bank
QTY*79*0*KH	Self-generation Applied From Starting Bank
MEA*AF*PRQ*0*KH***51	Self-generation Applied From Starting Bank Total
QTY*QE*0*KH	Ending Bank
MEA*AF*PRQ*0*KH***51	Ending Bank – Total
QTY*77*16651*KH	Generation Transferred In
MEA*AF*PRQ*16651*KH***51	Generation Transferred into Child account from Host - Total
REF*AN*CHILD*CS Program Description	Community Solar Program Description

**FirstEnergy (PA & NJ) Net Metering Examples**

867MU EXAMPLE 1 - CUSTOMER GENERATION (2000) MORE THAN USAGE (1500)

BPT\*00\*700418133078E\*20181213\*DD  
 N1\*SJ\*SUPPLIER NAME\*9\*123456789ABCD  
 N1\*8S\*JCPL-DISTRIBUTION\*1\*006973358  
 N1\*8R\*CUSTOMER NAME  
 REF\*12\*08012234567890876543  
 REF\*11\*123654879  
 REF\*BLT\*LDC  
 REF\*PC\*LDC  
 PTD\*BB  
 DTM\*150\*20181115  
 DTM\*151\*20181213  
 QTY\*D1\*0000.00000\*KH      ←=====NET USAGE  
 PTD\*SU\*  
 DTM\*150\*20181115  
 DTM\*151\*20181213  
 QTY\*QD\*1500.00000\*KH      ←=====DELIVERED USAGE  
 QTY\*87\*2000.00000\*KH      ←=====RECEIVED USAGE  
 PTD\*PM  
 DTM\*150\*20181115  
 DTM\*151\*20181213  
 REF\*MG\*S317190462  
 REF\*6W\*1      ←=====DELIVERED CHANNEL ID  
 REF\*NH\*ME-RSD  
 REF\*JH\*A  
 REF\*IX\*5.0  
 QTY\*QD\*1500.00000\*KH  
 MEA\*EA\*PRQ\*1500.00000\*KH\*32134.00000\*33634.00000\*51  
 PTD\*PM  
 DTM\*150\*20181115  
 DTM\*151\*20181213  
 REF\*MG\*S317190462  
 REF\*6W\*2      ←=====RECEIVED CHANNEL ID  
 REF\*NH\*JC-RSD  
 REF\*JH\*S  
 REF\*IX\*5.0  
 QTY\*87\*2000.00000\*KH  
 MEA\*EA\*PRQ\*2000.00000\*KH\*2393.00000\*4393.00000\*51

867MU EXAMPLE 1 - CUSTOMER GENERATION (2000) MORE THAN USAGE (1500)

BPT\*00\*700418133078E\*20181213\*DD  
 N1\*SJ\*SUPPLIER NAME\*9\*123456789ABCD  
 N1\*8S\*JCPL-DISTRIBUTION\*1\*006973358  
 N1\*8R\*CUSTOMER NAME  
 REF\*12\*08012234567890876543  
 REF\*11\*123654879  
 REF\*BLT\*LDC  
 REF\*PC\*LDC  
 PTD\*BB  
 DTM\*150\*20181115  
 DTM\*151\*20181213  
 QTY\*D1\*0000.00000\*KH      ←=====NET USAGE  
 PTD\*SU\*  
 DTM\*150\*20181115  
 DTM\*151\*20181213  
 QTY\*QD\*1500.00000\*KH      ←=====DELIVERED USAGE  
 QTY\*87\*2000.00000\*KH      ←=====RECEIVED USAGE  
 PTD\*PM  
 DTM\*150\*20181115  
 DTM\*151\*20181213  
 REF\*MG\*S317190462  
 REF\*6W\*1      ←=====DELIVERED CHANNEL ID  
 REF\*NH\*ME-RSD  
 REF\*JH\*A  
 REF\*IX\*5.0  
 QTY\*QD\*1500.00000\*KH  
 MEA\*EA\*PRQ\*1500.00000\*KH\*32134.00000\*33634.00000\*51  
 PTD\*PM  
 DTM\*150\*20181115  
 DTM\*151\*20181213  
 REF\*MG\*S317190462  
 REF\*6W\*2      ←=====RECEIVED CHANNEL ID  
 REF\*NH\*JC-RSD  
 REF\*JH\*S  
 REF\*IX\*5.0  
 QTY\*87\*2000.00000\*KH  
 MEA\*EA\*PRQ\*2000.00000\*KH\*2393.00000\*4393.00000\*51