

# PAPR DONNING PROCEDURES

1. Hydration and pre-entry medical monitoring.
  - a. Remove and secure all jewelry, loose hair & personal items.
  - b. Optional: Change into paper scrubs / switch boots for smaller shoes if not wearing overshoes

2. Thoroughly inspect PPE prior to donning (correct size/no rips or tears).



3. Don any communication equipment to be worn under PPE, test for function.

4. Perform hand hygiene and allow hands to dry. hand washing is preferred but ABHS may be used.

5. Don inner gloves



6. While seated: Don the full body suit with assistance and zip half way (if wearing overshoes remove boots/sneakers).



7. Put on outer boots/shoe covers over the suit. Cuff if necessary do not tape.



8. Don outer gloves, bending the elbow at 90° tape seem leaving a tab for removal.



9.
  - a. If the PAPR includes an inner shroud roll coverall suit hood into the suit back.
  - b. If the PAPR does not have an inner shroud don hood and zip suit closed.

10. Zip coverall closed.

11. Don PAPR belt, Include battery and filter pack.



12. Check to make sure that the battery clip did not puncture the suit.

13. Turn on the PAPR.

14. Don the PAPR hood.

15. Inshore the hood is properly seated on the head and entry person has no visible obstructions.



16. If the PAPR hood has an inner shroud tuck into suit.

17. Donning partner: Make sure the suit is zipped up to the neck and peel self-adhering strips and secure zipper flap.

18. Perform range of motion evaluation: Extend arms and bend at waste, squat, extend arms twist left to right.



19. Donning partner: Observe suit for gaps or restrictions.

20. Donning partner: Check all PPE to ensure complete coverage without gaps, tears, or vision obstructions

21. Acknowledge the entry person is ready.
  - a. Team members are to enter utilizing a buddy system at all times.

